

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Furmax](#) /
- › [Furmax Electric Standing Desk Instruction Manual - Model HAD0162](#)

Furmax HAD0162

Furmax Electric Standing Desk Instruction Manual

Model: HAD0162

[Instructions](#) [Overview](#) [Safety Information](#) [Setup](#) [Operating](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Furmax Electric Standing Desk is designed to provide a comfortable and healthy working environment. Featuring electric height adjustment and memory presets, it allows seamless transitions between sitting and standing positions. The desk includes a monitor stand, cup holder, headphone hook, and cable management holes for an organized workspace. Its robust metal frame ensures stability, even at maximum height.



Figure 1: The Furmax Electric Standing Desk in a typical office environment, showcasing its design and functionality with a monitor and laptop.

2. IMPORTANT SAFETY INFORMATION

- Always ensure the desk is on a stable and level surface.
- Do not exceed the weight capacity of 132 lbs (60 kg).
- When assembling the desk, use only the tools and instructions provided.
- Securely fasten all parts and check for stability before use.
- For electrical safety, do not touch or immerse the motor in water or any other liquid.
- Unplug the desk when not in use or during cleaning.
- Keep the desk away from children and pets to prevent injury.

3. SETUP AND ASSEMBLY

Assembly of the Furmax Electric Standing Desk is required. All necessary tools are included in the package. The tabletop consists of two pieces, which are joined during assembly. Follow the detailed instructions provided in the included manual for step-by-step guidance.

3.1. Key Components and Assembly Steps

- **Desk Frame:** The desk legs feature a box frame structure made of steel, providing stability. Ensure all connections are tightened securely.
- **Tabletop:** The wooden tabletop comes in two pieces. Carefully align and secure them according to the manual.
- **Monitor Stand:** The additional 3.7-inch height monitor stand is installed on top of the main desktop.
- **Accessories:** The cup holder, headphone hook, and hand controller can be installed on either the left or right side of the desktop based on user preference.
- **Cable Management:** Utilize the two integrated cable holes to route and organize your power and data cables.



Figure 2: Detailed view of the desk's integrated features: monitor stand, headphone hook, cup holder, and cable holes for efficient organization.

3.2. Assembly Video Guide

Your browser does not support the video tag.

Video 1: A user demonstrates the assembly process and initial setup of the Furmax Electric Standing Desk, highlighting key steps and features.

4. OPERATING INSTRUCTIONS

The Furmax Electric Standing Desk features an intuitive control panel for easy height adjustment and memory functions.

4.1. Height Adjustment

- **Up/Down Buttons:** Use the **Up** (▲) and **Down** (▼) buttons on the control panel to smoothly adjust the desk height. The motor lift mechanism provides a height range from 28.7 inches to 46.4 inches.
- **LED Display:** The current desk height is displayed on the LED screen of the control panel.



Figure 3: The intelligent push-button control panel, showing the LED display for height and buttons for adjustment and memory presets.

4.2. Memory Presets

4.5. Operation Video Guides

Your browser does not support the video tag.

Video 2: A user demonstrates the smooth electric height adjustment and memory preset functions of the desk.

Your browser does not support the video tag.

Video 3: This video provides a general overview of the Furmax Electric Standing Desk, showcasing its features and operation.

5. MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Inspections:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Electrical Components:** Keep the motor and control panel free from dust and moisture. Do not attempt to open or repair electrical components yourself.

6. TROUBLESHOOTING

- **Desk Not Moving:** Ensure the power cord is securely plugged into both the desk and a working electrical outlet. Check for any obstructions preventing movement.
- **Uneven Movement:** Verify that the desk is on a level surface and that all assembly screws are tightened evenly.
- **Control Panel Unresponsive:** Unplug the desk from the power source for 30 seconds, then plug it back in to reset the system.
- **Other Issues:** For complex problems or issues not listed here, please contact Furmax customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Furmax
Model Number	HAD0162
Product Dimensions	24"D x 47"W x 46.4"H
Adjustable Height Range	28.7 - 46.4 inches
Monitor Stand Dimension	27.5"L x 8.6"W x 3.7"H
Weight Capacity	132 lbs (60 kg)
Color	Carbon Black
Material Type	Wood, Metal (Alloy Steel Base)

Special Feature	Electric Height Adjustment, Memory Presets, Monitor Stand, Cup Holder, Headphone Hook, Cable Holes
Required Assembly	Yes (All tools included)

8. WARRANTY & SUPPORT

The Furmax Electric Standing Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included in your product packaging or contact Furmax customer support directly.

If you have any questions, require assistance with assembly, operation, or troubleshooting, please do not hesitate to contact the manufacturer, Furmax. Their professional after-sale team is available to help you.

Manufacturer: Furmax

Seller: Furmax (via Amazon)

For direct support, please visit the [Furmax Store on Amazon](#) or refer to the contact information provided in your product documentation.