

[Manuals.plus](#) /

› [GWY](#) /

› GWY Air Fryer Accessories Instruction Manual for Gourmia GAF798 GAF716 7QT Air Fryer

GWY GAF798, GAF716 (7QT)

GWY Air Fryer Accessories Instruction Manual

For Gourmia GAF798 and GAF716 7QT Air Fryers

INTRODUCTION

Thank you for choosing GWY Air Fryer Accessories. This product is designed to enhance your cooking experience with Gourmia GAF798 and GAF716 7QT air fryers. This manual provides instructions for proper installation, use, and maintenance to ensure optimal performance and longevity of your accessories.

These accessories include a non-stick crisper plate and protective rubber bumpers, crafted from food-grade steel with an enameled coating. They are designed for durability and ease of cleaning.



Compatible with



**Gourmia
GAF716 7QT**



**Gourmia
GAF798 7QT**

Image: The crisper plate shown with compatible Gourmia GAF716 and GAF798 7QT air fryer models, indicating proper fit.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 × Air Fryer Grill Plate (Crisper Plate)
- 4 × Air Fryer Rubber Bumpers

Package Includes

1 pcs replacement grill pan
4 pcs rubber bumper




Image: Contents of the package, including one grill pan and four rubber bumpers. Dimensions of the grill pan (8.97"x8.97") and bumpers (0.78"x0.98") are indicated.

SETUP

Before first use, ensure all packaging materials are removed. Wash the grill plate and rubber bumpers with warm, soapy water, then rinse and dry thoroughly.

Installing the Rubber Bumpers

1. Locate the designated slots on the sides of the air fryer grill plate.
2. Gently press each rubber bumper into its corresponding slot until securely fitted. The bumpers protect the air fryer basket from scratches and ensure the grill plate is stable.

Placing the Grill Plate

1. Ensure your air fryer basket is clean and dry.
2. Carefully place the grill plate into the air fryer basket. The handle on the grill plate should face upwards for easy removal.

3. Confirm the grill plate sits level and securely within the basket before adding food.

OPERATING

The GWY Air Fryer Grill Plate is designed to facilitate even cooking and crisping in your Gourmia air fryer.

Usage Guidelines

- Place food directly onto the grill plate. The design promotes whirlwind airflow, ensuring food is heated more evenly.
- The non-stick coating allows for cooking with minimal oil, contributing to healthier meals.
- The grill plate is suitable for a variety of foods, including meats, vegetables, fries, and baked goods.

Make it Easier for You to Cook




Image: The grill plate positioned within an air fryer, illustrating its use for cooking diverse food items.



Image: A visual representation of food being cooked on the grill plate, emphasizing uniform heating and achieving a crispy texture.

MAINTENANCE

Proper cleaning and care will extend the life of your air fryer accessories.

Cleaning Instructions

- **Allow to Cool:** Always allow the grill plate to cool completely before cleaning to prevent warping or damage to the non-stick coating.
- **Hand Washing:** Wash the grill plate with warm, soapy water and a soft sponge or cloth. Avoid using rough abrasive cloths, metal balls, or harsh scouring pads, as these can damage the non-stick surface.
- **Dishwasher Safe:** The grill plate is dishwasher safe. Place it on the top rack for best results.
- **Rubber Bumpers:** The rubber bumpers can be cleaned with warm, soapy water. Ensure they are dry before reattaching.




Food Grade Safety



Heat Resistant



Low Oil and Calories



Air Circulation &
360 Heating



Handle Design



Stainless steel
non-stick coating

Image: The grill plate being cleaned manually under running water and placed inside a dishwasher, demonstrating cleaning methods.



BEST QUALITY

Before



Must Have Replacement grill pan helps save money, protect air fryer, and extend the lifespan

After



Image: A comparison of a dirty air fryer basket before cleaning and a clean basket with the replacement grill pan, illustrating the benefits of maintenance.

TROUBLESHOOTING

This section addresses common concerns regarding your air fryer accessories.

Grill Plate Does Not Fit

- **Check Compatibility:** Ensure your air fryer is a Gourmia GAF798 or GAF716 7QT model. This grill plate is specifically designed for these models.
- **Measure:** Verify the inner dimensions of your air fryer basket. The grill plate measures 8.97" x 8.97".

Non-Stick Coating Deterioration

- **Avoid Abrasives:** Do not use metal utensils, abrasive sponges, or harsh cleaning agents, as these can scratch and damage the non-stick coating.
- **Temperature:** Always allow the plate to cool before cleaning. Sudden temperature changes can affect the coating.

Rubber Bumpers Fall Off

- **Secure Fit:** Ensure the rubber bumpers are fully inserted into their slots. They should fit snugly.
- **Replacement:** If bumpers become loose or damaged over time, replacements may be available from the manufacturer.

SPECIFICATIONS

- **Material:** Food-grade steel with non-stick enameled coating
- **Dimensions:** 8.97 inches x 8.97 inches (Grill Plate)
- **Compatibility:** Gourmia GAF798 7QT Air Fryer, Gourmia GAF716 7QT Air Fryer
- **Features:** Non-stick, heat resistant, dishwasher safe, handle for easy removal, whirlwind airflow design
- **Package Weight:** Approximately 6.4 ounces

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For details regarding warranty coverage, returns, or technical support, please contact the manufacturer, GWY, directly or refer to the product listing on the retailer's website.

Manufacturer: Goodtechnical

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

