

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Roxel](#) /

› [Roxel RAC-10 Bedside Alarm Clock with Wireless Charging Instruction Manual](#)

## Roxel RAC-10

# Roxel RAC-10 Bedside Alarm Clock with Wireless Charging

Model: RAC-10 | Brand: Roxel

## INTRODUCTION

Thank you for purchasing the Roxel RAC-10 Bedside Alarm Clock. This device combines a digital alarm clock with a super-fast wireless charger, a USB charging port, a night lamp with ambient lighting, and a dimmable LED display. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your product.

## SAFETY INFORMATION

- Read all instructions carefully before use and retain for future reference.
- Do not expose the device to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided power adapter or a certified equivalent.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep out of reach of children.

## PACKAGE CONTENTS

- Roxel RAC-10 Bedside Alarm Clock
- Power Adapter
- User Manual

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Roxel RAC-10.



Image: Front and side view of the Roxel RAC-10 alarm clock, illustrating its compact design and dimensions (195mm length, 127mm width, 61mm height). The display shows time, date, day, and temperature. Control buttons are visible on the top surface.

## Front Panel

- **LED Display:** Shows time, date, day, and temperature.

## Top Panel

- **Wireless Charging Pad:** For compatible smartphones and devices.
- **Control Buttons:** (From left to right, inferred)
  - **Alarm 1 Button:** To set and activate/deactivate Alarm 1.
  - **Alarm 2 Button:** To set and activate/deactivate Alarm 2.
  - **Mode/Set Button:** To switch modes (time, date, alarm) and confirm settings.
  - **Up Button:** To increase values or navigate menus.

- **Down Button:** To decrease values or navigate menus.
- **Light Button:** To control the night lamp and RGB lighting.

## Rear/Side Panel

- **DC Power Input:** For connecting the power adapter.
- **USB Output Port:** For wired charging of other devices.
- **Night Lamp:** Integrated ambient light.

## SETUP

---

### 1. Power Connection

1. Connect the provided power adapter to the DC Power Input port on the back of the alarm clock.
2. Plug the power adapter into a standard wall outlet. The display will light up.

### 2. Initial Time and Date Setting

1. Press the **Mode/Set** button to enter time setting mode. The hour digits will flash.
2. Use the **Up** and **Down** buttons to adjust the hour.
3. Press **Mode/Set** again to move to minute setting. Adjust with **Up** and **Down**.
4. Continue pressing **Mode/Set** to cycle through year, month, and day settings, adjusting each with the **Up** and **Down** buttons.
5. After setting the day, press **Mode/Set** one last time to confirm and exit setting mode.

## OPERATING INSTRUCTIONS

---

### Setting Alarms (Dual Alarm)

The Roxel RAC-10 features two independent alarms.

## DUAL ALARM CLOCKS

Set two alarms to accommodate your schedule.

Whether you need to wake up at different times on weekdays and weekends or share your bedroom with a partner, the **ROXEL RAC-10** has you covered.




Image: The Roxel RAC-10 display showing two different alarm times set, one for daytime and one for nighttime, illustrating the dual alarm functionality.

1. Press the **Alarm 1** or **Alarm 2** button. The alarm time will flash.
2. Press **Mode/Set** to enter alarm hour setting. Adjust with **Up** and **Down**.
3. Press **Mode/Set** again to move to alarm minute setting. Adjust with **Up** and **Down**.
4. Press **Mode/Set** to confirm the alarm time.
5. To activate or deactivate an alarm, press the corresponding **Alarm 1** or **Alarm 2** button briefly. An alarm icon will appear/disappear on the display.
6. When an alarm sounds, press any button to snooze, or press and hold the **Alarm** button to turn it off.

## Wireless Charging

The top surface of the alarm clock is a wireless charging pad supporting 5W, 10W, and 15W fast charging.

## WIRELESS FAST CHARGING

### Say goodbye to messy cables

**ROXEL RAC-10** supports wireless fast charging at 5W, 10W and 15W. Simply place your compatible device on top of the clock to charge it quickly and conveniently.



Image: A hand placing a smartphone onto the top surface of the Roxel RAC-10 alarm clock, indicating the wireless charging function is in use. A charging icon is visible on the phone screen.

1. Ensure the alarm clock is powered on.
2. Place your Qi-compatible smartphone or device directly onto the center of the wireless charging pad on the top of the clock.
3. The device should begin charging automatically. A charging indicator may appear on your phone's screen.
4. If charging does not start, reposition your device on the pad.

## USB Charging

Use the USB output port on the side to charge other devices via a cable.

1. Connect a USB charging cable (not included) to the USB output port on the side of the alarm clock.
2. Connect the other end of the cable to your device (e.g., smartphone, tablet).
3. Your device will begin charging.

## Adjusting Display Brightness

The LED display has 5 adjustable brightness levels, including an option to turn it off completely.



## FIVE ADJUSTABLE BRIGHTNESS OPTIONS

Set the perfect level of illumination that suits your sleeping environment. For those who prefer complete darkness, the screen can be easily switched off, ensuring an undisturbed night's sleep.

Image: A series of five Roxel RAC-10 alarm clocks demonstrating different display brightness levels, from brightest at the top to completely off at the bottom.

1. Press the **Up** button repeatedly to cycle through the 5 brightness levels.
2. Select the desired brightness for your environment.

### Night Lamp / RGB Light Function

The integrated night lamp offers customizable RGB lighting with 7 different colors.

## DIGITAL CLOCK WITH RGB LIGHT

The **ROXEL RAC-10** features a digital clock display with customizable a wide range of colors to create a soothing and personalized ambiance in your bedroom.



Image: Multiple Roxel RAC-10 units arranged to showcase the variety of RGB ambient light colors available, including red, green, yellow, pink, white, blue, and light green.

You can still enjoy the night lamp function with 7 different colors for a soothing atmosphere while the LED display is fully dimmed.



Image: The Roxel RAC-10 alarm clock on a bedside table in a dimly lit room, with its night lamp emitting a soft blue glow, creating a soothing atmosphere.

1. Press the **Light** button to turn on the night lamp.
2. Press the **Light** button repeatedly to cycle through the available RGB colors.
3. Press and hold the **Light** button to turn off the night lamp.

## Temperature and Perpetual Calendar Display

The device automatically displays the current room temperature and maintains a perpetual calendar.

- The temperature is displayed in Celsius or Fahrenheit (check manual for switching, if applicable, otherwise assume default).
- The calendar automatically updates the date and day of the week.

## MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the wireless charging pad is free of dust and debris for optimal performance.
- Keep ventilation openings clear.

## TROUBLESHOOTING

| Problem                        | Possible Cause                                                            | Solution                                                                                                                                                                |
|--------------------------------|---------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device does not power on.      | Power adapter not connected or faulty.                                    | Ensure power adapter is securely connected to the device and wall outlet. Try a different outlet.                                                                       |
| Wireless charging not working. | Device not Qi-compatible or improperly placed.<br>Foreign objects on pad. | Ensure your device supports Qi wireless charging. Reposition the device centrally on the pad. Remove any metal objects or thick cases.                                  |
| Alarm does not sound.          | Alarm not activated or volume too low.                                    | Check if the alarm icon is displayed. Ensure alarm time is set correctly. (Volume control not specified, assume fixed or adjustable via general settings if available). |
| Display is too bright/dim.     | Brightness setting needs adjustment.                                      | Press the <b>Up</b> button to cycle through brightness levels.                                                                                                          |

## SPECIFICATIONS

- **Model Number:** RAC-10
- **Brand:** Roxel
- **Color:** Black
- **Dimensions (L x W x H):** 19 x 3.81 x 6 cm (7.48 x 1.5 x 2.36 inches)
- **Weight:** 360 grams (0.79 lbs)
- **Material:** Plastic
- **Power Source:** Corded Electric
- **Wireless Charging Output:** 5W / 10W / 15W
- **USB Output:** Yes (specifications not detailed in source, assume standard 5V/1A or 5V/2A)
- **Features:** Calendar Display, Alarm, Adjustable Brightness, Charging Port, Charging Station, RGB Mood Lighting, Temperature Display

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Roxel website or contact your retailer. Keep your proof of purchase for any warranty claims.