

[Manuals.plus](#) /

› [Elegant Designs](#) /

› Elegant Designs LT1026-ABS 8-Inch Elipse Crystal Table Lamp User Manual

Elegant Designs LT1026-ABS

Elegant Designs LT1026-ABS 8-Inch Elipse Crystal Table Lamp User Manual

Model: LT1026-ABS

INTRODUCTION

Thank you for choosing the Elegant Designs LT1026-ABS Elipse Crystal Table Lamp. This manual provides essential information for the safe and proper setup, operation, and maintenance of your new lamp. Please read these instructions thoroughly before use and retain them for future reference.



Image: The Elegant Designs LT1026-ABS Elipse Crystal Table Lamp in Antique Brass finish, showcasing its spherical design adorned with numerous clear crystals, resting on a wooden surface.

SAFETY INFORMATION

- Always unplug the lamp from the electrical outlet before cleaning, changing the light bulb, or performing any maintenance.
- Do not use with a damaged cord or plug. If the cord or plug is damaged, contact a qualified electrician for repair or replacement.
- Do not use the lamp in wet locations or near water.
- Ensure the light bulb wattage does not exceed the maximum specified (40 watts).
- Keep the lamp away from flammable materials.
- This lamp is designed for indoor use only.

SETUP

1. Unpacking

- Carefully remove all components from the packaging.
- Inspect the lamp for any signs of damage. If damage is found, do not proceed with assembly or use.
- Retain packaging materials for future transport or returns.

2. Bulb Installation

The light bulb is not included with your purchase. This lamp requires 1 x 40 watt equivalent Type B10 candelabra base bulb (E12 base).

1. Ensure the lamp is unplugged from the power outlet.
2. Locate the bulb socket inside the crystal sphere.
3. Carefully screw the E12 base bulb into the socket until it is snug. Do not overtighten.



Image: A close-up view of the lamp's E12 candelabra base bulb socket, showing where the bulb should be inserted.

3. Placement

- Place the lamp on a stable, flat surface.
- Ensure the 6-foot plug-in cord is routed safely and does not pose a tripping hazard.
- Avoid placing the lamp in direct sunlight or near heat sources.

OPERATING INSTRUCTIONS

Turning the Lamp On/Off

This table lamp features an easily accessible rotary (gear) switch located on the power cord for quick and easy operation.

1. Plug the lamp's power cord into a standard 120V AC electrical outlet.
2. Locate the rotary switch on the cord.
3. Rotate the switch clockwise to turn the lamp ON.
4. Rotate the switch counter-clockwise to turn the lamp OFF.



Image: A close-up view of the in-line rotary switch on the lamp's power cord, used for turning the light on and off.

General Product Overview (Video)

For a general overview of Elegant Designs products and their aesthetic, you may watch the following video. Please note this video provides brand information and not specific operational instructions for this model.

Video: An overview of Elegant Designs, highlighting various lighting products and their design philosophy. This video is provided by the seller.

MAINTENANCE

Cleaning

- Always unplug the lamp before cleaning.
- Use a soft, dry cloth to gently wipe the metal frame and crystal accents.
- Avoid using abrasive cleaners, solvents, or polishes as they may damage the finish or crystals.



Image: A detailed close-up of the lamp's crystal elements, showing their faceted surfaces and how they are set within the metal frame.

Bulb Replacement

- Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it.
- Unscrew the old bulb counter-clockwise.
- Screw in a new E12 base, 40-watt equivalent Type B10 candelabra bulb clockwise until snug.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet.	Check the wall switch or circuit breaker. Test the outlet with another device.
Lamp does not turn on.	Bulb is loose or burned out.	Unplug the lamp, then tighten or replace the bulb.
Lamp flickers.	Loose bulb or faulty connection.	Unplug the lamp, tighten the bulb. If flickering persists, replace the bulb.

SPECIFICATIONS

- Model Number:** LT1026-ABS
- Product Dimensions:** 7.75"D x 7.75"W x 8"H
- Item Weight:** 2.21 Pounds
- Material Type:** Crystal, Metal, Plastic
- Finish Type:** Metal (Antique Brass)
- Bulb Base:** E12 (Candelabra)
- Max Wattage:** 40 watts
- Switch Type:** In Line Rotary Switch
- Power Source:** Corded Electric
- Voltage:** 120 Volts
- Indoor/Outdoor Usage:** Indoor

7.75"

8"



Image: The Elegant Designs LT1026-ABS lamp shown with its key dimensions, 7.75 inches in diameter and 8 inches in height.

WARRANTY

This product comes with a 1-year limited warranty against manufacturer defects. For warranty claims or further details, please contact the manufacturer or retailer where the product was purchased.

SUPPORT

For additional support, questions, or to report issues, please refer to the contact information provided by your retailer or visit the official Elegant Designs website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question