CyberpowerPC GMA2700A

CYBERPOWERPC Gamer Master Gaming PC User Manual

Model: GMA2700A

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your CYBERPOWERPC Gamer Master Gaming PC. The Gamer Master series is designed for high-performance gaming and multitasking, featuring AMD Ryzen CPUs and NVIDIA GeForce graphics cards. Please read this manual thoroughly before using your new system.

2. Setup Guide

2.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present: Desktop PC, Keyboard, Mouse, and Power Cord. Inspect the PC for any visible damage that may have occurred during shipping. If any damage is found, contact customer support immediately.



Image: The CYBERPOWERPC Gamer Master Gaming PC, including the desktop tower, keyboard, and mouse.

2.2 Connecting Peripherals

- **Power:** Connect the power cord to the PC's power supply unit and then to a wall outlet.
- **Monitor:** Connect your monitor(s) to the graphics card's display outputs (HDMI or DisplayPort).
- **Keyboard & Mouse:** Connect the included keyboard and mouse to any available USB ports on the PC.
- **Network:** For wired internet, connect an Ethernet cable to the RJ-45 port. For wireless, ensure Wi-Fi antennas are connected if applicable.
- **Audio:** Connect speakers or headphones to the audio jacks.



Image: A detailed view of the top input/output (I/O) panel, showing USB 3.0 ports, audio jacks, and power/reset buttons.

2.3 First Boot and Windows Setup

Press the power button on the front of the PC. The system comes with Genuine Windows 11 Home 64-bit pre-installed. Follow the on-screen prompts to complete the initial Windows setup, including region, language, and network configuration.

3. Operating Your PC

3.1 System Overview

Your CYBERPOWERPC Gamer Master features an AMD Ryzen 5 7600 3.8GHz 6-core CPU, 16GB DDR5 RAM, a 500GB PCIe Gen4 NVMe SSD, and an NVIDIA GeForce RTX 4060 8GB Video Card. This configuration provides robust performance for gaming and demanding applications.



Image: An internal view of the PC, highlighting the motherboard, CPU cooler with RGB lighting, graphics card, and RAM modules.

3.2 RGB Lighting Control

The PC features custom RGB case lighting and tempered glass side panels to showcase the internal components. Lighting effects can typically be controlled via pre-installed software (e.g., ASUS Aura Sync if an ASUS motherboard is detected) or a dedicated button on the case. Refer to the specific software or case manual for detailed instructions on customizing RGB effects.

3.3 Connectivity

The system offers extensive connectivity options:

- **USB Ports:** 6 x USB 3.1, 2 x USB 2.0
- **Video Outputs:** 1x HDMI, 2x DisplayPort
- **Network:** 1x RJ-45 Network Ethernet 10/100/1000, 802.11AC Wi-Fi
- **Audio:** 7.1 Channel audio support

4. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your PC.

4.1 Cleaning

Regularly clean the exterior of the PC with a soft, dry cloth. Use compressed air to clear dust from fans, vents, and internal components. Ensure the PC is powered off and unplugged before cleaning. Avoid using liquid cleaners directly on components.

4.2 Software Updates

Keep your operating system (Windows 11) and graphics drivers updated to the latest versions. This ensures system stability, security, and optimal performance for games and applications. Windows updates can be managed through the Settings app, and graphics drivers can be updated via NVIDIA's official website or GeForce Experience software.

5. Troubleshooting Common Issues

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
PC does not power on	Loose power cable, power supply switch off, faulty outlet.	Check all power connections, ensure PSU switch is ON, try a different outlet.
No display on monitor	Monitor cable loose, incorrect input selected on monitor, graphics card not seated properly.	Ensure monitor cable is securely connected to PC and monitor, select correct input, reseat graphics card (if comfortable).
Excessive fan noise	Dust buildup, high system load, fan malfunction.	Clean fans and vents, close unnecessary applications, monitor temperatures.
Keyboard/Mouse not responding	Loose USB connection, driver issue.	Try a different USB port, restart PC, check device manager for driver issues.

6. Technical Specifications

Component	Specification
Processor	AMD Ryzen 5 7600 3.8GHz (6 Cores / 12 Threads)
Chipset	AMD A620
RAM	16GB DDR5
Storage	500GB PCIe Gen4 NVMe SSD
Graphics Card	NVIDIA GeForce RTX 4060 8GB
Operating System	Windows 11 Home 64-bit
USB Ports	6 x USB 3.1, 2 x USB 2.0
Video Outputs	1x HDMI, 2x DisplayPort
Network	1x RJ-45 (10/100/1000), 802.11AC Wi-Fi
Audio	7.1 Channel

Component	Specification
Dimensions (LxWxH)	18.5 x 8.2 x 18.7 inches
Weight	35.1 pounds

7. Warranty and Support

Your CYBERPOWERPC Gamer Master Gaming PC comes with a **1 Year Parts & Labor Warranty** and **Free Lifetime Technical Support**. For any technical issues, warranty claims, or further assistance, please refer to the contact information provided with your product documentation or visit the official CyberpowerPC support website.

Online Support: www.cyberpowerpc.com/support

© 2023 CyberpowerPC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question