

Liudefa 8018-8

Liudefa 8-Light Modern Wood Recessed LED Ceiling Light Instruction Manual

Model: 8018-8 | Brand: Liudefa

1. INTRODUCTION

Thank you for purchasing the Liudefa 8-Light Modern Wood Recessed LED Ceiling Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

2. SAFETY INFORMATION

- **WARNING:** To avoid electric shock, always turn off the power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Ensure the mounting surface is structurally sound and can support the weight of the fixture.
- Do not exceed the recommended wattage for bulbs. This fixture uses E26 bulbs.
- Handle the fixture with care to prevent damage.
- Keep packaging materials away from children.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before installation. If any parts are missing or broken, contact customer service.

- Liudefa 8-Light Ceiling Light Fixture (Model 8018-8)
- Mounting Hardware
- Instruction Manual

Note: E26 bulbs are not included and must be purchased separately.

4. SPECIFICATIONS

Feature	Specification
Brand	Liudefa
Model Name	8018-8Black
Color	Black
Material	Metal, Wood
Style	Modern
Light Fixture Form	Ceiling
Product Dimensions	32"L x 32"W x 12"H (82cm x 82cm x 30cm)
Installation Type	Semi Flush Mount
Light Source Type	LED (Bulbs not included)
Bulb Base	E26
Number of Light Sources	8
Voltage	110 Volts
Wattage	Max 60 watts per bulb
Brightness	Up to 2000 Lumens (depending on bulbs)
Control Method	App, Push Button (requires compatible smart bulbs/switches for app control)
Special Feature	Waterproof (for indoor durability, not outdoor exposure)

Product Dimensions:



Image: Diagram illustrating the dimensions of the 8-light ceiling fixture.

5. SETUP AND INSTALLATION

Professional installation is recommended for this electrical fixture. Ensure you have all necessary tools (screwdriver, wire strippers, electrical tape, etc.) before starting.

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's location and turn it OFF. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Ensure the junction box is securely mounted to the ceiling and can support the fixture's weight.
3. **Attach Mounting Bracket:** Secure the fixture's mounting bracket to the junction box using the provided screws.
4. **Wire Connections:** Carefully connect the electrical wires. Match the live (black) wire from the fixture to the live (black) wire from the ceiling, the neutral (white) wire from the fixture to the neutral (white) wire from the ceiling, and the ground wire to the ground wire. Secure connections with wire nuts and electrical tape.
5. **Mount Fixture:** Carefully lift the fixture and attach it to the mounting bracket, securing it with the provided screws or nuts.
6. **Install Bulbs:** Screw E26 base bulbs (not included) into each of the 8 sockets. Do not overtighten.
7. **Restore Power:** Turn the power back ON at the circuit breaker.

Visual Guide for Installation:



Image: The Liudefa 8-Light Modern Wood Recessed LED Ceiling Light installed.

6. OPERATING INSTRUCTIONS

Once installed and powered, your Liudefa ceiling light can be operated via a standard wall switch. For advanced control options, such as app control, you will need to use compatible smart E26 bulbs and/or a smart switch system that supports app integration.

- **Standard Operation:** Use your existing wall switch to turn the light fixture ON or OFF.
- **App Control (with compatible bulbs/switches):** If using smart E26 bulbs or a smart switch, follow the instructions provided with those devices to pair them with their respective apps for remote control, scheduling, and other smart features.

Product in Use:



Material: iron+rubber wood


Applicable area :10-25m² space:Bedroom, living room

Image: The ceiling light fixture illuminating a living room.



Image: The ceiling light fixture in a bedroom.

black 8 heads



Material	size	light source	space	application
wood+ steel	h30cm*82cm	E26*8	15-28m²	bedroom Living room

Image: The ceiling light fixture providing bright illumination.

Life comes from creation



Natural wood



Carefully selected



Exquisite craftsmanship

Non-polluting, environmentally friendly paint, good decorative performance, smooth and delicate



Environmental protection
paint



Artificial paint



Beautiful and
translucent

Image: The ceiling light fixture showcasing its design.

Product Video Demonstration:

Your browser does not support the video tag.

Video: A demonstration of the 8-Light Wooden Recessed LED Ceiling Light in operation, showcasing its design and illumination.

7. MAINTENANCE

- **Cleaning:** Always turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Ensure the power is off and the bulbs have cooled before attempting to replace them. Unscrew the old E26 bulb and screw in a new one of the same type and wattage (max 60W).
- **Inspection:** Periodically check the fixture for any loose wiring or damage. If any issues are found, turn off the power and consult a qualified electrician.

Material Quality:



Image: Details of the solid wood and metal construction.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wire connection Faulty bulb	Check circuit breaker/fuse Verify all wire connections are secure (power off) Replace bulb(s)
Flickering light	Loose bulb Incompatible dimmer switch Faulty wiring	Tighten bulb Ensure bulbs are dimmable if using a dimmer; replace dimmer if necessary Consult a qualified electrician
Buzzing sound	Loose components Incompatible dimmer switch	Check for loose parts and tighten Ensure bulbs are dimmable if using a dimmer; replace dimmer if necessary

If you experience issues not listed above or if the problem persists after attempting the solutions, please contact customer support.

9. WARRANTY AND SUPPORT

This Liudefa product comes with a Limited Warranty. Please refer to your purchase documentation or contact customer service for specific warranty terms and conditions.

For technical assistance, replacement parts, or any questions regarding your product, please contact Liudefa customer support through the retailer where the product was purchased or visit the official Liudefa store online.

Liudefa Store: [Visit the Liudefa Store on Amazon](#)

