

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave Bullet Capacitive Stylus Instruction Manual

BoxWave Bullet Capacitive Stylus

BoxWave Bullet Capacitive Stylus Instruction Manual

Brand: BoxWave | **Model:** Bullet Capacitive Stylus

1. PRODUCT OVERVIEW

The BoxWave Bullet Capacitive Stylus is designed for precise and comfortable interaction with touchscreen devices, including the Wiseasy P5 EMV POS. This upgraded model features an extendable design for enhanced usability and includes a convenient keyring loop for portability. It offers a smooth glide on touchscreens, providing an alternative to finger-based interaction, particularly useful in environments requiring reduced direct contact.



Figure 1.1: The BoxWave Bullet Capacitive Stylus shown alongside a Wiseasy P5 EMV POS device, illustrating its intended use.

2. KEY FEATURES

- **New Upgraded Model:** The stylus is now extendable, allowing for comfortable use at 3 inches for precision tasks, while maintaining a compact 2-inch length for portability.
- **Smooth Glide:** Equipped with a rubber tip that ensures a smooth and responsive interaction with touchscreen surfaces, improving sensitivity and control.

- **Enhanced Hygiene:** Provides a method to interact with touchscreens without direct finger contact, suitable for environments like hospitals or for obtaining signatures.
- **Ultra Portable:** At only 2 inches (5cm) in length, it includes a keychain attachment for easy carrying on key rings.
- **High Quality Construction:** Manufactured from durable silicone and aluminum materials, ensuring a long-lasting tip and a robust body.





Figure 2.1: A close-up view of the stylus, highlighting its compact design and integrated keyring loop for easy attachment.



Figure 2.2: The stylus shown in its extended position, demonstrating the increased length for more comfortable and precise use.

3. SETUP

1. **Unpacking:** Remove the Bullet Capacitive Stylus from its packaging.
2. **Attaching Keyring (Optional):** If desired, attach the included keychain loop to your existing key ring for convenient portability.
3. **Extending the Stylus:** To extend the stylus for more comfortable use, gently pull the two sections apart until they lock into the extended position. To retract, push the sections back together.



Figure 3.1: The stylus attached to a set of car keys, demonstrating its portability when connected to a keyring.

4. OPERATING INSTRUCTIONS

The Bullet Capacitive Stylus is designed for intuitive use on any capacitive touchscreen device.

- **Basic Interaction:** Hold the stylus comfortably and gently tap or swipe the rubber tip across your device's touchscreen, just as you would with your finger.
- **Precision Tasks:** For drawing, writing, or selecting small icons, extend the stylus to its 3-inch length for improved grip and control.
- **Maintaining Hygiene:** Utilize the stylus to interact with public touchscreens (e.g., POS terminals, kiosks) to minimize direct skin contact.



Figure 4.1: A user interacting with a tablet using the Bullet Capacitive Stylus, demonstrating its application for touchscreen navigation.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Bullet Capacitive Stylus, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the rubber tip and aluminum body with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the stylus in a clean, dry place when not in use. The keyring attachment allows for secure storage with your keys or other items.
- **Avoid Damage:** Do not apply excessive force to the tip or bend the stylus, as this may damage its functionality.

6. TROUBLESHOOTING

If you experience issues with your Bullet Capacitive Stylus, consider the following:

- **Unresponsive Touch:** Ensure your device's screen is clean and free of smudges or debris. A dirty screen can interfere with stylus responsiveness.
- **Inconsistent Performance:** Check the stylus tip for any visible damage or wear. While durable, prolonged heavy use can affect performance.
- **General Device Issues:** If the stylus is unresponsive, test it on another capacitive touchscreen device to determine if the issue lies with the stylus or your primary device.

For further assistance, please refer to the contact information provided by BoxWave Corporation.

7. SPECIFICATIONS

Attribute	Detail
Item Weight	0.7 ounces
ASIN	B0CBMJT3CH
Date First Available	June 14, 2023
Manufacturer	BoxWave
Material	Silicone (tip), Aluminum (body)
Length (Retracted)	2 inches (5 cm)
Length (Extended)	3 inches

8. IMPORTANT NOTES

Please be aware of the following:

- The Wiseasy P5 EMV POS device is **NOT INCLUDED** with the purchase of this stylus. It is shown for compatibility demonstration purposes only.
- Purchase includes limited third-party technical support for Wiseasy P5 EMV POS (up to 3 inquiries via electronic messaging). This support is provided by BoxWave and is not affiliated with or endorsed by Wiseasy.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CBMJT3CH>

More documents and user manuals: <https://manuals.plus/>