

Dreo PolyFan 513S

Dreo PolyFan 513S Pedestal and Table Fan User Manual

Model: PolyFan 513S (Pedestal Fan), Dreo Air Circulator Fan (Table Fan)

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and save these instructions before using the appliance. When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Ensure the power supply matches the voltage specified on the fan's rating label.
- Do not operate any fan with a damaged cord or plug. Discard the fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect the fan, turn controls to OFF, then remove plug from outlet.
- Do not insert fingers or foreign objects into any opening of the fan.
- Do not use outdoors.
- Always place the fan on a stable, flat surface during operation.
- Do not use the fan in wet or damp locations such as bathrooms.
- Close supervision is necessary when any appliance is used by or near children.

2. PRODUCT OVERVIEW

This package includes two high-performance fans: the Dreo PolyFan 513S Pedestal Fan and a Dreo Air Circulator Table Fan. Both are designed to provide efficient air circulation for your home.

2.1 Pedestal Fan Components





Image 2.1: The Dreo PolyFan 513S Pedestal Fan, showcasing its sleek design, accompanying remote control, and a smartphone screen displaying the fan's app interface for smart control.

- Fan Head with Grille and Blades
- Adjustable Stand/Pole
- Base
- Control Panel (on stand)
- Remote Control
- Power Cord

2.2 Table Fan Components

DREO | Air Circulator Series

America's Home & Garden Best Brands of 2022*



CNET



*Based on Newsweek's 2022 America's Best Brands ranking.

Image 2.2: The Dreo Air Circulator Table Fan, featuring its compact design, powerful airflow indicated by blue arrows, and the included remote control. The image also highlights its 90-degree adjustable tilt capability.

- Fan Head with Grille and Blades
- Base with Control Buttons
- Remote Control
- Power Cord

2.3 Key Features

- **Powerful Airflow:** Pedestal fan provides up to 100 ft airflow, table fan up to 70 ft.
- **Quiet Operation:** Pedestal fan operates as low as 25dB for undisturbed use.
- **Omni-directional Oscillation (Pedestal Fan):** 120° horizontal and 105° vertical rotation for wide air distribution.
- **Adjustable Tilt (Table Fan):** 120° adjustable tilt for targeted airflow.
- **Remote Control:** Convenient adjustment of speeds, modes, and timers.
- **Smart Control:** Wi-Fi and Voice Control compatibility (Alexa/Google) for the pedestal fan.
- **Multiple Modes & Speeds:** 6 modes and 8 speeds for the pedestal fan, 4 speeds for the table fan.
- **Timer Function:** Up to 12-hour timer for the pedestal fan, 8-hour timer for the table fan.
- **Easy Cleaning:** Removable grilles and blades for simple maintenance.

3. SETUP

3.1 Pedestal Fan Assembly

1. **Attach Base:** Securely attach the base to the bottom of the fan stand using the provided screws.
2. **Connect Stand to Fan Head:** Carefully align and connect the fan head assembly to the top of the stand. Ensure it clicks into place or is secured with any provided fasteners.
3. **Power Connection:** Plug the power cord into a standard electrical outlet.

Immersive comfort all around.

Powered by
Turbosilent™ X

100 ft*
Max distance

882 CFM
Massive air volume

100ft




Image 3.1: A full view of the Dreo PolyFan 513S Pedestal Fan, illustrating its assembled form with the remote control and a smartphone displaying the control app. This image helps visualize the complete product after assembly.

3.2 Table Fan Setup

1. **Placement:** Place the table fan on a stable, flat surface.
2. **Power Connection:** Plug the power cord into a standard electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Control Panel (Pedestal Fan)

The control panel is located on the fan stand. It typically includes buttons for Power, Speed, Mode, Oscillation, and Timer.

- **Power Button:** Turns the fan ON/OFF.
- **Speed Button:** Adjusts fan speed (8 levels).
- **Mode Button:** Cycles through available modes (e.g., Normal, Natural, Sleep, Auto).
- **Oscillation Button:** Activates/deactivates horizontal and vertical oscillation.
- **Timer Button:** Sets the auto-off timer (up to 12 hours).

4.2 Remote Control

Both fans come with a remote control for convenient operation. Ensure the remote has working batteries (typically AAA, not included).

- **Power ():** Turns the fan ON/OFF.
- **Speed (+/-):** Increases/decreases fan speed.
- **Mode (M):** Changes operating mode.
- **Oscillation ():** Activates/deactivates oscillation.
- **Timer ():** Sets the auto-off timer.

4.3 Wi-Fi and Voice Control (Pedestal Fan Only)

The Dreo PolyFan 513S Pedestal Fan supports Wi-Fi connectivity for control via the Dreo app and voice commands through Alexa or Google Assistant.

1. **Download App:** Download the "Dreo" app from your smartphone's app store.
2. **Pair Device:** Follow the in-app instructions to pair your pedestal fan with your Wi-Fi network.
3. **Voice Assistant Integration:** Link your Dreo account with Alexa or Google Assistant through their respective apps to enable voice control.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your fans.

1. **Disconnect Power:** Always unplug the fan from the power outlet before cleaning.
2. **Clean Exterior:** Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
3. **Clean Grilles and Blades:**
 - The fan grilles and blades are designed for easy cleaning. Refer to the specific model's instructions for grille removal.
 - Use a vacuum cleaner with a brush attachment or a soft cloth to remove dust from the grilles and blades.
 - Ensure all parts are completely dry before reassembling and plugging in the fan.

5.2 Storage

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Power cord not securely plugged in.	Ensure the fan is plugged into a working electrical outlet. Check if the outlet is functional.
Weak airflow.	Fan speed is too low; Grilles or blades are dirty.	Increase the fan speed. Clean the fan grilles and blades as per maintenance instructions.
Fan makes unusual noise.	Foreign object inside; Fan not on a stable surface.	Unplug the fan and check for any obstructions. Ensure the fan is placed on a flat, stable surface.
Remote control not working.	Batteries are dead or incorrectly inserted; Remote is too far or obstructed.	Replace batteries with new ones, ensuring correct polarity. Reduce distance to fan and remove obstructions.
Wi-Fi/Voice control not responding (Pedestal Fan).	Fan not connected to Wi-Fi; App not configured correctly; Voice assistant not linked.	Check Wi-Fi connection in the Dreo app. Re-pair the device if necessary. Ensure Dreo account is linked to Alexa/Google Assistant.

7. SPECIFICATIONS

Feature	Dreo PolyFan 513S Pedestal Fan	Dreo Air Circulator Table Fan
Brand	Dreo	Dreo
Model	PolyFan 513S	Dreo Air Circulator Fan
Control Method	Remote, Voice, App	Remote, Manual Buttons
Oscillation	120° Horizontal, 105° Vertical	120° Adjustable Tilt
Max Airflow Distance	100 ft	70 ft
Noise Level	As low as 25dB	Not specified (generally quiet)
Speeds	8	4
Modes	6	Not specified (typically fewer than pedestal)
Timer	12 Hours	8 Hours
Indoor/Outdoor Usage	Indoor	Indoor

8. WARRANTY AND SUPPORT

Dreo products come with a manufacturer's warranty. For detailed warranty information, product registration, or technical support, please visit the official Dreo website or contact their customer service.

Website: www.dreo.com

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question