

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster Campaign Gaming Bundle, Black, 2MNGA0161B0L2 User Manual](#)

Monster 2MNGA0161B0L2

Monster Campaign Gaming Bundle User Manual

Model: 2MNGA0161B0L2

Brand: Monster

PRODUCT OVERVIEW

The Monster Campaign Gaming Bundle (Model: 2MNGA0161B0L2) is a comprehensive set designed to enhance your gaming experience. This bundle includes a gaming keyboard, a gaming mouse, a gaming headset, and a mouse pad, all engineered for performance and durability. It is compatible with personal computers running Windows operating systems.



Figure 1: The complete Monster Campaign Gaming Bundle, showcasing the keyboard, mouse, headset, and mouse pad.



Figure 2: Close-up view of the Monster Campaign Gaming Keyboard, featuring multi-color backlighting and dedicated multimedia keys.



Figure 3: The Monster Campaign Gaming Headset, equipped with an adjustable microphone for clear communication.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- Monster Campaign Gaming Keyboard
- Monster Campaign Gaming Mouse
- Monster Campaign Gaming Headset
- Monster Gaming Mouse Pad

SETUP

Connecting the Keyboard

1. Locate an available USB port on your computer.
2. Insert the USB connector of the keyboard firmly into the USB port.
3. The operating system will automatically detect and install the necessary drivers. Allow a few moments for this process to complete.

Connecting the Mouse

1. Locate another available USB port on your computer.
2. Insert the USB connector of the mouse firmly into the USB port.
3. The operating system will automatically detect and install the necessary drivers.

Connecting the Headset

1. Identify the audio (green) and microphone (pink) jacks on your computer.
2. Plug the headset's green audio jack into the computer's green audio output port.
3. Plug the headset's pink microphone jack into the computer's pink microphone input port.
4. Adjust audio settings in your operating system's sound control panel if necessary to select the headset as the default playback and recording device.

Mouse Pad Placement

Place the mouse pad on a flat, stable surface next to your keyboard. Ensure sufficient space for comfortable mouse movement during use.

OPERATING INSTRUCTIONS

Keyboard Functions

- **Standard Typing:** Use the keyboard as a standard input device for typing text and executing commands.
- **Multimedia Keys:** Utilize the dedicated multimedia keys located at the top of the keyboard for quick access to functions such as volume control, play/pause, and track navigation.
- **Backlighting Control:** The keyboard features multi-color backlighting. Press the **Fn** key in combination with specific function keys (e.g., **Fn + Scroll Lock** or **Fn + Home**) to cycle through lighting modes, adjust brightness, or turn the backlighting on/off. Refer to the keyboard's keycap markings for specific combinations.

Mouse Functions

- **Left/Right Click:** Perform standard left and right mouse button functions.
- **Scroll Wheel:** Scroll through documents and web pages. The scroll wheel also functions as a middle click button.
- **DPI Adjustment:** The mouse includes a dedicated DPI button (often located behind the scroll wheel) to cycle through different sensitivity settings (DPI - Dots Per Inch), allowing you to adjust cursor speed on the fly.
- **Side Buttons:** Utilize the side buttons for quick actions, often pre-programmed for forward/back navigation in web browsers or customizable for in-game commands.

Headset Usage

- **Audio Output:** The headset provides clear stereo audio for an immersive gaming and media experience.
- **Microphone:** The adjustable microphone allows for clear voice communication. Position the microphone approximately 1-2 inches from your mouth for optimal clarity.
- **Volume Control:** Use the inline volume control located on the headset cable to adjust the audio output level.

MAINTENANCE

- **Cleaning:** Regularly clean the surfaces of the keyboard, mouse, and headset with a soft, dry, lint-free cloth. For light dirt, a slightly damp cloth can be used, ensuring no moisture enters the internal components. Avoid harsh chemicals or abrasive materials.
- **Cable Management:** Avoid sharp bends, kinks, or excessive pulling on the cables to prevent internal wire damage. Use cable ties if necessary to keep cables organized.
- **Storage:** When not in use, store the gaming bundle in a cool, dry environment, away from direct sunlight, extreme temperatures, and excessive dust.

TROUBLESHOOTING

Keyboard/Mouse Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into a functional USB port on your computer. Try unplugging and re-plugging the device.
- **Try Different USB Port:** Connect the device to a different USB port on your computer to rule out a faulty port.
- **Restart Computer:** A system restart can often resolve connectivity issues.
- **Check Device Manager (Windows):** Open Device Manager (search for it in Windows Start menu) and check for any yellow exclamation marks next to the keyboard or mouse entries, indicating a driver issue. You may need to update or reinstall drivers.

No Sound from Headset / Microphone Not Working

- **Verify Jack Connections:** Ensure the green audio jack is in the audio output port and the pink microphone jack is in the microphone input port on your computer.
- **Check Inline Volume Control:** Confirm that the volume dial on the headset cable is not set to minimum or muted.
- **Operating System Sound Settings:** Go to your computer's sound settings (e.g., Sound Control Panel in Windows) and ensure the headset is selected as the default playback and recording device. Check volume levels for both output and input.
- **Test on Another Device:** If possible, test the headset on another computer or device to determine if the issue is with the headset or your computer's audio ports.

Keyboard Backlighting Not Working

- **Ensure Proper Connection:** Verify the keyboard's USB cable is fully connected.
- **Cycle Lighting Modes:** Press the designated backlighting control key combination (e.g., **Fn + Scroll Lock**) to ensure the lighting is not simply turned off or set to a very dim mode.

SPECIFICATIONS

| Feature | Detail |
|-------------------------|--------------------------------|
| Brand | Monster |
| Model | 2MNGA0161B0L2 |
| Connectivity Technology | USB |
| Compatible Devices | Personal Computer |
| Operating System | Windows |
| Product Dimensions | 17.5 x 6.88 x 0.98 inches |
| Item Weight | 2.4 ounces |
| Manufacturer | LIFEWORKS TECHNOLOGY GROUP LLC |
| Date First Available | July 11, 2023 |

WARRANTY AND SUPPORT

For detailed warranty information, terms, and conditions, please refer to the warranty card or documentation included with your Monster Campaign Gaming Bundle purchase. Keep your proof of purchase for warranty claims.

For technical support, troubleshooting assistance beyond this manual, or product inquiries, please contact the manufacturer, LIFEWORKS TECHNOLOGY GROUP LLC, or visit the official Monster brand website for customer service contact details.

Online resources and FAQs may also be available on the manufacturer's support pages.