

## Hot Wheels Mega-Wrex HTP14

# Hot Wheels Monster Trucks Mega-Wrex RC Truck Instruction Manual

## INTRODUCTION

This instruction manual provides essential information for the safe and effective operation of your Hot Wheels Monster Trucks Mega-Wrex 1:24 Scale Remote Control (RC) Truck. Please read this manual thoroughly before use and retain it for future reference. This RC truck is designed for exciting monster truck action, featuring all-terrain tires and the ability to perform wheelie stunts.

## IMPORTANT SAFETY INFORMATION

- **Adult Supervision:** Always ensure adult supervision during operation, especially for younger users.
- **Battery Safety:** Use only the specified batteries. Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove batteries if the toy will not be used for an extended period.
- **Operating Environment:** Operate the RC truck in open areas, away from people, pets, and obstacles. Avoid operating near water or in wet conditions to prevent damage to electronic components.
- **Avoid Obstructions:** Do not drive the truck into furniture, walls, or other hard surfaces, as this may cause damage to the toy or property.
- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.

## PACKAGE CONTENTS

- 1 Hot Wheels Monster Trucks 1:24 Scale Mega-Wrex RC vehicle
- 1 Remote Control Unit

*Note: Batteries for the remote control are not included and must be purchased separately.*

## SETUP

## 1. Battery Installation (Remote Control)

1. Locate the battery compartment on the back of the remote control.
2. Using a screwdriver (not included), open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

## 2. Powering On and Pairing

1. Ensure the RC truck is fully charged or has fresh batteries installed (if applicable, refer to product packaging for truck battery type).
2. Turn on the RC truck using the power switch, usually located on the underside or side of the vehicle.
3. Turn on the remote control. The remote and truck should automatically pair. A successful connection is often indicated by a solid light on both devices.
4. If pairing fails, turn both devices off and on again, ensuring they are close to each other.



Image: The Hot Wheels Mega-Wrex RC Monster Truck and its remote control, ready for setup.

## OPERATING INSTRUCTIONS

### Basic Controls

- **Forward/Reverse:** Use the left joystick on the remote control to move the truck forward or backward.
- **Steering:** Use the right joystick to steer the truck left or right.

### Performing Wheelie Stunts

The Mega-Wrex RC truck is designed to perform impressive wheelie stunts. To initiate a wheelie, accelerate forward

rapidly and then quickly pull back on the left joystick. Practice may be required to master this maneuver.



Image: The Mega-Wrex RC truck navigating an outdoor sandy terrain, showcasing its all-terrain capabilities.



***PERFORM WHEELIE STUNTS  
ON THE REAR WHEELS!***

Image: Close-up of the remote control unit, highlighting the joysticks and Hot Wheels Monster Trucks branding.



Image: The Mega-Wrex RC truck balanced on its rear wheels, demonstrating a wheelie stunt, with the remote control visible in the foreground.

## Product Overview Video

Video: An official product overview demonstrating the features and operation of the Hot Wheels Monster Trucks Mega-Wrex RC Truck.

## MAINTENANCE

- **Cleaning:** Wipe the truck and remote control with a damp cloth to remove dirt and dust. Do not submerge in water.
- **Storage:** Store the RC truck and remote control in a cool, dry place away from direct sunlight when not in use. Remove batteries from the remote control during long periods of storage.
- **Tire Care:** Regularly inspect the all-terrain tires for debris or damage. Clean as necessary to maintain optimal performance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Truck does not respond to remote.	Low batteries in remote or truck; not paired; out of range.	Replace batteries; re-pair devices; move closer to the truck.
Reduced performance or speed.	Low truck battery; dirty tires; operating on unsuitable terrain.	Charge truck battery; clean tires; move to a smoother surface.
Interference with other RC vehicles.	Multiple 2.4 GHz devices in close proximity.	Move to an area with less interference or operate one vehicle at a time.

## SPECIFICATIONS

- **Product Dimensions:** 5.1 x 16 x 6.5 inches
- **Item Weight:** 1.07 pounds
- **Item Model Number:** HTP14
- **Manufacturer Recommended Age:** 4 years and up
- **Batteries:** 2 AAA batteries required (for remote control, not included)
- **Frequency:** 2.4 GHz
- **Max Speed:** Approximately 5 mph
- **Range:** Approximately 100 feet
- **Manufacturer:** Mattel, Inc.
- **Release Date:** February 17, 2024

## WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Hot Wheels website. Keep your purchase receipt as proof of purchase.

You can also visit the [Hot Wheels Store on Amazon](#) for additional product information and support resources.