

RUN-CHICKEN Eternal

RUN-CHICKEN Eternal Solar Automatic Chicken Coop Door User Manual

Model: Eternal

1. INTRODUCTION

The RUN-CHICKEN Eternal is an automatic chicken coop door designed to provide convenience and security for your flock. It features integrated solar power, a battery backup system, and smart control options via a mobile application. This manual provides instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance of your device.



Image Description: A wide shot of a wooden chicken coop with the RUN-CHICKEN Eternal door installed. Two chickens are visible in the foreground, emphasizing the product's purpose. The image highlights the natural, outdoor setting where the door operates.

2. PRODUCT FEATURES

- **Automatic Operation:** Opens and closes automatically based on light sensor, timer, or GPS location.
- **Integrated Solar Power:** Built-in solar panel recharges the internal battery.
- **Battery Backup:** Rechargeable batteries provide power for up to 5 years, ensuring operation even on cloudy days.

- **Smart App Control:** Manage settings and schedules via the RUN-CHICKEN mobile application.
- **Weatherproof Design:** Constructed from durable aluminum, resistant to rust and extreme temperatures (-15°F to 140°F).
- **Predator-Proof:** Reinforced aluminum frame and secure lock protect against predators.
- **Anti-Pinch Safety:** Intelligent sensor stops door closure if an obstruction is detected.

PRODUCT FEATURES



Image Description: A graphic illustrating the main features of the RUN-CHICKEN Eternal door. Icons represent remote smart control, solar power, 5+ year battery life, GPS-based timer, custom timer, and the use of Duracell rechargeable batteries. The door itself is shown in the center.



WATER-PROOF

Fully waterproof housing protects all electronics from rain, splashes, and hose-downs.

Image Description: A close-up view of the RUN-CHICKEN Eternal door with water visibly dripping on its surface, illustrating its waterproof construction. This image highlights the product's durability against environmental elements.

3. INSTALLATION

3.1 Package Contents

- Automatic Chicken Coop Door with Built-in Solar Panel
- Rechargeable Batteries (2 AA, pre-installed)
- Mounting Screws (6 pieces)
- User Manual (this document)

3.2 Mounting Instructions

1. Select a suitable location on your chicken coop for the door. Ensure the area is flat and clear of obstructions.
2. Position the door against the coop wall and mark the six screw holes.
3. Use a drill to create pilot holes if necessary.
4. Secure the door to the coop using the provided mounting screws. Ensure it is firmly attached and level.
5. Verify that the door can move freely up and down without obstruction.



EASY MOUNTING

Mount it in minutes with 6 included screws — no expertise required.

Image Description: A person is shown using a power drill to attach the RUN-CHICKEN Eternal door to the side of a wooden chicken coop. This image demonstrates the ease of mounting the device with the

included screws.

3.3 Battery Installation/Check

The Eternal door comes with 2 AA rechargeable batteries pre-installed and pre-charged. These batteries are continuously recharged by the integrated solar panel. No external panel is needed. The batteries are designed to last for 5+ years under regular use.



Image Description: A close-up shot of a hand inserting a Duracell rechargeable battery into the battery compartment of the RUN-CHICKEN Eternal door. This illustrates the battery component and its role in powering the device.

4. OPERATION

4.1 Downloading the RUN-CHICKEN App

To utilize the smart features of your Eternal door, download the RUN-CHICKEN app on your smartphone.

- For Android devices: [Google Play Store](#)
- For iOS devices: [Apple App Store](#)

PROGRAMMING



Image Description: A graphic detailing the programming process for the RUN-CHICKEN door. It shows steps like downloading the app, pairing the device, customizing settings, and programming the door. QR codes for Google Play and Apple App Store are included for easy app access.

4.2 Pairing Your Device

1. Open the RUN-CHICKEN app on your smartphone.
2. Follow the in-app instructions to add and pair your Eternal door. This typically involves a quick sign-in and Bluetooth connection.

4.3 Setting Operating Modes

The Eternal door offers several operating modes:

- **Sunrise/Sunset Mode:** The door automatically opens at sunrise and closes at sunset, adjusting to natural light conditions. This can be based on a built-in light sensor or GPS location.
- **Timer Control:** Set specific opening and closing times for the door via the app.
- **GPS-Based Timer:** The app uses your location to calculate precise sunrise and sunset times for automated operation.
- **Manual Control:** Open or close the door manually through the app or by pressing a button on the device (if available).




Image Description: A person is shown relaxing in a chair outdoors, using a smartphone to control the RUN-CHICKEN Eternal door. This image emphasizes the convenience of remote app control, allowing for hands-off management of the coop door.

4.4 Anti-Pinch Safety Feature

The door is equipped with an intelligent safety sensor. If a chicken or other obstruction is detected during closing, the door will pause its movement to prevent injury. Once the obstruction is clear, the door will resume closing.



Image Description: A chicken is shown with its head and part of its body inside the opening of the RUN-CHICKEN Eternal door, demonstrating the anti-pinch safety mechanism. This image highlights the product's design to protect poultry during operation.

5. MAINTENANCE

5.1 Cleaning

The RUN-CHICKEN Eternal door is designed for easy care. Clean the door and solar panel periodically with mild soap and water to ensure optimal performance and battery charging efficiency. Avoid abrasive cleaners or harsh chemicals.



EASY CARE

Effortless cleaning with mild soap and water.

Image Description: A person is shown cleaning the RUN-CHICKEN Eternal door, which is installed on a wooden coop, using a spray bottle and a cloth. This image emphasizes the simplicity of maintaining the device.

5.2 Battery Life

The integrated rechargeable batteries are designed to last for over 5 years. Regular exposure to sunlight will keep them charged. In prolonged periods of low light, the stored energy will ensure continued operation.

6. TROUBLESHOOTING

6.1 Door Not Opening/Closing

- **Check Battery Level:** Ensure the batteries are sufficiently charged. Although solar-powered, prolonged periods of darkness or obstruction of the solar panel can affect charge.
- **Obstructions:** Inspect the door's path for any physical obstructions that might be preventing movement.
- **App Settings:** Verify that the operating mode (timer, sunrise/sunset) and schedule are correctly configured in the RUN-CHICKEN app.
- **Light Sensor:** If using sunrise/sunset mode, ensure the light sensor is clean and not obstructed. External lights near the coop can interfere with its function.

6.2 App Connectivity Issues

- **Bluetooth Range:** Ensure your smartphone is within 30 feet of the Eternal door for stable Bluetooth connection.
- **App Updates:** Check for and install any available updates for the RUN-CHICKEN app.
- **Restart Device/App:** Try restarting your smartphone and the RUN-CHICKEN app.

7. SPECIFICATIONS

Feature	Detail
Item Weight	2.29 pounds
Item Model Number	Eternal

Feature	Detail
Batteries	2 AA rechargeable batteries (included)
Operating Temperature	-15°F to 140°F (-26°C to 60°C)
Item Dimensions (LxWxH)	9.4 x 1.3 x 13.8 inches
Material	Aluminum
Special Feature	Automatic Operation, Easy Installation, Predator Proof, Solar Powered, Weatherproof
Included Components	Automatic Chicken Coop Door with Built-in Solar Panel, Rechargeable Batteries, Mounting Screws, User Manual

DIMENSIONS




Image Description: A detailed diagram illustrating the dimensions of the RUN-CHICKEN Eternal door. Measurements for overall height, width, and the door opening are provided. A silhouette of a chicken with 'UP TO 10LBS' indicates the maximum recommended weight for poultry using the door.

8. WARRANTY AND SUPPORT

8.1 Warranty Information


The RUN-CHICKEN Eternal door comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance under normal use conditions.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact RUN-CHICKEN customer service. Our team is dedicated to providing responsive support to ensure your satisfaction and the long-term protection of your flock.

Contact information can typically be found on the RUN-CHICKEN official website or through your purchase platform.

Related Documents - Eternal

	Run-Chicken Automatic Coop Door T50 Instruction Manual Comprehensive instruction manual for the Run-Chicken Automatic Coop Door T50, covering installation, battery replacement, operation, and troubleshooting. Learn how to set opening and closing times, understand indicator lights, and perform factory resets.
	RUN-CHICKEN Automatic Coop Door Universal Guide: Installation, Operation, and Maintenance Comprehensive guide for the RUN-CHICKEN Automatic Coop Door, covering installation, operation, safety, battery replacement, and product features for T50, Eternal, and Giant models. Learn how to set timers, troubleshoot, and maintain your coop door.
	RUN-CHICKEN Door Model T50 Instruction Manual This manual provides step-by-step instructions for mounting and operating the RUN-CHICKEN Door Model T50, including technical specifications, safety guidelines, and troubleshooting tips.
	RUN-CHICKEN Automatische Hühnerklappe T50: Installation und Bedienungsanleitung Umfassende Anleitung für die RUN-CHICKEN Automatische Hühnerklappe T50, die Installation, Bedienung, Wartung und Sicherheitshinweise abdeckt. Erfahren Sie, wie Sie Ihre automatische Geflügeltür einrichten und verwenden.
	Eternal Faucets Installation Guide: Comprehensive Instructions Detailed installation guide for Eternal faucets, including Basin Mixers, Sink Mixers, Wall Spouts, and Shower Mixers. Covers water supply requirements, main body installation, water connections, seal testing, and care instructions.
	Run-Chicken Automatic Coop Door T50 Instruction Manual Comprehensive instruction manual for the Run-Chicken Automatic Coop Door T50, covering installation, battery replacement, operation, and troubleshooting. Learn how to set opening and closing times, understand indicator lights, and perform factory resets.



[RUN-CHICKEN Automatic Coop Door Universal Guide: Installation, Operation, and Maintenance](#)

Comprehensive guide for the RUN-CHICKEN Automatic Coop Door, covering installation, operation, safety, battery replacement, and product features for T50, Eternal, and Giant models. Learn how to set timers, troubleshoot, and maintain your coop door.

lang:en score:41 filesize: 3.3 M page_count: 11 document date: 2024-05-15




[\[pdf\] User Manual Specifications Guide Warranty](#)

Universal Guide run chicken BATTERIES T50 Giant Use two four AA LR06 size alkaline batteries with a rated supply voltage of DC 1.5V to power the door We recommend buying from brands such as Duracell but any high quality UniversalGuide 2024 06 |||

ENG Universal Guide RUN-CHICKEN Thank you for purchasing our easy-to-use RUN-CHICKEN Door. With y ... UTTONFUNCTIONS. Main material: Aluminum Waterproof: IP56 Ingress Protection Grade Door size: T50/**Eternal**: 9.4 x 1.6 x 13.8 L x W x H Giant: 15,7 1,8 x 23,6 L x W x H Item weight: T50/Ete...

lang:en score:29 filesize: 3.3 M page_count: 11 document date: 2024-05-15

RUN CHICKEN Feeder F80 ManualThe battery powered Run Chicken Automatic Coop Door T50 saves
 you time and protects your chickens from the dangers of wild It is designed to make your v1run chicken
 2024 09 Manual srsltid AfmBOooRbC2QwgAvopuiDNzTPiJBWPxR Hxmlau0Y WOAK4aPNLEUFy
 ManualRUN your The your v1v1run WOAK4aPNLEUFyrun AfmBOoqb7IAfcHtXNCB3ylwiolKZTUqXO
 tg4jJGevDqVYry8cuaG7Zo ManualUntitledThe your v1v1v1run tg4jJGevDqVYry8cuaG7Zorun
 AfmBOopiYiC9E8uUzD Te5hHzkKn8Hxuxlyy2OgLS GP 0wmFd7RHeVV ManualUntitledUntitledThe
 your v1v1v1v1run 0wmFd7RHeVVrun AfmBOorLTaipnj2G veI Vc dSviBixQnKrvpHN6Wk o0aya0KtpdSK4
 ManualUntitledUntitledUntitledThe your v1v1v1v1v1run o0aya0KtpdSK4run AfmBOor1A8cxiiyqY
 Y8d25IATwSAI4jM8osmVe1yuzqljWuI Q52SE8u ManualUntitledUntitledUntitledUntitledThe
 your v1v1v1v1v1v1run Q52SE8urun AfmBOobRkKjEUIJd88ICcqYQHh4QuchHpKTK6py9InMJW75YP
 2BhWW ManualUntitledUntitledUntitledUntitledUntitledThe your v1v1v1v1v1v1RUN Manualrun
 2BhWWrun AfmBOorVPjTktBgN72jpbTSz6dCFPBladwPE4C8aARwKkMKb87 CQgGP
 ManualUntitledUntitledUntitledUntitledUntitledUntitledUntitledThe CQgGPrun



lang:en score:24 filesize: 2.22 M page count: 9 document date: 2024-09-05

Instruction manual 15 hours ago — TOOLS REQUIRED FOR MOUNTING Cross screwdriver PH2 Run
Chicken Feeder F80 is set to the DEFAULT FACTORY MODE mode unless configured RUN CHICKEN
Manual srsItid AfmBOOpCLeEJhENGXo2 q8LTQQeUJIEZ4FQqHKFijOvWCGuFqxJ6i6 z run chicken 2024
09 Sep 23 BEST PRACTICE USAGE Automatic comes preassembled batteries included Pull out plastic
strip before use Place prieš 5 dienas For more information watch instruction video IN APP A smart
durable and pest proof feeding solution with a 11 lbs kg capacity giorni fa days Apple App Store Follow
instructions in app CONFIGURATIONS UP The indicator light OPERATION differently by user This works
fantastically for 95% of With your help we can make new quality eco friendly products chickens Read
follow Our are unified their swift installation design robust 4 from Google Play or il y jours 1 day advanced
configuration device example if current time zone 8 m protective lid will open at next all mornings after
that HOW TO SET When almost empty RED BLINKING LIGHT start blink In this case you need replace
them High alkaline 2xAA Leveler warnings handling safety advice Page 3 Unscrew 2 screws attached
IMPORTANT Save these future reference INSTALLER Leave Quick assembly maintenance life easier
while premium aluminum shines GREEN when jour giorno 16 AfmBOOrX0VXTKikNwaYjUzR0V8u
CQpfQg9glB2LK Al8VWrCpVAKcy AfmBOooH4FNBInvi3d8K9VqutjE74XEmEzInU AqGuJcL
BS7CUz06hp AfmBOoqAP D1Bp9zdysnPZYBXqkYA3dFNOGnRqX6 Q4EoXsTUUgfhf45
AfmBOooEYhVGiQK1xZvIdQLQ4M5KSa5NTtRP7nFWBjox94i0o bt2x2d
AfmBOoqUAqArmmqL1o7Ht7WY3Nx1vHr4g2aBnpvzIYYjzL3fmYJ5vFH



AfmBOoqmSxLP4TXn6GpqIVvbMhg61SHT4Xy0vITMQ 51noA aCXutW
AfmBOor8pRiZ7rUliTKUEfdEi79x avJXOoWW0qCJID6XYIFv 5JXYRU
AfmBOoo9rHCdFos3knrPlsodAjwCGJeSel95egVF9soBc8m3IDx5dhVI AfmBOoqZs72Wktcr pA
y3XDH2u02oNHxSgWskNLNwSpONraVCKXfqcC AfmBOopr3f3FRvQUusJFSfrOST8AI3SK
BEckOmBVIovyqJB9KMgdhoaU AfmBOoo7LE0p 3HvAl6A2h3SL5tm11HLKcv3r7f1rWHJw N0IOGdBnwp
AfmBOoqhL0QeAX4wuONp5219MOUFI5QP4jYwSAuJiFBzMuwh91SNj7nO
AfmBOopMTNN0aHx4T7NGuX Ty1wH 4UjVBBJTVSis31Rty C3Nn40ffi
AfmBOoqn7WHnifPZX3M2gj4RlrYwlnTmb2aO7FyL2Wj0E7dD9U UAlq5
AfmBOopSgALWpzNHIUoJ9DhVD9dYO KhO1GrcFRvLjmuR xn4OhWfvVJ
AfmBOooaXvwTndlyxYt33y5pFQmxH 8VM09m6hsv ly9pVQF8WrNWov6 AfmBOorwjGU1DFwQlsqd
kQmgAwpn7ENrd0qHbDXnugYUM6eKzGB2c87 AfmBOooY0Uu1QXgIFFgwHbY nYvCtdFj0BTLuRDFVD
DXNz3V GslPQ5 AfmBOopOFHdbAHnKRRfCtwCX1tJN9gNZUY czGpzPIVU1IKPdXumER3V
AfmBOophBXsPduCSyHee9geRmGrb8AfUDZGb0JPRi3JkYq6F52nVVP AfmBOor 9TyFoFFM
GtfOWzE4p14ac9WnPh wU5PyEEryJAfXiHegff
AfmBOorPCQnAkFil7BsR2tFWgKDj23GhY72pWzL7cdKZCUaNsfxNI7J
AfmBOoq0HI7UeBhhIYbeOdsHPi5m9YRXuFuQwvD08pam0Twx025nXtM
AfmBOop5EHIdiEtexhPkrCrEkeWdQfjY W3 ZeXn7fg8dUZEja dxs2P
AfmBOooHe8nq3k8F0A2LXS792Zig5SaeTD2IOjchrMFcwHCy6P72p64m AfmBOoobnmP3QpraK10
DyJgc0dUyh Nzci7fHFTS9eXZQIDZU6IjGW AfmBOoqaAXr96Netlg0sE d
AbZdW6ABtQAm5GONG0vQSdG57DlhYW7 AfmBOooz
RDpcOwww0Z0b5qeofQFO2sO4nVM9Tz4dsGWnEil 4dayxQiR
AfmBOoozy6ckG5P9eI9RC7IzOwdgU76SRc29ocISAeSOduA3irg1DScA
AfmBOorrqSOEqE5pN8YU8rIMuIncpqQsu9JiE8H9ZXwa84LLn75PdcSW AfmBOorkaUcPzakR
dIW1CGbFGC0rtq A2ZLeRwtRci9rns7nzmslgjM AfmBOorkwQ0IV
OaQ7GMH7fu1ENah3tdNscjBKBG99DPLfCRMBPKh3mH AfmBOooZSfNBK
YkCaCgQFNkgiPNDIRBsZlg c6rsuL2hyd2 6FlxXh AfmBOooJ JcnWd292
85Y4hGQdiuQ7Qe0VQbu99qMsNou2 85Ww NJ
AfmBOoo2NkuB7SIXD2E1TPfG9b2AFSmtUg4xFmXck5OxfTYaojpUZ3kD AfmBOoriHEZy5cScZQ4YmT
z26wrq9rJ9COLsvk0wlrV4gBCzv7rJ0Ra AfmBOoph CaTpoLeObjW
tyM8uuSsH4SCHmG63R5ubGkLEil5CaDChY2
AfmBOooZ4f4haTgOqdqucmqo33HApAekTuEqSaHzCtw2kjtYdbU3 HXJ AfmBOopWROQ
Z5MkA9cB6Y0a66I4KqAcVDLmW ZeVcrasGE8H5 HI91Z
AfmBOorJeNAP0kCA7O9EfKuUGamPbsaBiRtxUryhZp1Bu5h59sRMAAdOs AfmBOoo5PRI
5MDIFc9i8nWaRACfPBidLcfYn8bQdPGRggztd1OvGcU AfmBOop1
F7oKN1dJ0kCdly7QHS7mbO2LBRsqrUHWuouWdWazGPNNqwf AfmBOoqBXadR gRxBNY30t Sc
KzfBQOfb1SqkZJ7kS9doKgo9A9I4Hc AfmBOoo BVbth6qCKuJ9xfj6Z
TpyizampjSbcdpy6osSMT0K4VSfuZP AfmBOorr4xsZWzKPVMjpUSSN3Huu5a3NukSEJ
3762T32My6E5fhVJyz AfmBOooNDyP cwKzBRj87wIAWSj cY 3iKa1hg3jw0iRBsTbI9xwL24K
AfmBOorXgysY5EmXDEet3RSv6qltuRne2F07R493wAcJaQaju mMmf9
AfmBOoqoQgLfaUkEoeESFiOLi5PR6O5gRfkDX87v0LL4PIC8 0 3GNiA AfmBOoovExVP
vAifAzJkVZEN7Y8tam3KQDAjJM0GJIEUQeu7jsjPUOs eu
AfmBOorCpb1jvXHeIUXETJNvPqnQ2izMXmoKe1ldQhA8nhEN9cjeD o9
AfmBOorbD8omXUXy6sgaNTTDJJCzb1YZ0Dq2WWPJQgiVLPAPMZtN7mJ
AfmBOoq745WMxvRCLibJOZtt0sgaj0YK okQUinNDuovj041NVmZV
AfmBOoqE2N2jCagrCpvDdZItTLM52ceCtxpLptfmK7jgs2Vi2Y7oymiH
AfmBOoqaL4G8aX7liFNk3AVISjyIO HIZwTCL7JQ1ytzHecvKpHVSTwU sept WARRANTY AND
SUPPORT warranty valid year be claimed online registering feeder US You manually close later than 20
minutes AfmBOorzvzy2CHo6cKEuJnfocR xwuF ZGFTV6riQFkwNWAflQpp3DF
AfmBOopANp694YtuKRJLESti2ZgX2ZonAxFDLWcTSK52UYxXBz 9iHwq
AfmBOopPxHW1Ats2IUXBVE01kgtrsILV4v7IMTr72eOH7TdvzEghEuyY AfmBOopq4v5ezR vh
bb7zb2VCFBrTB sLgNENjZn2oVKgcGmO3r9cH
AfmBOoog1Ux49jwuW56xCituOLnrZpwloeKuwsjDr91bGYYkiYj9yrDT

AfmBOoppFLJjTlmi9ZjbWesl919uQ8l35GVlhJdV5QQWLjruJiYusXXl AfmBOopFLySHDAJiR4Hs
ruTSw0jJC9DT031 gBkQ0BBz5TjxzuO2ziT
AfmBOooO8aO3NCgO78xI2gxS9GAz87EiccqJnvHNk2krOqZJ53WgCoPO AfmBOoq
ZrpqH4eI0qA39etuE4AksKZ69EHOKw43eTHgdjnlGvNX6Bzz
AfmBOorJotf6S6XfFRanJ9gIVIBJPWmC8cMjyjiGjqOzvsGDC WcMz0
AfmBOopKuX0ezOPZ0hsQ00puSrwsAMB1mEiTde2 NrUrnYp8OXW2e3B
AfmBOoobcXVTVSA9TpvBFKTrfy7W FqA3sQdvtbHdTBHous9xMpH3TGB AfmBOop9kTmhl12
8mH23O2 H4KY e0rlc4o1Bp1EcCCZ97mZPQn15kp
AfmBOopB5dSpxlsPYljgQLQWleLdL5uEoCJFit3NqChJmjiBE1eJrkHDR AfmBOoqkQYDiCz
ssXS7lhOLrYzGONIwt09OHyQt2cGAyElzyEbzmGQR
AfmBOoq8KuZFQkd8FBtUvuwfHZiKanR9nQnAjm6QeJhC3tKEwSeFvVUL AfmBOoqi
5233ZvswU6CBvSgQXMbzquU7N3zW BAig1IUAcS4Yau3Mc3 AfmBOoqrBKofJM21 115TRx5a2crFiV
p4cfSSWYOJJTDaPGC2bwaoMD |||

F80 ENG RUN-CHICKEN Thank you for purchasing our Automatic Chicken Feeder
F80. With your help, we ... ays easier and transform chicken raising into a happy,
carefree activity. Automatic Solar Coop Door **Eternal** With integrated solar panel and
rechargeable batteries, door **Eternal** is a hassle-free and ec...

lang:en **score:23** filesize: 2.22 M page_count: 9 document date: 2024-09-05



[RUN-CHICKEN Automatische Hühnerklappe T50: Installation und Bedienungsanleitung](#)

Umfassende Anleitung für die RUN-CHICKEN Automatische Hühnerklappe T50, die Installation, Bedienung, Wartung und Sicherheitshinweise abdeckt. Erfahren Sie, wie Sie Ihre automatische Geflügeltür einrichten und verwenden.

lang:de **score:19** filesize: 1.52 M page_count: 23 document date: 2024-08-14

[\[pdf\] Guide](#)

Hühnerklappe Modell T50 von RUN CHICKENMODE D USINE PAR DÉFAUT Ce mode fonctionne
exceptionnellement bien pour 95 % des utilisateurs En usine la porte s ouvre automatiquement 20
minutes UniversalGuide EUrun chicken 2024 09 UniversalGuide EU srsltid AfmBOorSZN FTrTCcpkGp
t8ER68kwqcMXmt0CPYsmRbt5cSNYGvWkJK CHICKENHühnerklappe CHICKENZA več informacij
preberite sklop DELOVANJE VRAT Glavni material Aluminij Vodoodpornost IP56 Ingress Protection
Grade NAVODILA ZA MONTAŽOMODE minutes run AfmBOop t9mgy0NnULVpzzY
1Z3ll4vIHQZA7LM7R98QsjKwQbQyji trun minutes Über der Oberkante Tür ist ein Freiraum mindestens
30 cm Eternal 55 Giant und links rechts unter mindestens v1run
t8ER68kwqcMXmt0CPYsmRbt5cSNYGvWkJkrun AfmBOopNdHdfiP i4BjP7y46CdK36WZtt
ZEGFlaiaFITYnjA1xT7noE mindestens Prova porta premendo il pulsante 24 25 SU La spia luminosa
diventa VERDE quando si apre GIU La v1v1run ZEGFlaiaFITYnjA1xT7noErun
AfmBOopj8XSQgkf0nidtZhdovOPakP8izN3jru5A1m4QiOQKYALd1jQb La Schließen TASTE drücken
BALDIGES AUF ZU Ein BLAUES BLINKEN zeigt an dass sich die im Vorbereitungsmodus befindet wenn
Sensor des v1v1v1run AfmBOopj8XSQgkf0nidtZhdovOPakP8izN3jru5A1m4QiOQKYALd1jQbRun
AfmBOopVvHGJsJ VhTUR 8lpqulqgBivWTs2hAeFX7Aru90DiMGwdRB6 des Antriebseinheit durch Lösen
4 Schrauben mit einem Kreuzschlitzschraubendreher PH2 abnehmen Klappe nicht funktioniert oder
Batterien leer v1v1v1v1run 8lpqulqgBivWTs2hAeFX7Aru90DiMGwdRB6run AfmBOooesYHMz92J5
I9Hg8vAdtyZPA4DphCq9sIR4IVbdhZH CXlRwi CHICKENDE FR IT SLOZa leer v1v1v1v1v1run CXlRWirun
AfmBOoqHM6XspiZy4SWpvipzOySJW1WbdhWwh XjIRagD55z6U7xIDHP SLODE leer v1v1v1v1v1v1run
AfmBOooFihJmBA1cOhZGp8mRaOlKowF9l9538ESq5jyAbf3bKigSmScarun leer v1v1v1v1v1v1v1run
XjIRagD55z6U7xIDHPrun AfmBOorGdJTdINCRZ9sL GYFe4Z PxOxDpvVSro4bRWm8XVy7nRzFQlp
leer v1v1v1v1v1v1v1v1run PxOxDpvVSro4bRWm8XVy7nRzFQlprun
AfmBOoqfcWbeAJQz2PNIsbMCnVdYvUIHcZ969Met0zQqYUsXy7k1dUPM leer v1v1v1v1v1v1v1v1run
AfmBOoqfcWbeAJQz2PNIsbMCnVdYvUIHcZ969Met0zQqYUsXy7k1dUPMrun
AfmBOooXcWZsLwUjAajKXcdp4x9l6tCiUboCxEEdt40HcocTsy8WorMY



DE - FR - IT - SLO Vielen Dank, dass Sie sich für diese praktische Automatische
Hühnerklappe Modell ... MENT DE LA PORTE. Hauptmaterial: Aluminium
Wasserdicht: IP56 Ingress Protection Grade Tgrre: T50/**Eternal**: 24 cm 3,4 cm 35 cm
L x B x H Giant: 40 cm 3,4 cm x 60 cm L x B x H Artikelgewicht: T...
lang:de **score:19** filesize: 1.52 M page count: 23 document date: 2024-08-14



[\[pdf\]](#) User Manual Specifications Guide Warranty

run chickenBefore mounting the door ensure you have enough space on coop For smooth operation of it is necessary to provide a minimum 12 T50 Eternal B1HbgyLuWSLm media amazon images I B1HbgyLuWSL ref dp product quick view |||
ENG Universal Guide RUN-CHICKEN Thank you for purchasing our easy-to-use RUN-CHICKEN Door. With y ... UTTONFUNCTIONS. Main material: Aluminum Waterproof: IP56 Ingress Protection Grade Door size: T50/**Eternal**: 9.4 x 1.6 x 13.8 L x W x H Gaint: 16,5 1,8 x 25,2 L x W x H Item weight: T50/Ete...
lang:en **score:17** filesize: 3.27 M page_count: 11 document date: 2024-05-13



[\[pdf\]](#)

Eternal ENG pages run chicken 2023 10 |||

...

lang:en **score:16** filesize: 1 M page_count: 0 document date: 0000-00-00