

iLodn MKB1PHei0712-Cutout

iLodn Magnetic Wallet Instruction Manual

Model: MKB1PHei0712-Cutout | Brand: iLodn

INTRODUCTION

This manual provides detailed instructions for the iLodn Magnetic Wallet, a MagSafe-compatible card holder designed for various iPhone models. It offers a slim and secure solution for carrying essential cards, combining convenience with protection.

WHAT'S IN THE BOX

- Magnetic Phone Wallet

SPECIFICATIONS

Feature	Description
Material	Faux Leather
Color	Jet
Card Capacity	Up to 3 cards
Dimensions (D x W x H)	0.5"D x 2.65"W x 3.85"H
Weight	0.04 Kilograms
Closure Type	Magnetic
Additional Features	Magnetic, Card Holder, Metallic Shielding

COMPATIBILITY

The iLodn Magnetic Wallet is compatible with a wide range of iPhone models and MagSafe-compatible cases. This includes:

- iPhone 17 Pro Max, iPhone 17 Pro, iPhone 17 Air, iPhone 17
- iPhone 16 Pro Max, 16 Pro, 16 Plus, 16
- iPhone 15 Pro Max, 15 Pro, 15 Plus, 15
- iPhone 14 Pro Max, 14 Pro, 14 Plus, 14
- iPhone 13 Pro Max, 13 Pro, 13, 13 mini
- iPhone 12 Pro Max, 12 Pro, 12, 12 mini
- MagSafe compatible cases

Compatible with MagSafe Product



iPhone 12 Series and Later





**MagSafe Cases
Magnetic Ring**

Product information

Item details	
Brand Name	iLodn
Age Range Description	Adult-Girl-Teens-For-Women-66+
Model Name	Mk11Ph60712-Cutout
Model Number	MKB1PH60712-Cutout
Manufacturer	iLodn
Customer Reviews	4.4 (2,377) 4.4 out of 5 stars
Best Sellers Rank	14th in Cell Phones & Accessories (Top 100 in Cell Phones & Accessories) 18th in Cell Phone Accessories (Top 100 in Cell Phone Accessories) 18th in Cell Phone Cases (Top 100 in Cell Phone Cases)
ASIN	B0CBQ9M2FJ
Item Type Name	Adult-Girl-Teens-For-Women-66+
Included Components	Magnetic Phone Wallet
Item Height	0.5 inches
Unit Count	3 Count
Manufacturer Warranty Description	Adult-Girl-Teens-For-Women-66+

2026-01-12



Figure 1: Compatibility overview for iLodn Magnetic Wallet, showing various iPhone models and MagSafe cases.

SETUP & INSTALLATION

Attaching the Wallet

Ensure your iPhone or iPhone case is MagSafe compatible. Align the magnetic wallet with the MagSafe ring on the back of your device or case. The wallet will snap securely into place due to its strong magnetic connection.

Strong MagSafe Connection

The magnet is strong when aligned correctly, not afraid of dropping.




Figure 2: Strong MagSafe connection ensures the wallet stays firmly attached.

Video 1: Demonstration of the strong magnetic attachment and slim profile of the iLodn Magnetic Wallet.

OPERATING INSTRUCTIONS

Inserting Cards

The iLodn Magnetic Wallet is designed to hold up to 3 standard-sized cards. Gently slide your cards into the main compartment. The built-in card clip will hold them firmly in place.

Easily to hold 1-3 cards

Say goodbye with your bulky wallet.



Figure 3: The wallet can comfortably hold 1 to 3 cards, maintaining a slim profile.

Removing Cards

To remove cards, utilize the convenient cutout at the bottom of the wallet to push them upwards. Alternatively, if the wallet is detached from your phone, you can push cards from the back opening.

Easy to Take Out

Simply access your card from the top, bottom and the back.



Figure 4: Cards can be easily accessed by pushing from the bottom cutout or the back opening.

Video 2: This video illustrates the ease of accessing cards from the wallet, making it convenient for daily use.

MAINTENANCE

To maintain the quality and appearance of your iLodn Magnetic Wallet, clean it with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the faux leather material.

TROUBLESHOOTING

Wallet not attaching securely

- Ensure your iPhone or case is genuinely MagSafe compatible. Non-MagSafe cases may not provide sufficient magnetic strength.
- Check for any debris, dust, or foreign objects between the wallet and the phone/case that might obstruct the magnetic connection.

Cards falling out

- The wallet is designed to hold up to 3 cards. Overfilling the wallet may compromise the secure fit of the cards.
- Ensure all cards are fully inserted into the compartment. The built-in card clip is designed to hold them firmly.

Cards difficult to remove

- New wallets may be slightly stiff. The faux leather material will soften and become more flexible with regular use.
- Utilize the bottom cutout or the back opening to push cards out, as demonstrated in the operating instructions.

IMPORTANT INFORMATION

Metallic Shielding

The iLoDn Magnetic Wallet incorporates metallic shielding to protect your credit cards and other magnetic stripe cards from demagnetization when attached to your phone.



Metallic shielding provides degauss protection for your cards to prevent demagnetization



Figure 5: Metallic shielding protects cards from demagnetization.

Wireless Charging

For optimal wireless charging performance and to prevent potential interference, it is recommended to remove the magnetic wallet from your iPhone before placing it on a wireless charger.



Figure 6: The slim profile allows for easy removal for wireless charging.

WARRANTY AND SUPPORT

iLodn proudly stands behind its products with a **24-month after-sale service**. If your magnetic wallet experiences any defect or stops functioning within 2 years of purchase, please contact iLodn customer support. We will assist you with troubleshooting or arrange for a replacement product. The manufacturer also provides a **Lifetime Replacement Warranty**.

For support, please refer to the contact information provided with your product packaging or visit the official iLodn website.