SHIMANO SEC5000XGFJC

Shimano Sedona FJ Spinning Reel SEC5000XGFJC Instruction Manual

Your guide to setting up, operating, and maintaining your Shimano Sedona FJ Spinning Reel.

1. Setup

Proper setup ensures optimal performance and longevity of your spinning reel.

1.1 Mounting the Reel

To mount the reel, align the reel foot with the reel seat on your fishing rod. Tighten the reel seat's locking mechanism until the reel is securely fastened. Ensure there is no wobble.



Image: The Shimano Sedona FJ Spinning Reel, shown from a front-side angle, illustrating how it would appear when mounted on a fishing rod. The handle is visible on the left, and the spool is centered.

1.2 Handle Assembly

The handle can be attached to either side of the reel for left or right-hand retrieve. Insert the handle shaft into the designated opening on the reel body and screw the cap on the opposite side to secure it firmly. Ensure the handle rotates smoothly without excessive play.

1.3 Spooling the Line

Attach your fishing line to the spool using an arbor knot. Close the bail and begin winding the line onto the spool, maintaining light tension on the line. Fill the spool to approximately 1/8 inch (3mm) from the rim to prevent line tangles and ensure optimal casting distance. The **Propulsion Line Management System** is designed to assist with smooth line lay and casting.



Image: A side view of the Shimano Sedona FJ Spinning Reel, highlighting the spool and its rim, which is crucial for proper line spooling.

2. Operating Instructions

Understanding the reel's functions will enhance your fishing experience.

2.1 Casting

1. Hold the rod and reel comfortably.
2. Press the line against the rod with your index finger.
3. Open the bail arm.
4. Swing the rod forward, releasing your finger at the desired point to cast the lure or bait.
5. Close the bail arm manually or by turning the handle after the cast.



Image: A top-down view of the Shimano Sedona FJ Spinning Reel, showing the bail arm in an open position, ready for casting.

2.2 Retrieving

Turn the handle to retrieve the line. The **HAGANE Gear** provides durability and smoothness, while **SilentDrive** technology reduces noise and vibration, contributing to a quiet and smooth retrieve. The **G-Free Body** design shifts the reel's center of gravity closer to the rod, improving balance and reducing fatigue during prolonged use.

2.3 Drag Adjustment

The drag system controls the amount of resistance the line experiences when a fish pulls on it. To adjust the drag, turn the knob located on the top of the spool. Turn clockwise to increase tension and counter-clockwise to decrease tension. Set the drag to approximately one-third of your line's breaking strength.

3. Maintenance

Regular maintenance extends the life and performance of your reel.

3.1 Cleaning

- After each use, especially in saltwater, rinse the reel thoroughly with fresh water. Do not submerge the reel.
- Wipe down the exterior with a soft cloth to remove dirt and salt residue.
- Allow the reel to air dry completely before storage.

3.2 Lubrication

Periodically apply a small amount of high-quality reel oil to moving parts such as the handle shaft, bail arm pivots, and line roller. Use reel grease for gears if you disassemble the reel (recommended only for experienced users). Refer to a qualified service technician for internal lubrication.



Image: A detailed side view of the Shimano Sedona FJ Spinning Reel, useful for identifying external lubrication points.

3.3 Storage

Store your reel in a dry, cool place away from direct sunlight and extreme temperatures. Loosen the drag completely before storage to prevent compression of the drag washers.

4. Troubleshooting

Common issues and their potential solutions.

- **Line Twists:** Overfilling the spool, improper line spooling, or using lures that spin excessively can cause line twists. Reduce

the amount of line, re-spool correctly, or use swivels.

- **Stiff Handle:** A stiff handle can indicate a need for lubrication or the presence of dirt/salt buildup. Clean and lubricate the handle shaft. If the issue persists, professional servicing may be required.
- **Drag Slipping/Sticking:** This often points to dirty or worn drag washers. Ensure the drag is not overtightened during storage. For persistent issues, drag washer replacement by a service technician is recommended.
- **Bail Not Closing:** Check for obstructions around the bail arm mechanism. Ensure the bail spring is functioning correctly. If the spring is damaged, professional repair is needed.

5. Specifications

Key technical details for the Shimano Sedona FJ Spinning Reel SEC5000XGFJC.

Feature	Detail
Brand	SHIMANO
Model Name	SEC5000XGFJC
Item Weight	2 Pounds
Gear Ratio	6.2:1 (Size 5000)
Material	Blend
Hand Orientation	Varies by Model (Convertible)
UPC	022255285162
Key Features	HAGANE Gear, SilentDrive, Propulsion Line Management System, G-Free Body

6. Warranty and Support

6.1 Warranty Information

For specific warranty details and claims, please contact the manufacturer directly. The warranty description states: "Contact Manufacturer."

6.2 Customer Support

For further assistance, technical support, or service inquiries, please visit the official Shimano website or contact their customer service department. Keep your purchase receipt and model information handy when contacting support.

© 2023 Shimano. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question