

HyperX 77Z45AA

HyperX Cloud III Wireless Gaming Headset User Manual

Model: 77Z45AA

PRODUCT OVERVIEW

The HyperX Cloud III Wireless headset represents an advancement in gaming audio technology, building upon previous models with enhanced features and design. This wireless headset prioritizes user comfort for extended periods of use, whether for gaming sessions or streaming. It offers significant battery life and incorporates re-tuned audio drivers for optimized sound quality and spatial audio capabilities. The headset provides reliable wireless connectivity and features an improved microphone for clear communication. Integrated controls allow for convenient audio adjustments.

WHAT'S IN THE BOX

- Headphone
- Detachable microphone
- Wireless receiver
- USB-C Cable

SETUP

Connecting Your Headset

The HyperX Cloud III Wireless headset offers versatile connectivity options for various devices:

- **Wireless USB Connection:** Utilize the included wireless receiver for 2.4GHz wireless connectivity with compatible devices such as PC, PS5, PS4, and Nintendo Switch.
- **USB-C Cable:** Connect the headset directly using the provided USB-C cable for a wired connection.
- **USB-A Adapter:** An adapter is included to convert the USB-C connection to USB-A, ensuring compatibility with a wider range of devices.

Ensure the headset is charged before initial use. Connect the wireless receiver to your desired device's USB port. The headset should automatically pair. If using a wired connection, simply plug the USB-C cable into the headset and your

device.



Image: The HyperX Cloud III Wireless headset, showcasing its sleek black design and detachable microphone.

OPERATING INSTRUCTIONS

Power and Battery Life

The HyperX Cloud III Wireless boasts an impressive battery life of up to 120 hours on a single charge, allowing for extended gaming or media consumption without frequent recharging. The headset features a power indicator to inform you of the battery status.

Up to 120 Hours of Battery



2.4GHz Wireless

Image: A user wearing the HyperX Cloud III Wireless headset, highlighting its 120-hour battery life and 2.4GHz wireless connectivity.

Audio Controls

Convenient controls are located directly on the headset earcup for quick access to essential functions:

- **Volume Wheel:** Adjust the audio volume up or down.
- **Mic Mute Button:** Quickly mute or unmute your microphone. An LED indicator on the microphone provides visual confirmation of its mute status.

Audio and Mic Controls



Mic Mute Button

Volume Wheel

Image: Close-up view of the headset's earcup, showing the mic mute button and volume wheel for easy audio and microphone control.

Microphone Usage

The headset features an upgraded 10mm detachable microphone designed for crystal-clear communication. It includes noise-cancelling capabilities and a built-in mesh filter to reduce disruptive background sounds. The LED mic-mute indicator provides a clear visual cue when the microphone is muted.

Ultra-Clear, Noise-Cancelling 10mm Detachable Microphone



 **LED Mic-Mute
Indicator**

Image: Detailed view of the ultra-clear, noise-cancelling 10mm detachable microphone with its LED mic-mute indicator.

Audio Experience

The Cloud III Wireless is equipped with re-tuned 53mm angled drivers, engineered by HyperX audio specialists to deliver an optimized listening experience. It includes a lifetime activation of DTS® Headphone:X® Spatial Audio, providing premium quality audio and precise sound localization for an immersive experience.

Custom Tuned, Angled 53mm Drivers

DTS Headphone:X Spatial Audio

dts
headphone **X**™

Image: A user experiencing the headset's custom-tuned, angled 53mm drivers and DTS Headphone:X Spatial Audio for enhanced sound.

COMFORT AND DURABILITY

Designed for comfort during prolonged use, the Cloud III Wireless features HyperX signature memory foam in both the headband and ear cushions. These are wrapped in soft, premium leatherette, ensuring a plush and comfortable fit. The headset's durable aluminum frame provides resilience against wear and tear, making it suitable for frequent travel and intense gaming sessions.



HyperX Signature Memory Foam

Soft, Premium Leatherette
All Day Comfort

Image: A user wearing the HyperX Cloud III Wireless headset, emphasizing the HyperX Signature Memory Foam and soft, premium leatherette for all-day comfort.

SPECIFICATIONS

Feature	Detail
Brand	HyperX
Model Name	Cloud III Wireless Black
Connectivity Technology	Wireless (2.4GHz)
Headphones Jack	Wireless USB
Battery Life	Up to 120 Hours

Charging Time	4.5 Hours
Audio Driver Size	53 Millimeters
Microphone	10mm Detachable, Noise-Cancelling
Spatial Audio	DTS Headphone:X Spatial Audio
Compatible Devices	Gaming Consoles, Laptops, Desktops (PC, PS5, Nintendo Switch)
Material	Aluminum (Frame)
Item Weight	11.6 Ounces
Product Dimensions	6.1 x 3.41 x 7.48 inches

MAINTENANCE

To ensure the longevity and optimal performance of your HyperX Cloud III Wireless headset, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the earcups and headband. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. When not in use, consider placing it in a protective case to prevent dust accumulation and physical damage.
- **Cable Care:** Handle the USB-C cable and wireless receiver with care. Avoid sharp bends or excessive pulling that could damage the connectors or cable integrity.
- **Microphone Care:** When detaching or reattaching the microphone, do so gently to avoid damaging the port. Keep the microphone clean and free from debris.

TROUBLESHOOTING

If you encounter issues with your HyperX Cloud III Wireless headset, refer to the following common troubleshooting steps:

- **No Audio/Low Volume:**
 - Ensure the headset is powered on and fully charged.
 - Check the volume wheel on the earcup and your device's audio settings.
 - Verify that the wireless receiver is securely plugged into the correct USB port on your device.
 - If using a wired connection, ensure the USB-C cable is properly connected.
 - Confirm that the HyperX Cloud III Wireless is selected as the default audio output device in your system settings.
- **Microphone Not Working:**
 - Check if the microphone is properly attached and not muted (LED indicator should be off).
 - Verify that the HyperX Cloud III Wireless microphone is selected as the default input device in your system's sound settings.
 - Adjust the microphone volume in your device's settings or through the HyperX NGENUITY software (if applicable).
- **Connectivity Issues:**

- Ensure the headset and wireless receiver are within range (up to 20 meters / 65 feet).
- Try plugging the wireless receiver into a different USB port.
- Restart your device and the headset.
- Avoid sources of interference (e.g., other 2.4GHz devices, Wi-Fi routers).

• **Sound Quality Issues (Distortion/Static):**

- Ensure the headset is fully charged.
- Move closer to the wireless receiver to improve signal strength.
- Check for any physical damage to the headset or cables.
- If using HyperX NGENUITY software, try resetting audio settings or adjusting the equalizer.

For more detailed troubleshooting or persistent issues, please refer to the official HyperX support website or contact customer service.

WARRANTY AND SUPPORT

For information regarding the product warranty, including terms, conditions, and duration, please refer to the warranty card included with your purchase or visit the official HyperX website. For technical support, product registration, or to access frequently asked questions and driver downloads, please visit the HyperX support portal.




HyperX Official Website: www.hyperx.com




Customer Support: Refer to the contact information provided on the HyperX website for your region.



© 2023 HyperX. All rights reserved. HyperX is a trademark of HP Inc.

Related Documents - 77Z45AA

	<p>HyperX Cloud Alpha Wireless Gaming Headset User Guide</p> <p>Comprehensive user guide for the HyperX Cloud Alpha Wireless Gaming Headset, detailing setup for PC and PlayStation 5, feature explanations, charging instructions, and software integration.</p>
	<p>HyperX Cloud Flight for PS Wireless Gaming Headset Quick Start Guide</p> <p>Quick start guide for the HyperX Cloud Flight wireless gaming headset for PlayStation consoles. Learn how to set up, charge, and connect your headset.</p>
	<p>HyperX QuadCast S USB Condenser Microphone User Manual and Guide</p> <p>Comprehensive user manual for the HyperX QuadCast S USB microphone and quick start guide for the HyperX Cloud Flight for PS headset. Covers setup, specifications, controls, and usage with PC, Mac, and consoles.</p>

	<p>HyperX Cloud 3 WL Wireless Gaming Headset User Manual</p> <p>Comprehensive user manual for the HyperX Cloud 3 WL wireless gaming headset, covering charging, software setup, PC and PlayStation 5 configuration, and regulatory compliance information.</p>
	<p>HyperX Cloud III Gaming Headset Quick Start Guide</p> <p>A quick start guide for the HyperX Cloud III Gaming Headset, covering overview, setup with PC, mic mute button, volume wheel, and NGENUITY software.</p>
	<p>HyperX Cloud Stinger Core Wireless Gaming Headset Quick Start Guide</p> <p>Quick start guide for the HyperX Cloud Stinger Core Wireless Gaming Headset, covering setup, charging, usage, LED indicators, and troubleshooting for PlayStation and PC.</p>