Panana 1

Panana Modern 6-Drawer Vertical Dresser Instruction Manual

Model: 1

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Panana Modern 6-Drawer Vertical Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Image 1.1: Panana Modern 6-Drawer Vertical Dresser (White) with gold handles.

2. Safety Information

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as needed.
- For stability, it is highly recommended to anchor the dresser to a wall using the provided anti-tip kit. This prevents accidental tip-over, especially in households with children or pets.
- Do not allow children to climb on the dresser or drawers.
- Distribute weight evenly across drawers to maintain balance and prevent tipping.
- Do not overload drawers beyond their capacity.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- 6 Drawer Fronts
- Drawer Side and Back Panels (for 6 drawers)
- Drawer Bottom Panels (for 6 drawers)
- 6 Gold Metal Handles
- Drawer Slides (Left and Right sets for 6 drawers)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Kit (wall anchor strap, screws)
- Instruction Manual

4. Setup and Assembly

Assembly typically requires two people. Tools required (not included): Phillips head screwdriver, hammer.

1. **Prepare Workspace:** Clear a spacious area and lay out all parts on a soft, protective surface to prevent damage.
2. **Assemble the Frame:** Attach the side panels to the bottom panel using the provided dowels and cam locks. Secure the back panel.
3. **Install Drawer Slides:** Attach the dresser slides to the inner sides of the dresser frame, ensuring they are level and correctly oriented.
4. **Assemble Drawers:** For each of the six drawers, attach the side and back panels to the drawer front. Slide the bottom panel into the grooves. Secure the drawer slides to the assembled drawer box.
5. **Attach Handles:** Secure the gold metal handles to the front of each drawer.
6. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser frame.
7. **Attach Top Panel:** Secure the top panel to the assembled frame.
8. **Install Anti-Tip Kit:** Position the dresser in its desired location. Attach the anti-tip strap to the back of the dresser and then to a wall stud using the provided hardware. This step is critical for safety.



Image 4.1: Product dimensions (15.2"D x 20"W x 51.6"H) and individual drawer dimensions.

5. Operating Instructions

- **Opening/Closing Drawers:** Gently pull or push the gold handles to open and close the drawers. Avoid excessive force.
- **Storage:** Utilize the six spacious drawers for organizing clothing, accessories, or other household items. Distribute weight evenly.

6. Maintenance

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** The eco-friendly boards are resistant to water and scratches. Wipe spills immediately to prevent potential damage.

- **Hardware Check:** Periodically inspect all screws and fittings to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.

7. Troubleshooting

Problem	Possible Cause	Solution
Dresser feels wobbly or unstable.	Loose hardware; uneven floor; anti-tip kit not installed.	Check and tighten all screws and cam locks. Ensure the dresser is on a level surface. Install the anti-tip kit securely to a wall stud.
Drawers do not slide smoothly.	Drawer slides misaligned; debris in slides; overloaded drawer.	Remove the drawer and inspect the slides for proper alignment and any obstructions. Ensure the drawer is not overloaded.
Drawer does not close completely.	Obstruction inside the drawer or behind it; misaligned drawer slides.	Check for items blocking the drawer's path. Verify drawer slide alignment.

8. Specifications

Brand: Panana

Model: 1

Material: Wood (Eco-friendly boards)

Color: White

Product Dimensions (D x W x H): 15.2" x 20" x 51.6"

Number of Drawers: 6

Item Weight: 47 pounds

Finish Type: Unfinished (referring to the wood grain texture, not raw wood)

Furniture Finish: Gold (for handles)

Mounting Type: Floor Mount (with wall anchor option)

9. Warranty Information

Specific warranty details for this product may vary. Please refer to your purchase documentation or contact Panana customer support for information regarding warranty coverage and terms.

10. Customer Support

For assistance with assembly, missing parts, or any other inquiries, please contact Panana customer support through the retailer where the product was purchased or visit the official Panana website for contact information.
Online Resources: Panana Brand Store on Amazon

© 2023 Panana. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question