



Manuals.plus /

- › CIRCLE JOY /
- › CIRCLE JOY Electric Wine Opener Set (Model SGS-KD-8) User Manual

CIRCLE JOY SGS-KD-8

CIRCLE JOY Electric Wine Opener Set (Model SGS-KD-8) User Manual

Model: SGS-KD-8

1. INTRODUCTION

Thank you for choosing the CIRCLE JOY Electric Wine Opener Set. This 4-in-1 set is designed to enhance your wine experience with convenience and efficiency. It includes a rechargeable electric wine opener, a rechargeable wine aerator pourer, a foil cutter, and a vacuum wine stopper. This manual provides detailed instructions for the proper setup, operation, maintenance, and troubleshooting of your new wine set.

TRADITIONAL CORKSCREWS



CIRCLE JOY Electric Wine Opener Set

Easy to use

Uncork fastly

Durable

Rechargeable



The complete CIRCLE JOY Electric Wine Opener Set, featuring the electric opener, aerator pourer, foil cutter, and vacuum wine stopper.

Your browser does not support the video tag.

Official product video demonstrating the CIRCLE JOY Electric Wine Opener Set, including the electric opener, aerator, and vacuum stopper in use.

2. PACKAGE CONTENTS

Please ensure all items are present in your package:

- 1 x Electric Wine Opener
- 1 x Rechargeable Wine Aerator Pourer
- 1 x Foil Cutter
- 1 x Vacuum Wine Stopper
- 1 x USB Charging Cable
- 1 x User Manual

HOW TO CLEAN



FILL A BOTTLE WITH CLEAN WATER



PLACE THE AERATOR WITH TUBE ON THE BOTTLE



PRESS TO DISPENSE THE WATER THROUGH THE AERATOR



WIPE DOWN THE TUBE AND AERATOR WITH A WASHCLOTH. STORE YOUR AERATOR IN A DRY PLACE

All components included in the CIRCLE JOY Electric Wine Opener Set.

3. SETUP

3.1. Charging the Devices

Before first use, fully charge both the Electric Wine Opener and the Rechargeable Wine Aerator Pourer using the provided USB charging cable. The LED indicator will turn off when fully charged.

HOW TO USE



Connect the USB cable to the charging port on the device. The LED indicator will show charging status.

3.2. Assembling the Wine Aerator Pouter

Insert the long tube into the bottom silicone plug of the aerator pouter. Ensure it is securely fitted to allow proper wine flow.

CIRCLE JOY

Make for the
best taste

The pouter finishes first breathing by infusing the bottle with air, then optional full aeration is completed by the oxygenating switch, which reveals true flavors and aromas of your wine.



Properly attach the tube to the base of the wine aerator pouter.

4. OPERATING INSTRUCTIONS

4.1. Using the Foil Cutter

1. Place the foil cutter on top of the wine bottle.
2. Grip the bottle firmly and twist the foil cutter around the bottle neck to cleanly remove the foil seal.
3. Remove the foil cutter and discard the foil.



Twist the foil cutter to effortlessly remove the wine bottle's foil seal.

4.2. Using the Electric Wine Opener

1. Place the electric wine opener vertically on top of the wine bottle, ensuring the corkscrew is centered over the cork.
2. Press and hold the lower button. The corkscrew will automatically penetrate the cork and pull it out of the bottle.
3. Once the cork is fully removed, lift the opener from the bottle.
4. To release the cork from the opener, press and hold the upper button. The cork will be ejected.

TRADITIONAL WINE AERATOR



- X** Wait too long
- X** Difficult to clean
- X** Inconvenient Use
- X** Inconvenient to carry

CIRCLE JOY ELECTRIC WINE AERATOR POURER

1 ONE-TOUCH OPERATION

2 AUTOMATIC POUR

3 INSTANT AERATING

4 PORTABLE

5 EASY TO CLEAN



The electric wine opener effortlessly removes the cork with a simple press of a button.

4.3. Using the Rechargeable Wine Aerator Pourer

1. Insert the assembled aerator pourer firmly into the neck of the opened wine bottle.
2. Place a wine glass beneath the pourer's spout.
3. Press the button on top of the aerator pourer to dispense and aerate the wine simultaneously. Press again to stop.

BASED ON BERNOULLI PRINCIPLE TO ACHIEVE EFFICIENT AUTOMATIC AERATING



▲ Before



▲ After



The electric wine aerator pourer instantly aerates and dispenses wine with one touch.

4.4. Using the Vacuum Wine Stopper

1. Place the vacuum wine stopper firmly into the neck of the opened wine bottle.
2. Pump the top of the stopper several times until resistance is felt. This indicates a vacuum seal has been created, preserving the wine's freshness.

HOW TO USE



FULLY CHARGE FOR THE FIRST TIME.
THE LED INDICATOR WILL TURN OFF WHEN FULLY CHARGED.



INSTALL THE TUBE INTO THE BOTTOM SILICONE PLUG
OF THE DISPENSER.



PLACE THE AERATOR WITH TUBE ON THE WINE BOTTLE.



PRESS THE BUTTON TO WORK, PRESS AGAIN TO STOP.

Use the vacuum wine stopper to seal opened bottles and maintain wine freshness.

5. CARE AND MAINTENANCE

5.1. Cleaning the Electric Wine Opener

Wipe the exterior of the electric wine opener with a soft, damp cloth. Do not immerse the device in water or wash it under running water, as this can damage the electronic components.

5.2. Cleaning the Wine Aerator Pourer

1. Detach the tube from the aerator pourer.
2. Fill a bottle or glass with clean water.
3. Insert the aerator pourer with its tube into the water.
4. Press the button to dispense the water through the aerator, flushing out any wine residue.
5. Wipe down the tube and aerator with a washcloth and allow them to air dry completely before storing.

CIRCLE JOY



Clean the aerator pourer by running clean water through it.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Electric Wine Opener not turning on/working.	Low battery.	Charge the device fully using the USB cable.
Cork not removing completely.	Opener not aligned vertically or battery low.	Ensure the opener is centered and vertical. Recharge if necessary.
Wine Aerator Pourer not dispensing wine.	Tube not properly inserted or low battery.	Check tube connection. Recharge the aerator.
Vacuum Wine Stopper not creating a seal.	Stopper not firmly placed or insufficient pumping.	Ensure stopper is pushed down firmly. Pump more times until resistance is felt.

7. PRODUCT SPECIFICATIONS

Brand: CIRCLE JOY

Model Number: SGS-KD-8

Material: Metal

Color: Silver

Item Weight: 1.2 Pounds

Number of Items: 4 (Electric Wine Opener, Wine Aerator Pourer, Foil Cutter, Vacuum Wine Stopper)

Power Source: Rechargeable (USB)

8. WARRANTY AND SUPPORT

CIRCLE JOY is committed to customer satisfaction. This product comes with a 12-month satisfaction service. If you encounter any issues or have questions during use, please do not hesitate to contact CIRCLE JOY customer support for assistance.

For support, please refer to the contact information provided on the product packaging or visit the official CIRCLE JOY website.