

[Manuals.plus](#) /

> [DACOM](#) /

> DACOM FreeBeats Open Ear Bluetooth Headphones H11 User Manual

DACOM H11

DACOM FreeBeats Open Ear Bluetooth Headphones H11 User Manual

Model: H11 | Brand: DACOM

INTRODUCTION

Thank you for choosing the DACOM FreeBeats Open Ear Bluetooth Headphones. These wireless earbuds are designed to provide a comfortable listening experience while keeping you aware of your surroundings. Featuring Bluetooth 5.3, Environmental Noise Cancellation (ENC), and a long playtime, they are ideal for various activities including sports, work, and daily commutes. This manual will guide you through the setup, operation, and maintenance of your new headphones.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- DACOM FreeBeats Open Ear Bluetooth Headphones (Left and Right earbuds)
- Charging Case
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The DACOM FreeBeats headphones feature an open-ear design for comfort and situational awareness. The lightweight earbuds rest gently on your ear without entering the ear canal.

Open-Ear Comfort



Image: The DACOM FreeBeats Open Ear Bluetooth Headphones, showing both earbuds and their charging case.

The earbuds are equipped with 16.2mm dynamic drivers for clear audio and feature a secure, comfortable fit suitable for various activities.

Pilotes à membrane vibrante de 16,2 mm




Image: An exploded view of the earbud, illustrating the 16.2mm dynamic driver and internal structure.

SETUP

1. Charging the Headphones

Before first use, fully charge the headphones and the charging case. Place the earbuds into the charging case. Connect the charging case to a power source using the provided USB cable. The indicator lights on the case will show the charging status.

45H Super Long Playtime

The Headphone can continue to listen to
15 Hour Per Charge



15 Hrs
Single Charge

+

45 Hrs
With Charging Case

=

10 Min
1.5-Hour Playtime

Image: The DACOM FreeBeats charging case with earbuds, illustrating the charging process and battery indicators.

A full charge provides up to 15 hours of continuous playback for the earbuds, and the charging case extends total playtime to 45 hours. A 10-minute quick charge can provide 1.5 hours of playtime.

2. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and an indicator light (or voice prompt) will confirm.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "DACOM FreeBeats" (or similar name) in the list of available Bluetooth devices.
5. Select "DACOM FreeBeats" to connect. Once connected, a voice prompt will confirm successful pairing.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

The DACOM FreeBeats headphones feature intuitive touch controls on each earbud.

Commandes à touche unique

-  **Raccrocher**
Appuyez sur "" L "" ou "" R "" 2 fois
-  **Répondre**
Appuyez sur "" L "" ou "" R "" 2 fois
-  **Rejeter l'appel**
Appuyez longuement sur "" L "" ou "" R "" 3 secondes
-  **Musique Lecture/Pause**
Appuyez sur "" L "" ou "" R "" 2 fois
-  **Monter le son**
Appuyez sur "" R "" 1 fois
-  **Baisser le volume**
Appuyez sur "" L "" 1 fois
-  **Siri**
Appuyez longuement sur "" L "" ou "" R "" 3 secondes et libre de réveiller siri

-  **Chanson précédente**
Appuyez sur "" L "" 3 fois
-  **Prochaine chanson**
Appuyez sur "" R "" 3 fois



Image: Detailed diagram of single-touch controls for various functions.

Touch Control Functions

Function	Action
Play/Pause Music	Tap 'L' or 'R' earbud 2 times
Next Song	Tap 'R' earbud 3 times
Previous Song	Tap 'L' earbud 3 times
Volume Up	Tap 'R' earbud 1 time
Volume Down	Tap 'L' earbud 1 time
Answer Call	Tap 'L' or 'R' earbud 2 times
End Call	Tap 'L' or 'R' earbud 2 times
Reject Call	Long press 'L' or 'R' earbud for 3 seconds
Activate Voice Assistant (Siri)	Long press 'L' or 'R' earbud for 3 seconds and release

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your DACOM FreeBeats headphones.

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool,

dry place.

- **Water Resistance:** The earbuds are sweatproof, making them suitable for workouts. However, they are not designed for swimming or submersion in water. Avoid exposing them to excessive moisture.
- **Charging:** Use only the provided charging cable or a certified equivalent. Do not attempt to charge with damaged cables or chargers.

TROUBLESHOOTING

If you encounter issues with your headphones, please refer to the following common solutions:

Common Issues and Solutions

Problem	Possible Solution
Earbuds not pairing	<ul style="list-style-type: none">◦ Ensure earbuds are charged and out of the case.◦ Turn off and on Bluetooth on your device.◦ Forget "DACOM FreeBeats" from your device's Bluetooth list and try pairing again.◦ Restart your device.
No sound from one earbud	<ul style="list-style-type: none">◦ Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again.◦ Check device's audio balance settings.
Earbuds not charging	<ul style="list-style-type: none">◦ Ensure the charging cable is securely connected to both the case and the power source.◦ Check if the charging case has power.◦ Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
Poor sound quality	<ul style="list-style-type: none">◦ Ensure the earbuds are within Bluetooth range of your device (up to 10 meters).◦ Avoid obstacles between the earbuds and your device.◦ Check your device's audio settings.

SPECIFICATIONS

DACOM FreeBeats H11 Technical Specifications

Feature	Detail
Model Name	FreeBeats (H11)
Brand	DACOM
Color	Black
Ear Placement	Open-Ear (Extra-auricular)
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3

Feature	Detail
Bluetooth Range	10 Meters
Driver Size	16.2 mm Dynamic Drivers
Frequency Range	20 Hz - 20000 Hz
Battery Life (Earbuds)	Up to 15 hours per charge
Total Playtime (with Case)	Up to 45 hours
Control Method	Touch Control
Microphone	Included (ENC Noise Cancelling)
Water Resistance Level	Sweatproof (IPX rating not specified, but "Étanche" is mentioned, implying resistance)
Weight (Item)	63 Grams
Compatible Devices	Bluetooth-enabled smartphones, tablets, laptops, Smart TVs, and other devices supporting touch control.

WARRANTY AND SUPPORT

Warranty: Your DACOM FreeBeats H11 headphones come with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

Support: For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact DACOM customer support through the retailer where you purchased the product or visit the official DACOM website for contact information.