

ODK B0CBS58WP6

ODK 55 Inch L Shaped Gaming Computer Desk Instruction Manual

Brand: ODK | Model: B0CBS58WP6

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your ODK 55 Inch L Shaped Gaming Computer Desk. Designed for optimal space utilization and functionality, this desk features integrated power outlets, reversible storage shelves, and a carbon fiber surface. Please read this manual thoroughly before assembly and use to ensure proper setup and longevity of your product.

IMPORTANT SAFETY INFORMATION

Always assemble the desk according to the instructions. Ensure the desk is stable and secure before use, especially in small spaces. Keep the desk away from high-traffic areas and secure it to the wall if possible to prevent tip-over hazards. Do not overload the desk beyond its stated weight capacity.

PRODUCT FEATURES

- Power Outlets & Charging Ports:** Equipped with 3 AC power outlets, 1 USB charging port, and 1 Type-C port for convenient charging of electronic devices directly from your desk.
- Carbon Fiber Texture & Sturdy Construction:** Features a durable carbon fiber texture board and a robust metal frame, ensuring stability, scratch resistance, and water resistance.
- Reversible Corner Desk for Small Space:** The L-shaped design is ideal for maximizing space in corners. The storage shelves can be configured on either the left or right side during assembly to fit your room layout.
- Ample Storage Space:** Includes two-tier open shelves and a dedicated PC stand to provide generous space for your computer tower, books, files, and other accessories. A convenient side storage bag helps organize gaming gear or office supplies.
- Easy Assembly:** The desk comes with clear, detailed instructions and all parts are clearly labeled for a straightforward assembly process.

SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. All necessary tools and hardware are included in the package.

- Unpack Components:** Carefully remove all parts from the packaging. Verify that all components and hardware

listed in the instruction manual are present.

2. **Identify Parts:** Each part is labeled with a letter or number. Refer to the assembly diagram in your manual to identify each piece.
3. **Assemble Frame:** Begin by assembling the metal frame components. Secure all screws loosely at first, then tighten them fully once the entire frame is in place to allow for minor adjustments.
4. **Attach Desktop Panels:** Secure the carbon fiber desktop panels to the assembled frame using the provided hardware.
5. **Install Storage Shelves:** Attach the two-tier open shelves. Decide whether you want them on the left or right side of the L-shape before securing them.
6. **Attach PC Stand:** Secure the dedicated PC stand in its designated location under the desk.
7. **Install Side Storage Bag:** Attach the fabric side storage bag to the desk frame using the designated hooks or fasteners.
8. **Connect Power Unit:** Ensure the power outlet and charging port unit is securely fitted into the desktop cutout. Connect the desk's main power cord to a functional wall outlet.
9. **Adjust Foot Pads:** Adjust the non-slip foot pads at the base of each leg to ensure the desk is level and stable on uneven surfaces. This also protects your floor from scratches.




Image: Detailed product dimensions showing the overall size and layout of the ODK L-shaped desk.

Your browser does not support the video tag.

Video: An overview of the ODK L-shaped gaming computer desk, demonstrating its features and compact design.

OPERATION

Your ODK L-shaped desk is designed for convenience and efficiency in your workspace.


Power Outlets and Charging Ports

The integrated power strip provides easy access to power for your electronic devices. Simply plug your electronics into the 3 AC outlets, 1 USB-A port, or 1 Type-C port located on the desktop. Ensure the desk's main power cord is connected to a functional wall outlet for power delivery.



Power Outlets

Equip 3 power outlets and 2 USB charging ports for your electronic devices



PC Stand & Large Storage Space

Provide large space for computer towers and game devices

Image: Close-up view of the integrated power outlets, USB, and Type-C charging ports on the desk surface.

Storage Features

Utilize the two-tier open shelves for organizing books, files, or displaying decorative items. The dedicated PC stand keeps your computer tower off the floor, improving airflow and accessibility. The side storage bag is ideal for keeping smaller items like headphones, controllers, or office supplies neatly organized and within reach, helping to maintain a clutter-free desktop.



Adjustable Foot Pads

Protect your floor from scratches and ensure stability on uneven surfaces



Side Storage Bag

An extra side storage bag can help you organize your gaming devices

Image: Details of the adjustable foot pads for stability and the convenient side storage bag for organization.

CARE AND MAINTENANCE

- Cleaning:** Wipe the carbon fiber surface and metal frame with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents that could damage the finish.
- Spills:** Immediately wipe up any liquid spills to prevent water damage, especially on the desktop surface.
- Tighten Fasteners:** Periodically check and tighten all screws and fasteners to ensure the desk remains stable and secure over time.
- Avoid Overloading:** Do not exceed the maximum weight recommendation of 100 kilograms (220 lbs) to prevent structural damage to the desk.
- Placement:** Place the desk on a level surface. Avoid direct sunlight or extreme temperature changes to prevent material warping or fading.

TROUBLESHOOTING

Desk Wobbles

If the desk feels unstable or wobbles, first ensure that all assembly screws are securely tightened. Then, adjust the non-slip foot pads on each leg individually to ensure even contact with the floor, compensating for any unevenness in your flooring.

Power Outlets Not Working

Verify that the desk's main power cord is firmly plugged into a functional wall outlet. Check if the circuit breaker on the integrated power strip (if applicable) has tripped; reset it if necessary. If issues persist, ensure the wall outlet itself is working by testing it with another device. If the problem continues, contact customer support or a qualified electrician.

Difficulty with Assembly

Review the assembly instructions carefully, paying close attention to the diagrams and part labels. Ensure all parts are correctly oriented before tightening screws. If you encounter persistent difficulties, do not force parts; instead, contact ODK customer support for assistance.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ODK
Model	B0CBS58WP6
Dimensions (D x W x H)	31.5"D x 55.1"W x 29.5"H
Color	Carbon Fiber Surface, Black
Top Material Type	Carbon Fiber
Base Material	Metal
Power Outlets	3 AC Outlets, 1 USB-A, 1 Type-C
Storage Options	Two-tier open shelves, PC stand, Side storage bag
Maximum Weight Recommendation	100 Kilograms (220 lbs)
Assembly Required	Yes

WARRANTY AND SUPPORT

This ODK L Shaped Gaming Computer Desk comes with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your product or contact ODK customer support directly.

For any questions, assistance with assembly, or troubleshooting, please contact ODK customer support. Contact information can typically be found on the product packaging or the official ODK website. Please have your model number (B0CBS58WP6) ready when contacting support.