



Manuals.plus /

- › Fresh 'n Rebel /
- › Fresh 'n Rebel Twins 3+ Tip Wireless In-Ear Bluetooth Headphones User Manual

## Fresh 'n Rebel Twins 3+ Tip

# Fresh 'n Rebel Twins 3+ Tip Wireless In-Ear Bluetooth Headphones

User Manual

## INTRODUCTION

---

This manual provides detailed instructions for setting up, operating, and maintaining your Fresh 'n Rebel Twins 3+ Tip Wireless In-Ear Bluetooth Headphones. Please read this manual carefully before using your device to ensure optimal performance and longevity.



Image: Fresh 'n Rebel Twins 3+ Tip wireless earbuds in their charging case, showcasing the dried green color and compact design.

## WHAT'S IN THE BOX?

---

Upon unboxing your Fresh 'n Rebel Twins 3+ Tip headphones, ensure all the following items are present:

# WAS IST IN DER BOX?



- Twins 3+ Tip True Wireless Ohrhörer
- Ladebox
- 3 Größen mit weichen Silikon-Ohrstöpseln
- Ladekabel (USB auf USB-C)

Image: A visual representation of the package contents, including the Twins 3+ Tip True Wireless Earbuds, their charging box, three sizes of soft silicone ear tips (S, M, L), and a USB-A to USB-C charging cable.

- Twins 3+ Tip True Wireless Earbuds
- Charging Case
- 3 Sizes of Soft Silicone Ear Tips (S, M, L)
- USB-A to USB-C Charging Cable

## SETUP GUIDE

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the Twins 3+ Tip earbuds and their charging case. The case supports both wired (USB-C) and wireless (Qi) charging.

- Connect the provided USB-A to USB-C cable to the charging case and a power source.
- Alternatively, place the charging case on a Qi-compatible wireless charging pad.
- A full charge takes approximately 1.5 hours.
- The earbuds provide up to 6 hours of playback on a single charge, with the charging case extending total playtime to 27 hours.
- Quick charge feature: 15 minutes of charging provides 3 hours of playback.

**27ST**

**WIEDERGABEZIT**

 = **6ST** |  = **21ST**

**SCHNELLADEN**

**15 MIN. ⚡ = 3ST**

Image: Visual representation of the battery life, indicating 27 hours of total playtime (6 hours from earbuds + 21 hours from case) and the quick charge capability (15 minutes charge for 3 hours playback).

## 2. Initial Pairing

Follow these steps to pair your Twins 3+ Tip headphones with your device:

1. Ensure the earbuds are in the charging case and the case has power.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Select "Twins 3+ Tip" from the list of available devices.
5. Once connected, you will hear an audible confirmation.

## 3. Multipoint Bluetooth Connection

The Twins 3+ Tip supports Multipoint Bluetooth, allowing you to connect to two devices simultaneously. This feature enables seamless switching between audio sources, for example, from your laptop to your smartphone.

ERHÄTLICH  
IN 6 FARBEN



Image: An illustration demonstrating the Multipoint Bluetooth feature, allowing the earbuds to be connected to two devices, such as a laptop and a smartphone, at the same time.

## OPERATING INSTRUCTIONS

---

### Button Controls

The Twins 3+ Tip earbuds feature clickable button controls for easy management of music playback, calls, and voice assistant activation. Refer to the diagram below for button locations and functions.



Image: A detailed view of an earbud, indicating the user-friendly clickable button for optimal control and its compatibility with voice assistants like Siri and Google Assistant.

**Earbud Control Functions**

Action	Function
Single Click	Play/Pause music, Answer/End call
Double Click (Left Earbud)	Previous Track
Double Click (Right Earbud)	Next Track
Triple Click	Activate Voice Assistant
Long Press	Reject Call

**In-Ear Detection (Automatic Pause)**

The Twins 3+ Tip earbuds are equipped with in-ear detection sensors. Music playback will automatically pause when you remove an earbud from your ear and resume when you put it back in.

## AUTOMATISCHE PAUSE IN-EAR-ERKENNUNG



Die Wiedergabe deiner Musik wird automatisch angehalten und fortgesetzt

Image: A visual demonstrating the automatic pause feature, where music playback is automatically paused and resumed when the earbuds are taken out or put back into the ear.

### Beamforming ENC Microphones

For crystal-clear phone calls, the Twins 3+ Tip features Beamforming Environmental Noise Cancellation (ENC) microphones. These microphones reduce ambient noise and focus on your voice, ensuring clear communication even in noisy environments.

## BEAMFORMING ENC-MIKROFONE



Reduziert Umgebungsgeräusche und konzentriert sich auf deine Stimme für kristallklare Telefonate

Image: A diagram highlighting the Beamforming ENC Microphones, explaining how they reduce ambient noise and concentrate on your voice for crystal-clear phone calls.

## IPX4 Splashproof Rating

The Twins 3+ Tip earbuds are IPX4 splashproof, meaning they are resistant to splashes of water from any direction. This makes them suitable for workouts or light rain, but they are not designed for submersion in water.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your Twins 3+ Tip headphones, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Ear Tips:** Remove the silicone ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching them to the earbuds.
- **Storage:** When not in use, always store the earbuds in their charging case to protect them from dust, dirt, and damage. Store in a cool, dry place away from extreme temperatures.
- **Avoid Water Exposure:** While splashproof, avoid prolonged exposure to water or high humidity. Do not wear them while swimming or showering.

## TROUBLESHOOTING

---

If you encounter issues with your Twins 3+ Tip headphones, try the following solutions:

## Common Issues and Solutions

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then open again. Check your device's Bluetooth settings and forget "Twins 3+ Tip" if previously paired, then try pairing again.
Only one earbud working	Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid for a few seconds, then open it again. This often re-syncs them.
No sound	Check the volume on both your connected device and the earbuds. Ensure the earbuds are properly connected via Bluetooth. Try playing audio from a different application or device.
Poor call quality	Ensure the microphones are not obstructed. Move closer to your connected device. Check for strong Wi-Fi or other wireless interference.
Charging issues	Check the charging cable and power adapter. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris. If using wireless charging, ensure proper alignment on the Qi pad.

If the issue persists, please refer to the support section or contact Fresh 'n Rebel customer service.

## SPECIFICATIONS

---

Feature	Detail
Model Name	Twins 3+ Tip
Brand	Fresh 'n Rebel
Connectivity Technology	Wireless (Bluetooth)
Ear Placement	In-Ear
Form Factor	In-Ear
Noise Control	Noise Shielding (ENC Microphones)
Playtime (Earbuds)	Up to 6 hours
Total Playtime (with Case)	Up to 27 hours
Charging Time	Approx. 1.5 hours
Water Resistance	IPX4 Splashproof
Microphones	Beamforming ENC Microphones
Special Features	Multipoint Bluetooth, In-Ear Detection, Clickable Button Control, Wireless Charging (Qi)
Item Weight	53 Grams
ASIN	B0CBShQ58F

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the official Fresh 'n Rebel website or contact their customer service directly. Keep your proof of purchase for warranty claims.

You can visit the Fresh 'n Rebel store on Amazon for more information:[Fresh 'n Rebel Amazon Store](#)