

## acer A314-36P-35UU

# Acer Aspire 3 A314-36P-35UU Slim Laptop User Manual

Model: A314-36P-35UU | Brand: Acer

## 1. INTRODUCTION AND OVERVIEW

The Acer Aspire 3 A314-36P-35UU is a slim and lightweight laptop designed for everyday productivity and multitasking. Featuring a 14.0-inch Full HD IPS display, an Intel Core i3-N305 Processor, 8GB LPDDR5 memory, and a 128GB NVMe SSD, it offers reliable performance for various tasks. This manual provides essential information for setting up, operating, and maintaining your laptop.



The Acer Aspire 3 A314-36P-35UU laptop, open and ready for use.

### Key Features:

- **Purposeful Design:** Thin and light for easy portability.
- **Ready-to-Go Performance:** Powered by an Intel Core i3-N305 Processor for efficient multitasking.

- **Visually Stunning Display:** 14.0" Full HD IPS screen with narrow bezels for clear visuals.
- **Internal Specifications:** 8GB LPDDR5 Onboard Memory and 128GB NVMe SSD for storage.
- **Enhanced Communication:** HD front-facing camera with Acer TNR and PurifiedVoice technology for clear video calls.
- **Wireless Connectivity:** Wi-Fi 6 (802.11ax) for strong and consistent wireless signals.
- **Improved Thermals:** Enhanced thermal system for efficient cooling during extended use.
- **Operating System:** Windows 11 Home in S mode.

## 2. WHAT'S IN THE BOX

---

Upon unpacking your Acer Aspire 3 laptop, please ensure all the following items are present:


- Acer Aspire Laptop
- AC Adapter
- Power Cord

## 3. SETUP

---

Follow these steps to set up your new Acer Aspire 3 laptop:

1. **Unpack the Laptop:** Carefully remove the laptop and all accessories from the packaging.
2. **Connect Power:** Plug the AC adapter into the laptop's DC-in jack and then into a power outlet. It is recommended to fully charge the battery before first use.
3. **Initial Boot:** Open the laptop lid and press the power button. The laptop will guide you through the initial Windows 11 setup process. Follow the on-screen instructions to configure your region, language, network, and user account.
4. **Connect Peripherals:** Connect any external devices such as a mouse, external keyboard, or monitor to the available ports.



The laptop features multiple ports for connectivity, including USB Type-C, USB 3.2, and HDMI.

## 4. OPERATING YOUR LAPTOP

---

### Power On/Off:

- To power on, press the power button located on the keyboard.
- To power off, click the Start button in Windows, then select Power > Shut down.


## Using the Touchpad:

The touchpad functions as a mouse. Use single-finger taps for left-clicks and two-finger taps for right-clicks. You can also use multi-touch gestures for scrolling and zooming.

## Connecting to Wi-Fi:

Your laptop supports Wi-Fi 6 for fast and stable wireless connections. To connect:

1. Click the Wi-Fi icon in the taskbar.
2. Select your desired network from the list.
3. Enter the network password if prompted and click Connect.



Enjoy fast and reliable internet with Wi-Fi 6 connectivity.

## Windows 11 Home in S Mode:

Your laptop comes with Windows 11 Home in S mode, which is a version of Windows streamlined for security and performance. In S mode, you can only install apps from the Microsoft Store, and you must use Microsoft Edge for safe browsing. You can switch out of S mode at any time, but you cannot switch back.

---

This video demonstrates the powerful tools available with Microsoft 365, enhancing productivity on your Windows 11 device.

---

This video showcases Windows AI Photos, demonstrating how to easily enhance and manage your images.

---

This video illustrates the Windows 11 AI Snipping tool, allowing for easy text extraction and sensitive information protection.

---

This video demonstrates Windows AI Paint, highlighting its enhanced features for drawing and digital creation, including background removal.


---

This video introduces Microsoft Windows Copilot, your everyday AI companion for enhancing creativity and productivity.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your laptop:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and exterior. For stubborn smudges, dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals.
- **Battery Care:** To maximize battery life, avoid fully discharging the battery frequently. Store the laptop in a cool, dry place when not in use for extended periods.
- **Software Updates:** Regularly update your Windows operating system and drivers to ensure security and performance.
- **Thermal Management:** The Aspire 3 features improved thermals. Ensure the vents are not obstructed to allow for proper airflow and prevent overheating. Avoid using the laptop on soft surfaces like beds or couches that can block ventilation.



### Ready-to-Go Performance

The Intel® Core i3 processor and Intel® UHD graphics distribute performance where you need it most. From streaming to browsing to photo and video editing and more — experience the performance boost you need for your biggest breakthroughs.

The laptop's improved thermal design helps maintain optimal operating temperatures.

## 6. TROUBLESHOOTING

If you encounter issues with your laptop, try the following basic troubleshooting steps:

- **No Power:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Check if the power outlet is functional.
- **System Unresponsive:** If the laptop freezes, press and hold the power button for 10-15 seconds to force a shutdown. Wait a few moments, then restart the laptop.
- **Wi-Fi Connectivity Issues:** Restart your router and modem. On your laptop, turn Wi-Fi off and then on again. Ensure you are selecting the correct network and entering the correct password.
- **Display Problems:** If the screen is blank or flickering, try connecting an external monitor to the HDMI port to determine if the issue is with the laptop's display or graphics output.
- **Slow Performance:** Close unnecessary applications, check for malware, and ensure your operating system is up to date. Consider freeing up disk space if your storage is nearly full.

For more complex issues, refer to the Acer support website or contact customer service.

## 7. SPECIFICATIONS

Below are the detailed specifications for the Acer Aspire 3 A314-36P-35UU Slim Laptop:

Feature	Specification
Model Name	A314-36P-35UU

Feature	Specification
Screen Size	14 Inches
Screen Resolution	1920 x 1080 pixels (Full HD IPS)
Processor	Intel Core i3-N305 (3.8 GHz)
RAM	8 GB LPDDR5
Memory Speed	2400 MHz
Hard Drive	128 GB NVMe SSD
Graphics Coprocessor	Intel UHD Graphics (Integrated)
Wireless Type	802.11ax (Wi-Fi 6), Bluetooth
USB 3.0 Ports	3 (1x USB Type-C 3.2 Gen 2, 2x USB 3.2 Gen 1)
HDMI Port	1 (HDMI 2.1 with HDCP support)
Operating System	Windows 11 Home in S Mode
Item Weight	3.09 pounds
Product Dimensions	12.93 x 0.74 x 8.55 inches
Color	Silver

## 8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Acer support website. The warranty typically covers manufacturing defects for a specified period from the date of purchase.

If you require technical assistance or have questions not covered in this manual, please contact Acer customer support through their official channels. Have your laptop's model number (A314-36P-35UU) and serial number ready when contacting support.