

## QCen 800W

# QCen 800W Centrifugal Juicer Machine Instruction Manual

Model: 800W | Brand: QCen

## 1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is switched off before assembling, disassembling, or cleaning.
- Keep hands and utensils out of the feed chute during operation to prevent injury.
- Always use the food pusher provided.
- Do not operate the appliance if the cord or plug is damaged.
- Place the juicer on a stable, flat, and dry surface.
- This appliance is for household use only.

## 2. PRODUCT OVERVIEW (COMPONENTS)

Familiarize yourself with the parts of your QCen 800W Centrifugal Juicer Machine:

- **Motor Base:** Contains the powerful 800W motor and speed control dial.
- **Feed Chute:** Wide 3-inch opening for inserting fruits and vegetables.
- **Food Pusher:** Used to guide ingredients down the feed chute.
- **Filter Basket:** Stainless steel precision micro filter that separates juice from pulp.
- **Juice Collector:** Container to collect extracted juice, often with a lid to prevent splattering.
- **Pulp Container:** Collects discarded pulp.
- **Safety Locking Arm:** Secures the juicer components in place for safe operation.
- **Cleaning Brush:** Included for easy cleaning of the filter basket.

QCen

# Centrifugal Juicer

Easy to extract juice from fruits and vegetables, provide you with 100% nutrients and vitamins every day.

---



Image: Overview of the QCen 800W Centrifugal Juicer Machine and its various parts.

# 3" Wide Mouth

Save your time on chopping and cutting the fruits and vegetables before juicing



Image: Close-up of the 3-inch wide mouth feed chute, designed to reduce preparation time.

## 3. SETUP

Follow these steps to assemble your juicer before first use:

1. Place the motor base on a clean, dry, and stable surface. The non-slip rubber feet will help secure it.
2. Insert the pulp container into its designated slot at the back of the motor base.
3. Place the filter basket onto the motor base, ensuring it is securely seated.
4. Position the juicer cover over the filter basket and motor base.

5. Lift the safety locking arm and secure it into the grooves on the juicer cover. The juicer will not operate unless the locking arm is correctly engaged.
6. Place the juice collector under the spout at the front of the juicer. Ensure the lid is removed from the spout before use.
7. Insert the food pusher into the feed chute.

For a visual guide on assembly, watch the demonstration video below:

---

Video: A demonstration of the juicer's assembly and operation.

## 4. OPERATING INSTRUCTIONS

Prepare your ingredients and begin juicing:

1. Wash all fruits and vegetables thoroughly.
2. Cut larger items into pieces that fit comfortably into the 3-inch wide feed chute. Remove any hard pits or large seeds.
3. Plug the juicer into a power outlet.
4. Select the appropriate speed setting using the dial:
  - **Speed '1' (Low):** Ideal for soft fruits and vegetables such as watermelon, oranges, grapes, and strawberries.
  - **Speed '2' (High):** Suitable for harder fruits and vegetables like carrots, celery, apples, and pears.
5. Turn the juicer ON.
6. Gradually feed the prepared ingredients into the feed chute. Use the food pusher gently to guide them down. Do not force ingredients.
7. The fresh juice will flow into the juice collector, and the pulp will accumulate in the pulp container.
8. Once juicing is complete, turn the juicer OFF and unplug it.

# 2 Speed Control

For different fruits and vegetable



## SPEED I

For soft fruits and veg



## SPEED II

For hard fruits and veg



Image: Illustration of the dual speed control, indicating optimal settings for various produce types.

Video: A user demonstrating the juicer in action, making fresh fruit and vegetable juice.

## 5. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your juicer. All detachable parts are dishwasher safe.

1. Ensure the juicer is OFF and unplugged before cleaning.
2. Release the safety locking arm and remove the food pusher and juicer cover.
3. Carefully remove the filter basket. Use the provided cleaning brush to remove any pulp or residue from the mesh.
4. Empty the pulp container and juice collector.

5. Wash all detachable parts (food pusher, juicer cover, filter basket, pulp container, juice collector) with warm, soapy water or place them in the dishwasher.
6. Wipe the motor base with a damp cloth. Never immerse the motor base in water.
7. Allow all parts to dry completely before reassembling or storing.

---

## EASY TO CLEAN

Removable accessories, easy to install and clean,  
all parts except the motor are dishwasher safe.



Image: Detachable components of the juicer shown in water, highlighting ease of cleaning.

Video: A review discussing the QGen Juicer, which may include insights into its long-term maintenance and cleaning.

## 6. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Safety locking arm not engaged. Power cord not plugged in. Overheat protection activated.	Ensure locking arm is securely in place. Check power connection. Unplug and let cool for 15-30 minutes.
Low juice yield or excessive pulp.	Incorrect speed setting for ingredients. Filter basket is clogged. Ingredients not fresh.	Use Speed '2' for harder produce. Clean the filter basket thoroughly. Use fresh, firm fruits and vegetables.
Juicer vibrates excessively or makes loud noise.	Uneven loading of ingredients. Filter basket not properly seated.	Feed ingredients slowly and evenly. Disassemble and re-seat the filter basket correctly.
Juice leaks from the side.	Components not assembled correctly. Too much foam.	Disassemble and reassemble all parts, ensuring a tight fit. Use the juice collector lid to minimize foam.

## 7. SPECIFICATIONS

Feature	Detail
Brand	QCen
Model	800W
Color	Red
Maximum Power	800 Watts
Number of Speeds	2
Feed Chute Size	3 inches (Wide Mouth)
Special Feature	Overheat Protection, Safety Locking Arm, Non-slip Rubber Feet
Finish Type	Stainless Steel
Blade Material	Stainless Steel
Is Dishwasher Safe	Yes (detachable parts)
Product Dimensions	13.7"D x 12.01"W x 7.76"H
Item Weight	6.98 pounds
Power Source	Corded Electric

## **8. WARRANTY AND SUPPORT**

Your QGen 800W Centrifugal Juicer Machine comes with a manufacturer's warranty against defects in materials and workmanship under normal household use. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact QGen customer service through the contact information provided in your product documentation or visit the official QGen website.