Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 1396/02

Ariete 1396 Modern Drip Coffee Maker Instruction Manual

Model: 1396/02

1. Introduction

Thank you for purchasing the Ariete 1396 Modern Drip Coffee Maker. This appliance is designed to prepare delicious American coffee with ease and convenience. Featuring a large capacity, heating base, and LCD display, it ensures your coffee stays hot and ready to serve. Please read this manual carefully before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or coffee maker in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.
- The appliance operates on 220 Volts. Ensure your power supply matches this requirement.

3. Parts and Components

Familiarize yourself with the parts of your Ariete Drip Coffee Maker:

- Water Reservoir with Water Level Indicator
- Lid
- Filter Basket (removable)
- Reusable Filter
- Glass Carafe with Handle
- Heating Plate
- Control Panel with LCD Display (Mode, Sel, HR, Min, Power buttons)
- Power Cord





Figure 3.1: Front view of the Ariete 1396 Drip Coffee Maker, showing the LCD display, control buttons, and glass carafe.



Figure 3.2: View of the coffee maker with the lid open, showing the removable filter basket and reusable filter.

4. Setup

1. **Unpacking:** Carefully remove the coffee maker and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the glass carafe, lid, and reusable filter in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.

3. **First Brew Cycle (Cleaning):** Fill the water reservoir to the MAX level with cold water. Do not add coffee grounds. Place the empty filter basket with the reusable filter in position. Close the lid. Place the empty carafe on the heating plate. Plug the coffee maker into a 220V electrical outlet. Press the Power button to start a brewing cycle. Allow the full cycle to complete. Discard the water from the carafe. Repeat this process 2-3 times to ensure the appliance is clean.
4. **Placement:** Place the coffee maker on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.

5. Operating Instructions

5.1. Brewing Coffee

1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with fresh, cold water up to the desired level, indicated by the water level indicator. Do not exceed the MAX (15 cups) mark.
2. **Add Coffee Grounds:** Place the reusable filter into the filter basket. Add the desired amount of ground coffee to the filter. A general guideline is one level tablespoon of ground coffee per cup, but adjust to your taste.
3. **Close Lid and Position Carafe:** Close the lid securely. Place the empty glass carafe onto the heating plate.
4. **Start Brewing:** Plug the coffee maker into a 220V electrical outlet. Press the**Power** button. The indicator light will illuminate, and the brewing process will begin.
5. **Serving:** Once the brewing cycle is complete, the coffee maker will automatically switch to the "keep warm" function, indicated by the heating plate remaining warm. You can serve coffee directly from the carafe. The heating plate will keep the coffee warm for approximately 40 minutes.



Figure 5.1: Serving coffee from the carafe after brewing.

5.2. Setting the Clock and Programmed Brewing

The Ariete 1396 features an LCD display and programmable timer for delayed brewing.



Figure 5.2: Close-up of the control panel, showing the LCD display and buttons.

1. **Setting the Current Time:**
    - Ensure the coffee maker is plugged in.
    - Press the **MODE** button until the clock icon is displayed.
    - Use the **HR** button to set the hour and the **MIN** button to set the minutes.
    - The time will be set automatically after a few seconds of inactivity or by pressing the **SEL** button.
2. **Setting the Programmed Start Time:**
    - Prepare the coffee maker with water and coffee grounds as described in "5.1. Brewing Coffee".
    - Press the **MODE** button until the timer icon is displayed.
    - Use the **HR** button to set the desired hour for brewing and the **MIN** button to set the minutes.
    - Press the **SEL** button to confirm the programmed time. The timer indicator will light up, confirming the setting.
    - The coffee maker will automatically start brewing at the set time.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

1. **Daily Cleaning:**
    - Always unplug the coffee maker before cleaning and allow it to cool completely.
    - Remove the reusable filter and filter basket. Discard used coffee grounds.
    - Wash the reusable filter, filter basket, and glass carafe in warm, soapy water. These parts are also dishwasher safe (top rack recommended).
    - Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

- Do not immerse the main unit, cord, or plug in water or any other liquid.

2. **Descaling:** Mineral deposits from water can build up over time and affect performance. Descale your coffee maker every 2-3 months, or more frequently if you have hard water.
    - Prepare a descaling solution: Mix white vinegar and water in a 1:2 ratio (e.g., 1 cup vinegar to 2 cups water). Fill the water reservoir with this solution up to the MAX level.
    - Place the empty carafe on the heating plate.
    - Start a brewing cycle without coffee grounds. Allow half of the solution to brew through, then turn off the coffee maker and let it sit for 15-20 minutes to allow the solution to work.
    - Turn the coffee maker back on and allow the remaining solution to brew through.
    - Discard the solution. Run 2-3 cycles with fresh, clean water to rinse out any remaining vinegar taste or smell.

7. Troubleshooting

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working 220V outlet. Check your circuit breaker.
Coffee is not brewing.	Water reservoir empty; carafe not properly placed; unit needs descaling.	Fill water reservoir. Ensure carafe is correctly positioned on the heating plate. Perform a descaling cycle.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust the amount of coffee grounds. Use a medium grind for drip coffee makers.
Water overflows from filter basket.	Too much coffee grounds; filter clogged; carafe not on heating plate.	Reduce coffee grounds. Clean the reusable filter thoroughly. Ensure carafe is correctly placed.
LCD display not working or showing incorrect time.	Power interruption; settings reset.	Reset the current time as per section 5.2. If problem persists, contact customer support.

8. Specifications

- **Model Name:** Modern filter coffee maker
- **Model Number:** 1396/02
- **Brand:** Ariete
- **Color:** Black
- **Coffee Maker Type:** Drip Coffee Machine
- **Filter Type:** Reusable
- **Operation Mode:** Fully Automatic
- **Voltage:** 220 Volts
- **Capacity:** Up to 15 cups
- **Included Components:** Filter, Carafe
- **Product Dimensions:** 6.69 x 9.84 x 12.99 inches

- **Item Weight:** 5.06 pounds
- **Human Interface Input:** Buttons
- **Coffee Input Type:** Ground coffee

9. Warranty and Support

9.1. Warranty Information

This Ariete product is covered by a manufacturer's warranty against defects in materials and workmanship. The specific duration and terms of the warranty may vary by region. Please retain your proof of purchase for warranty claims. For detailed warranty information, refer to the warranty card included with your product or visit the official Ariete website.

9.2. Customer Support

If you have any questions, require technical assistance, or need to report a problem with your Ariete 1396 Drip Coffee Maker, please contact Ariete Customer Support. You can typically find contact information (phone numbers, email, or support portals) on the official Ariete website or on the product packaging.
For online resources, visit the Ariete Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBTWLDDM

More documents and user manuals: **https://manuals.plus/**