

[Manuals.plus](#) /

› [QCen](#) /

› QCen 800W Centrifugal Juicer Extractor Instruction Manual

QCen 800W

QCen 800W Centrifugal Juicer Extractor Instruction Manual

Model: 800W

[Introduction](#)

[Safety Instructions](#)

[Product Components](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the QCen 800W Centrifugal Juicer Extractor. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new juicer. Please read it thoroughly before first use and keep it for future reference.



Figure 1: Q Cen 800W Centrifugal Juicer Extractor

This image displays the Q Cen 800W Centrifugal Juicer Extractor in Aqua, positioned on a countertop with fresh fruits and vegetables such as lettuce, tomatoes, cucumbers, and onions. A clear pitcher filled with orange juice is placed next to the juicer, highlighting its primary function.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- Always ensure the lid is securely locked with the safety locking arm in place before operation. The juicer will not operate if not correctly assembled.

- Do not operate the appliance with a damaged cord or plug.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the food pusher provided.
- The appliance features an overload protection system that will switch off the machine if overheating occurs. Allow it to cool down before resuming use.
- Avoid juicing items with very low water content, as this can strain the motor.
- This appliance is for household use only.

SAFETY DESIGN



Overheating protection

The device will automatically shut down when it overheats.



Safety lock arm

Only works when the lock is in place, otherwise it won't start.



Non-slip rubber feet

Makes you safer and more stable to use than other juicers.



Figure 2: Safety Features

This image illustrates the key safety features of the QCen Juicer. It highlights the overheating protection mechanism, the safety lock arm that prevents operation unless properly secured, and the non-slip rubber feet designed for stability during use.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your QCen Centrifugal Juicer:

1. Food Pusher
2. Feed Chute (3-inch wide mouth)
3. Lid/Cover
4. Safety Locking Arm
5. Filter Basket (Stainless Steel)
6. Juice Collector/Spout
7. Pulp Container
8. Motor Base with Control Dial
9. Juice Pitcher

3" Wide Mouth

Save your time on chopping and cutting the fruits and vegetables before juicing



Figure 3: Wide Mouth Feed Chute

This image provides a close-up view of the juicer's 3-inch wide feed chute, demonstrating its capacity to accommodate whole fruits like apples, reducing the need for extensive pre-cutting.

4. SETUP AND ASSEMBLY

Before first use, wash all detachable parts (lid, filter basket, pulp container, juice pitcher, food pusher) in warm soapy water, rinse thoroughly, and dry. The motor base should only be wiped with a damp cloth.

1. Place the motor base on a stable, flat, and dry surface.
2. Insert the juice collector onto the motor base, ensuring it is seated correctly.
3. Carefully place the stainless steel filter basket into the juice collector, ensuring it is firmly in place.
4. Position the lid onto the juice collector, aligning the spout with the juice outlet.
5. Secure the lid by lifting the safety locking arm and locking it into the vertical position on the juice cover. The juicer will not operate unless this arm is securely locked.
6. Place the pulp container under the pulp outlet and the juice pitcher under the juice spout.
7. Insert the food pusher into the feed chute.

5. OPERATING INSTRUCTIONS

Prepare your fruits and vegetables by washing them thoroughly. For best results, remove large seeds and hard pits. The 3-inch wide mouth reduces the need for extensive chopping.

1. Ensure the juicer is properly assembled and the safety locking arm is engaged.
2. Plug the juicer into a suitable power outlet.
3. Turn the control dial to the desired speed setting:
 - **Speed 1 (Low Speed):** Ideal for soft fruits and vegetables such as watermelon, oranges, strawberries, grapes, and tomatoes. (Approx. 14000-18000 RPM)
 - **Speed 2 (High Speed):** Suitable for harder fruits and vegetables like carrots, celery, apples, pears, and ginger. (Approx. 18000-22000 RPM)
4. Gradually feed the prepared fruits and vegetables into the feed chute using the food pusher. Do not force the produce down, as this can reduce juice yield and strain the motor.
5. Once juicing is complete, turn the control dial to "0" (Off) and unplug the appliance.

2 Speed Control

For different fruits and vegetable



SPEED I

For soft fruits and veg



SPEED II

For hard fruits and veg



Figure 4: Dual Speed Control

This image illustrates the two-speed control settings of the juicer. Speed I is recommended for soft produce like watermelon, oranges, and strawberries, while Speed II is for harder items such as carrots, celery, and apples.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your juicer. Clean the appliance immediately after each use.

1. **Unplug the Juicer:** Always ensure the juicer is unplugged from the power outlet before cleaning.
2. **Disassemble:** Unlock the safety arm, remove the lid, filter basket, juice collector, pulp container, and food pusher.
3. **Rinse Parts:** Rinse all detachable parts under running water to remove pulp residue.
4. **Clean Filter Basket:** The stainless steel filter basket should be cleaned with the provided brush or a soft brush to remove any trapped pulp. Be careful as the blades are sharp.
5. **Dishwasher Safe Parts:** All detachable parts, except the motor base, are dishwasher safe (top rack recommended).
6. **Clean Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
7. **Dry and Store:** Ensure all parts are completely dry before reassembling or storing the juicer. Store in a cool, dry place.

EASY TO CLEAN

Removable accessories, easy to install and clean, all parts except the motor are dishwasher safe.



Figure 5: Easy Cleaning Process

This image shows the various detachable components of the QCen Juicer, such as the lid, filter basket, and juice collector, being rinsed under water, emphasizing the product's design for easy cleaning.

7. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in. Safety locking arm not engaged. Overheat protection activated.	Ensure the power cord is securely plugged into an outlet. Check that the safety locking arm is fully locked in the vertical position. Unplug the juicer and allow it to cool down for at least 30 minutes before restarting.
Low juice yield or wet pulp.	Feeding produce too quickly. Filter basket clogged. Incorrect speed setting for produce type.	Feed produce slowly and steadily. Clean the filter basket thoroughly. Use Speed 2 for harder fruits and vegetables.
Excessive vibration or noise.	Improper assembly of filter basket. Hard object in the filter basket.	Disassemble and reassemble the filter basket, ensuring it is seated correctly. Turn off and unplug the juicer, then check and remove any foreign objects from the filter basket.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	QCen
Model	800W
Color	Aqua
Maximum Power	800 Watts
Voltage	110 Volts (AC)
Number of Speeds	2
Feed Chute Size	3 inches (Wide Mouth)
Blade Material	Stainless Steel
Finish Type	Stainless Steel
Special Feature	Overheat Protection
Product Dimensions	13.7"D x 12.01"W x 7.76"H
Item Weight	6.89 pounds
Dishwasher Safe Parts	Yes (Detachable parts, excluding motor base)

9. WARRANTY AND SUPPORT

QCen products are manufactured with quality and reliability in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact QCen customer support.

For technical assistance, troubleshooting not covered in this manual, or parts replacement, please contact QCen customer support through the retailer where the product was purchased or visit the official QCen website.

Online Resources:

- QCen Store on Amazon: [Visit the QCen Store](#)

© 2023 QCen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question