



Manuals.plus /

› Gaiatop /

› GAIATOP Fabric Shaver Instruction Manual

Gaiatop Q12

GAIATOP Fabric Shaver Instruction Manual

Model: Q12

1. INTRODUCTION

Thank you for choosing the GAIATOP Fabric Shaver. This innovative device is designed to efficiently remove lint, fuzz, and pills from various fabrics, restoring your clothes and furniture to a fresh, new appearance. Featuring a dual-head design with 6-leaf blades, a powerful motor, and an intelligent LED display, this rechargeable lint remover offers convenience and superior performance. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage to the device or injury, please observe the following safety precautions:

- Keep the device out of reach of children.
- Do not use the shaver on wet fabrics or in wet environments.
- Avoid pressing the shaver too hard against the fabric, as this may cause damage to the fabric or the device.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Ensure the net cover is securely tightened before operation. The device features a safety lock protection mechanism that automatically stops the blades if the net cover is loose or incorrectly assembled.
- Do not touch the blades directly.
- Unplug the device before cleaning or when not in use for extended periods.

3. PRODUCT OVERVIEW

The GAIATOP Fabric Shaver is designed for effective lint and fuzz removal. Below are the key components of the device:

- **Dual Shaving Heads:** Equipped with two shaving heads for larger coverage and faster lint removal.
- **6-Leaf Blades:** High-efficiency blades designed for powerful and precise shaving.
- **LED Digital Display:** Shows remaining power, speed level, and charging status.
- **Power Button/Speed Control:** Used to turn the device on/off and adjust between 3 speed levels.
- **Type-C Charging Port:** For convenient and universal charging.
- **Lint Container:** Large capacity, transparent container to collect removed lint and fuzz.
- **Safety Lock:** Prevents operation if the shaving head cover is not properly secured.
- **Honeycomb Mesh:** Features 3 sizes of honeycomb mesh to protect fabrics while effectively removing pills.



Figure 3.1: GAIATOP Fabric Shaver - Front View

2 in 1 Design

Shaves Hair Balls



Solve Pet Hair



 GAIATOP
Lint Remover

Figure 3.2: Two-in-One Design: Fabric Shaver and Lint Roller

Safety Lock Protection

Automatic shutdown when components are assembled incorrectly



3-Sizes Honeycomb Mesh

Without damaging clothes
Accurate removal of pompoms

300%
Hardness Upgrade

322
Different caliber mesh



Figure 3.3: Safety Lock Mechanism and Honeycomb Mesh Detail

4. SETUP

Before first use, please follow these steps:

1. Unpack the GAIATOP Fabric Shaver and all accessories from the exquisite packaging box. Verify that all components are present: 1 x Electric lint shaver, 1 x Type-C charging cable, 1 x Cleaning brush, 1 x User manual.

2. Inspect the device for any visible damage. If any damage is found, do not use the device and contact customer support.
3. Ensure the shaving head cover is securely attached and locked into place.
4. It is recommended to fully charge the device before its initial use.

5. CHARGING

The GAIATOP Fabric Shaver is equipped with a rechargeable battery for cordless convenience.

Rechargeable Fabric Shaver

LED Display for Power & Speed Level
& Charging Status

TYPE-C
Charging Port

2.5-4H
Fully charged for use



Figure 5.1: Charging the Fabric Shaver via Type-C Port

- Connect the provided Type-C charging cable to the charging port on the device.
- Plug the other end of the cable into a compatible USB power source (e.g., laptop/desktop, power bank, car charger, or a charger adapter (5V/1A)).
- The LED digital display will show the charging status and battery percentage.
- A full charge typically takes approximately 2.5 to 4 hours.
- The device can be used while charging, functioning as a non-stop sweater shaver.
- Once fully charged, the device can operate for up to 150 minutes.

6. OPERATING INSTRUCTIONS

Follow these steps to effectively remove lint and fuzz from your fabrics:

1. **Prepare the Fabric:** Lay the garment or fabric flat on a hard, smooth surface. Ensure the fabric is clean and dry. For delicate fabrics, stretch them slightly to create a taut surface.
2. **Power On:** Press and hold the power button to turn on the device. The LED display will illuminate.
3. **Select Speed:** Briefly press the power button to cycle through the 3 available speed levels. Choose a lower speed for delicate fabrics and a higher speed for tougher, more pilled materials.
4. **Begin Shaving:** Gently glide the shaving heads over the pilled or lint-covered area. Use light, circular motions or short, sweeping strokes. Avoid pressing down too hard to prevent damage to the fabric.
5. **Monitor Progress:** Observe the LED display for battery level and adjust speed as needed. The large coverage area and powerful suction will efficiently remove fuzz.
6. **Applicable Fabrics:** This fabric shaver is suitable for a wide range of materials, including wool coats, cotton skirts, sweaters, sofas, curtains, sheets, blankets, quilts, and plush dolls.
7. **Power Off:** Once finished, press and hold the power button to turn off the device.

Suitable For **All Types Fabric**



Figure 6.1: Suitable for Various Fabric Types

Excellent **Gift Choice**



Figure 6.2: Fabric Shaver in Use on Furniture and Bedding

7. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your fabric shaver.

1. **Empty Lint Container:** After each use, or when the lint container appears full, gently detach it from the main body. Dispose of the collected lint and fuzz. The visual design of the container allows you to easily see when it needs emptying.

2. **Clean Blades and Mesh:** Use the provided cleaning brush to remove any remaining lint or debris from the blades and the honeycomb mesh. Be careful not to damage the blades.
3. **Reassemble:** Reattach the lint container and ensure the shaving head cover is securely fastened. The safety lock feature will prevent operation if not properly assembled.
4. **Storage:** Store the device in a cool, dry place away from direct sunlight and moisture.

8. TROUBLESHOOTING

If you encounter any issues with your GAIATOP Fabric Shaver, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Charge the device fully using the provided Type-C cable.
Device stops working during use.	Net cover is loose or not tightened.	Ensure the net cover is securely fastened. The safety lock will prevent operation if it's loose.
Ineffective lint removal.	Lint container is full or blades are clogged.	Empty the lint container and clean the blades and mesh with the cleaning brush.
Unusual noise during operation.	Debris caught in blades or loose component.	Turn off the device, carefully remove the shaving head cover, and clean any debris from the blades. Ensure all parts are securely reassembled.

If the problem persists after attempting these solutions, please contact GAIATOP customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Model Number	Q12
Package Dimensions	6.97 x 4.84 x 3.46 inches
Item Weight	15.1 ounces
Battery Type	1 Lithium Ion battery (included)
Material	Plastic
Color	White
Operation Mode	Electric
Charging Port	Type-C
Charging Time	Approx. 2.5-4 hours
Operating Time	Up to 150 minutes (fully charged)

10. WARRANTY AND SUPPORT

GAIATOP is committed to providing high-quality products and excellent customer service. Your GAIATOP Fabric Shaver comes with a manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact customer support.

If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our friendly customer support team. We offer 24-hour support to ensure your satisfaction.

Contact Information:

Please refer to the contact details provided on the product packaging or the official GAIATOP website for the most up-to-date support information.