

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-318 Electric Shaver User Manual: Cordless, Rechargeable, IPX6 Waterproof Rotary Shaver](#)

VGR V-318

VGR V-318 Electric Shaver User Manual

Cordless, Rechargeable, IPX6 Waterproof Rotary Shaver

1. INTRODUCTION

Thank you for choosing the VGR V-318 Electric Shaver. This manual provides detailed instructions for the safe and effective use, maintenance, and care of your new shaver. Please read it thoroughly before first use and keep it for future reference.

The VGR V-318 is a premium cordless, rechargeable electric shaver designed for both wet and dry use. It features a 3-head rotary shaving system, an integrated pop-up trimmer, and an LED digital display for convenience.

2. SAFETY INFORMATION


WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Avoid using the shaver while it is charging.
- Do not fully submerge the shaver in water for extended periods. While IPX6 waterproof, it is designed for rinsing, not prolonged submersion.
- Keep the appliance away from children.
- Always hold the shaver away from your face when turning it on or off to prevent accidental cuts or irritation.
- Do not use the shaver if it is damaged or malfunctioning.
- Only use the charging cable provided with the shaver.

3. PACKAGE CONTENTS

Carefully unpack your VGR V-318 Electric Shaver and check that all items are present and in good condition. The package should contain:

- VGR V-318 Electric Shaver
- USB Charging Cable
- Cleaning Brush
- Protective Cap for Shaver Head
- Travel Pouch
- User Manual (this document)



FIVE-WAY SMART KNIFE HEAD IS A CLEAN SHAVE FOR FAST AND BORN

Image: The VGR V-318 Electric Shaver displayed with its included accessories: a USB charging cable, a small cleaning brush, a clear protective cap for the shaver head, and a black travel pouch.

4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your VGR V-318 Electric Shaver:

- **Rotary Shaver Head:** Features three flexible blades for a close shave.
- **Pop-up Trimmer:** Located on the back for precise trimming of sideburns and mustaches.
- **Power Button:** To turn the shaver on and off.
- **LED Digital Display:** Shows battery level and other indicators.
- **Charging Port:** Located at the bottom of the shaver.



Image: A front and back view of the VGR V-318 Electric Shaver. The front displays the three rotary shaving heads, the power button, and the LED digital display. The back shows the smooth, ergonomic design.

VGR®
VOYAGER

CONSTANT SHAVING IS COMFORTABLE

MEN'S ELECTRIC SHAVER

Rotating three-blade head, Body Wash LED display



Image: Detailed close-up images of the VGR V-318 Electric Shaver. One inset shows the intricate design of the three rotary shaving blades, and another shows the pop-up trimmer extended from the back of the shaver.

5. CHARGING THE SHAVER

Before first use, fully charge the shaver. Subsequent charges should be performed when the battery indicator on the LED display shows low power.

1. Ensure the shaver is turned off.
2. Insert the small end of the USB charging cable into the charging port at the bottom of the shaver.
3. Connect the larger end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
4. The LED display will indicate charging status. A full charge typically takes approximately 1 hour.
5. Once fully charged, the shaver provides approximately 90 minutes of cordless operation.
6. Disconnect the charging cable once charging is complete.

PACKAGE SIZE
19*12.9*7cm

PACKING QUANTITY
48

PACKING SIZE
55*44*41.5cm

SHIPPING WEIGHT
16.7kg

PARTS

Travel bag, knife head cover, cleaning brush, English instruction book

ACCESSORY DISPLAY





Image: A graphic representation of the VGR V-318 shaver's charging capabilities, highlighting USB charging, a 1-hour full charge time, and a sustained usage time of 90 minutes.

6. OPERATING THE SHAVER

6.1 Basic Shaving

1. Press the power button to turn on the shaver.
2. For a dry shave, ensure your face is clean and dry.
3. For a wet shave, apply shaving foam or gel to your face. The shaver is IPX6 waterproof and can be used in the shower.
4. Hold the shaver at a right angle to your skin and move it in small, circular motions.
5. Stretch your skin with your free hand to make the hairs stand upright, allowing for a closer shave.
6. After shaving, press the power button to turn off the shaver.

6.2 Using the Pop-up Trimmer

The pop-up trimmer is ideal for shaping sideburns, mustaches, and detailing.

1. Turn on the shaver.
2. Slide the trimmer release button (usually on the back of the shaver) upwards to engage the pop-up trimmer.
3. Hold the trimmer perpendicular to your skin and carefully trim the desired areas.
4. Once finished, push the trimmer back down until it clicks into place.

7. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your shaver. The VGR V-318 is IPX6 waterproof, allowing for easy rinsing.

1. Daily Cleaning (after each use):

- Turn off the shaver and disconnect it from any charging cable.
- Open the shaver head assembly (refer to the diagram in the Product Overview section if unsure).
- Rinse the shaver head thoroughly under running tap water. You can also rinse the inner chamber.
- Use the provided cleaning brush to remove any stubborn hair clippings from the blades and inner parts.
- Shake off excess water and leave the shaver head open to air dry completely before closing it or

attaching the protective cap.

2. Deep Cleaning (monthly or as needed):

- For a more thorough clean, you may carefully detach the individual rotary blades from the shaver head.
- Rinse each blade and its corresponding foil under running water.
- Ensure all parts are completely dry before reassembling.

3. Storage: Store the shaver in a cool, dry place. Use the protective cap to prevent damage to the shaver head.

COMFORT PRODUCTS FOCUS ON THE DETAILS



LIGHT TOUCH SWITCH

You can turn it on with a touch of the button



POP-UP SIDE BURNS

Trim your sideburns with ease

Image: A visual representation emphasizing the IPX6 waterproof rating of the VGR V-318 Electric Shaver, indicating its suitability for both wet and dry shaving and easy cleaning under running water.

8. TROUBLESHOOTING

If you encounter issues with your VGR V-318 Electric Shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is depleted, connect it to the charger.
- **Poor shaving performance:**
 - Clean the shaver head thoroughly to remove any trapped hairs or debris.
 - Ensure the shaver is fully charged. Low battery can affect motor speed.
 - The blades may be worn. Shaver heads typically need replacement every 12-18 months depending on usage.
- **Shaver feels hot during use:** This can be normal during extended use. If it becomes excessively hot or uncomfortable, turn off the shaver and allow it to cool down. Ensure the shaver head is clean and free of obstructions.
- **LED display not working:** Ensure the shaver is charged. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact VGR customer support for further assistance.


9. SPECIFICATIONS

Feature	Specification
Model Name	V-318
Brand	VGR
Head Type	Rotary (3-head)
Power Source	Battery Powered (Cordless)
Special Features	Rechargeable, IPX6 Waterproof, Pop-up Trimmer, LED Digital Display
Charging Time	Approx. 1 hour
Battery Life	Approx. 90 minutes
Recommended Use	Face
Blade Material	Stainless Steel
Item Weight	0.31 Kilograms
Package Dimensions	18.9 x 12.9 x 7.1 cm

10. WARRANTY AND SUPPORT

VGR products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included in your product packaging or visit the official VGR website. Please retain your proof of purchase for warranty claims.

Related Documents - V-318

	<p>VGR V-306 Electric Shaver User Manual - Professional Grooming Guide</p> <p>Detailed user manual for the VGR V-306 electric shaver for men. Covers package contents, features, setup, operation, maintenance, troubleshooting, technical specifications, and safety recommendations. Includes contact information for Stockluder.</p>
	<p>VGR V-930 Professional Hair Trimmer User Manual with AFA Endorsement</p> <p>Comprehensive user manual for the VGR V-930 Professional Hair Trimmer, featuring AFA endorsement with player imagery. Covers safety instructions, components, usage, charging, cleaning, maintenance, and technical specifications for this personal grooming device.</p>
	<p>VGR V-906 Professional Hair Trimmer User Manual</p> <p>Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.</p>
	<p>VGR V-085 Professional Hair Trimmer Manual and Safety Instructions</p> <p>This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.</p>
	<p>VGR V-990 Cordless Hair Trimmer User Guide</p> <p>Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.</p>
	<p>VGR V-282 Professional Hair Clipper User Manual and Specifications</p> <p>Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.</p>

Documents - VGR – V-318

[\[pdf\]](#) Instructions

общие указания по безопасности VGR Профессионал V 318 Мужская бритва 1 VOYAGE R 2 6
 КОМПОНЕНТЫ БРИТВЫ Бреющая головка Кнопка отсоединения 3 Выдвижной триммер 4 вкл
 20240131050034 26100772 1cybermall ru product instructions 20240131050034 srsItd
 AfmBOophwnMaH5pi7xkent5xbvLBGVq1IH0seU9Dgm bX59b5qXgDAdB безопасностиобщие VGR
 120240131050034 AfmBOopUXdv0UiUNUO2ewnu8FIdRk krVUR7cwypsTRI84I7D aGI3M6cybermall
 bX59b5qXgDAdBcybermall AfmBOopogK0TQ3 6r0td4kbR3ugFM6UjFQEUPTGTNle3N JtQ464dFP ||| |||

|||

...

lang: score:17 filesize: 593.05 K page_count: 1 document date: 2024-01-30

