

[Manuals.plus](#) /

› [AOHI](#) /

› AOHI Desk Charger 120W AOC-C006 User Manual

AOHI AOC-C006

AOHI Desk Charger 120W AOC-C006 User Manual

Model: AOC-C006

Brand: AOHI

1. INTRODUCTION

Welcome and thank you for choosing the AOHI Desk Charger 120W AOC-C006. This manual provides essential information for the safe and efficient use of your new charger. Please read it thoroughly before use and retain it for future reference.

Package Contents

- 1 x AOHI Desk Charger 120W AOC-C006
- 1 x User Manual



The AOHI Desk Charger 120W AOC-C006, a compact power adapter with multiple ports.

2. SAFETY INSTRUCTIONS

Important Safety Information

- Do not expose the device to water or excessive moisture.
- Do not disassemble or attempt to repair the device.
- Keep out of reach of children.
- Use only with compatible devices and cables.
- Avoid extreme temperatures.
- Unplug during lightning storms or when unused for long periods.

3. SETUP

Connecting the Charger

1. Connect the power cable to the charger's input port.
2. Plug the power cable into a standard wall outlet (AC 100-240V, 50/60Hz).
3. The charger is now ready for use.



The AOHI Desk Charger connected to a power outlet and charging a laptop via a USB-C cable.

4. OPERATING INSTRUCTIONS

Charging Your Devices

The AOHI Desk Charger 120W AOC-C006 features 2 USB-C ports and 2 USB-A ports, allowing you to charge multiple devices simultaneously.

USB-C Ports (Power Delivery)


These ports support Power Delivery (PD) for fast charging compatible devices such as laptops, tablets, and smartphones. Use a USB-C to USB-C cable for optimal performance.

USB-A Ports

These ports are suitable for charging a wide range of USB-A compatible devices, including smartphones, smartwatches, and other accessories.

1. Connect your device's charging cable to the appropriate USB-C or USB-A port on the charger.

2. Connect the other end of the cable to your device.
3. The device should begin charging automatically.



The AOHI Desk Charger simultaneously charging a laptop and a smartphone, demonstrating its multi-device capability.



A close-up view of the AOHI Desk Charger's ports, showing two USB-C (PD) and two USB-A ports.

5. MAINTENANCE

Cleaning and Storage

- Disconnect the charger from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the surface of the charger. Do not use liquid cleaners or aerosols.
- Store the charger in a cool, dry place when not in use.
- Avoid dropping or subjecting the charger to strong impacts.

6. TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Device not charging	Loose connection	Ensure cables are securely plugged into both the charger and the device.
Device not charging	Incompatible cable/device	Use a compatible charging cable and ensure your device supports the charger's output.
Slow charging	Cable quality	Use high-quality, certified charging cables, especially for fast charging.
Slow charging	Device power requirements	Some devices may require specific power profiles. Check your device's specifications.
Charger feels warm	Normal operation	It is normal for the charger to become warm during operation, especially under heavy load. If it becomes excessively hot, disconnect it immediately.

If the issue persists, please contact AOHI customer support.

7. SPECIFICATIONS

Technical Details

- **Model:** AOC-C006
- **Input:** AC 100-240V, 50/60Hz
- **Total Output Power:** 120W
- **USB-C Ports:** 2 (Power Delivery compatible)
- **USB-A Ports:** 2
- **Dimensions:** 10 x 5 x 1.27 cm
- **Weight:** 1 kg
- **Color:** Black



An internal view of the AOHI Desk Charger, highlighting its GaN technology for efficient power delivery.

8. WARRANTY AND SUPPORT

Warranty Information

This AOHI product is covered by a 2-year manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Customer Support

For technical support, warranty claims, or any questions regarding your AOHI Desk Charger, please visit the official AOHI website or contact their customer service directly.

Website: www.aohi.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question