Aramox Aramoxtmqv14isgw-02

Aramox Mini Fridge USB Refrigerator User Manual

Model: Aramoxtmqv14isgw-02

Introduction Safety Information Package Contents Product Overview Setup Operation Maintenance Troubleshooting Specifications

1. Introduction

Thank you for choosing the Aramox Mini Fridge USB Refrigerator. This compact and portable device is designed to keep your beverages cool or warm, making it ideal for various settings such as camping, car travel, outdoor picnics, RVs, boats, and trucks. This manual provides essential information for the safe and efficient use of your mini fridge.

2. Safety Information

- Read all instructions before using the appliance.
- Do not immerse the unit in water or other liquids.
- Keep the appliance away from direct sunlight and heat sources.
- Ensure proper ventilation around the unit to prevent overheating.
- Use only the provided USB cable for power.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support if issues arise.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Package Contents

Please check the package for the following items:

- Aramox Mini Fridge USB Refrigerator (Black)
- USB Power Cable with On/Off Switch
- User Manual (this document)

4. Product Overview

The Aramox Mini Fridge is a compact and versatile device designed for personal use. It features a USB power interface for convenient plug-and-play operation and can both cool and warm contents.





Figure 4.1: Front view of the Aramox Mini Fridge USB Refrigerator.



Figure 4.2: Dimensions of the Aramox Mini Fridge USB Refrigerator (approx. 19.4 x 9 x 9 cm).



Figure 4.3: Interior view of the Aramox Mini Fridge USB Refrigerator with the door open.

5. Setup

1. **Unpack:** Carefully remove the mini fridge and all accessories from the packaging.
2. **Placement:** Place the mini fridge on a stable, flat surface. Ensure there is adequate space around the unit for ventilation. Avoid placing it near heat sources or in direct sunlight.

3. **Connect Power:** Insert the USB plug of the provided power cable into a compatible USB port (e.g., computer, car USB adapter, power bank).
4. **Power On:** Locate the On/Off switch on the USB cable and slide it to the "On" position. The unit will begin to operate.



Figure 5.1: Connecting the USB power cable to the mini fridge.

6. Operating Instructions

The Aramox Mini Fridge offers both cooling and warming functions. The operation is straightforward:

- **Cooling Function:** When the unit is powered on, it will automatically begin to cool. For optimal cooling performance, place pre-chilled beverages inside. The unit can reduce the temperature by approximately 8.5 degrees Celsius within 5 minutes.
- **Warming Function:** This model is designed to maintain the temperature of warm items. Place pre-warmed items inside to keep them hot. The unit does not actively heat cold items to a high temperature.
- **Capacity:** The internal clearance is approximately 80x80x140mm (3.15x3.15x5.51 inches), suitable for a single standard beverage can or small items.
- **Power Control:** Use the On/Off switch on the USB cable to turn the unit on or off.

Important: This mini fridge is designed for portability and convenience, not as a primary refrigeration unit. Performance may vary based on ambient temperature and power source.

7. Maintenance

- **Cleaning:** Disconnect the power before cleaning. Wipe the interior and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** When not in use for extended periods, ensure the unit is clean and dry. Store it in a cool, dry place away from direct sunlight.
- **Ventilation:** Regularly check that the ventilation grilles at the back and bottom of the unit are free from dust and obstructions.

8. Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	• USB cable not properly connected. • On/Off switch is in "Off" position. • USB power source is not providing power.	• Ensure USB cable is securely plugged into both the fridge and the power source. • Slide the On/Off switch to the "On" position. • Try a different USB port or power adapter.
Unit is not cooling/warming effectively.	• Poor ventilation. • Ambient temperature is too high. • Door is not closed properly. • Contents were not pre-chilled/warmed.	• Ensure clear space around the ventilation grilles. • Use in a cooler environment if possible. • Check that the door is securely latched. • For best results, place pre-chilled or pre-warmed items inside.
Unusual noise from the unit.	• Unit is not on a flat surface. • Fan obstruction.	• Place the unit on a stable, flat surface. • Check for any obstructions near the fan. If the noise persists, discontinue use and contact support.

9. Specifications

Feature	Detail
Brand	Aramox
Model	Aramoxtmqv14isgw-02
Color	Black
Power Source	USB
Function	Cooling & Warming
Product Dimensions	Approx. 3.54 x 3.54 x 7.64 inches (9 x 9 x 19.4 cm)
Internal Clearance	Approx. 3.15 x 3.15 x 5.51 inches (80 x 80 x 140 mm)
Item Weight	Approx. 1.05 pounds (0.48 kg)
Cooling Performance	Temperature reduction by 8.5°C in 5 minutes (approx.)
Material	Plastic

10. Warranty Information

Aramox products are built to meet standard specifications and undergo strict factory quality control. For specific warranty details, please refer to the documentation provided with your purchase or contact Aramox customer support. Keep your proof of purchase for warranty claims.

11. Customer Support

If you encounter any issues or have questions regarding your Aramox Mini Fridge USB Refrigerator, please contact Aramox customer support through the retailer where you purchased the product or visit the official Aramox store on Amazon:

Visit the Aramox Store on Amazon

© 2025 Aramox. All rights reserved.