

PARTPHONER PAFP073AB1

PARTPHONER PAFP073AB1 Floor Lamp User Manual

Model: PAFP073AB1

1. INTRODUCTION

Thank you for purchasing the PARTPHONER PAFP073AB1 Floor Lamp. This modern, adjustable floor lamp is designed to provide versatile lighting for various spaces such as living rooms, bedrooms, offices, and kids' rooms. Please read this manual carefully before assembly and use to ensure proper operation and safety.

Safety Information

- Ensure the power is disconnected before assembly, installation, or maintenance.
- This lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Use only E26 base bulbs. Do not exceed the maximum wattage specified for the bulb socket.
- Keep the lamp away from flammable materials.
- Do not attempt to modify the lamp in any way. Any modifications may void the warranty and pose a safety risk.
- If the power cord is damaged, it must be replaced by the manufacturer or a qualified service agent to avoid hazards.

2. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Lamp Head with Pole Sections
- Sturdy Round Base
- Foot Switch Power Cord
- User Manual



Figure 2.1: Overview of lamp components including the lamp head, pole, base, and foot switch.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your PARTPHONER Floor Lamp:

1. **Attach Pole Sections:** Carefully screw the pole sections together clockwise until they are securely tightened. Ensure the power cord runs freely through the pole.
2. **Connect to Base:** Screw the assembled pole onto the sturdy round base clockwise until it is firm and stable.
3. **Install Bulb:** Ensure the lamp is unplugged. Screw an E26 base bulb (not included) into the lamp head socket clockwise until it is snug. Do not overtighten.

Suitable for E26 Bulbs

Note: Bulb is Not Included in The Package



Figure 3.1: Proper installation of an E26 bulb into the lamp socket.

4. **Plug In:** Insert the power plug into a standard 120V AC wall outlet.

4. OPERATING INSTRUCTIONS

Your PARTPHONER Floor Lamp is designed for ease of use and flexible lighting.

Foot Switch Operation

- To turn the lamp ON, gently press the foot switch located on the power cord.
- To turn the lamp OFF, press the foot switch again.
- The lamp is also compatible with wall switches. Ensure the foot switch is in the 'ON' position if using a wall switch.

Adjusting the Lamp Head

The lamp head features an adjustable design to direct light where needed.

- The lamp head can rotate horizontally up to 350°.

- The lamp head can tilt vertically up to 90°.
- Gently adjust the lamp head to your desired angle. Avoid excessive force to prevent damage.



Figure 4.1: Adjustable lamp head showing horizontal and vertical movement ranges.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your floor lamp.

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down completely. Unscrew the old bulb counter-clockwise and replace it with a new E26 base bulb.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.

6. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	<ol style="list-style-type: none"> 1. Power cord not plugged in. 2. Bulb is loose or faulty. 3. Foot switch is off. 4. Power outlet is not working. 	<ol style="list-style-type: none"> 1. Ensure the power cord is securely plugged into a working outlet. 2. Tighten or replace the E26 bulb. 3. Press the foot switch to turn the lamp on. 4. Test the outlet with another device.
Light flickers.	<ol style="list-style-type: none"> 1. Bulb is loose. 2. Bulb is incompatible or faulty. 	<ol style="list-style-type: none"> 1. Tighten the bulb. 2. Replace the bulb with a new E26 base bulb.
Lamp head is difficult to adjust.	Mechanism may be stiff.	Apply gentle, even pressure. Do not force the adjustment. If persistent, contact support.

If the problem persists after trying these solutions, please contact PARTPHONER customer support.

7. SPECIFICATIONS

Feature	Specification
Model Number	PAFP073AB1
Brand	PARTPHONER
Material	Metal
Finish Type	Matte
Color	Black
Product Dimensions (D x W x H)	34D x 34W x 160H centimetres
Item Weight	3.45 kg
Bulb Base	E26
Switch Type	Foot Switch
Voltage	120 Volts (AC)
Indoor/Outdoor Usage	Indoor



Figure 7.1: Key dimensions of the PARTPHONER PAFP073AB1 Floor Lamp.

8. WARRANTY INFORMATION

PARTPHONER products are manufactured to high-quality standards. For specific warranty details regarding your PAFP073AB1 Floor Lamp, please refer to the warranty card included with your purchase or visit the official PARTPHONER website. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your PARTPHONER PAFP073AB1 Floor Lamp, please contact our customer support team. Contact information can typically be found on the product packaging, the official PARTPHONER website, or through your retailer.