

[manuals.plus](#) /

› [Vandlion](#) /

› [Vandlion A32 Full 1080P HD Body Worn Camera User Manual](#)

**Vandlion A32**

# **Vandlion A32 Full 1080P HD Body Worn Camera User Manual**

Model: A32

## **1. INTRODUCTION**

Thank you for choosing the Vandlion A32 Full 1080P HD Body Worn Camera. This compact and versatile device is designed for various applications, including body-worn recording for security personnel, sports activities, and in-car video capture. It features 1080P Full-HD video recording, a 180-degree rotatable lens, and support for external MicroSD/TF cards.



Image 1: The Vandlion A32 camera is suitable for various uses, including sports and professional body-worn applications.

## 2. PRODUCT OVERVIEW

---

Familiarize yourself with the camera's components and controls.



Image 2: Front and side view of the Vandlion A32 camera, highlighting the lens, screen, and control buttons.

## 2.1 Camera Components

- **180° Rotatable Lens:** Allows for flexible recording angles.
- **Display Screen:** For live view, playback, and menu navigation.

- **Control Buttons:** Power, Record, Audio Save, Playback, Menu, Navigation, Volume.
- **MicroSD Card Slot:** For external memory storage.
- **USB Port:** For charging and data transfer.
- **Integrated Clip:** For attaching the camera to clothing or gear.



Image 3: Rear view of the Vandlion A32 camera, illustrating the integrated clip for secure attachment.

### 3. SETUP

#### 3.1 Charging the Camera

Before first use, fully charge the camera. Connect the camera to a USB power adapter or a computer's USB port using the provided USB cable. The charging indicator will show the charging status. A full charge typically takes approximately 3 hours.

### 3.2 Inserting a MicroSD Card

The Vandlion A32 does not have built-in memory and requires an external MicroSD/TF card for recording. It supports cards up to 128GB. Ensure the camera is powered off before inserting or removing the memory card.

1. Locate the MicroSD card slot on the side of the camera.
2. Gently insert the MicroSD card into the slot with the gold contacts facing down until it clicks into place.
3. To remove, push the card in slightly until it springs out.



Image 4: The camera connected to a laptop for charging and file transfer, also illustrating the MicroSD card slot.

## 4. OPERATING THE CAMERA

## 4.1 Power On/Off

Press and hold the Power button to turn the camera on or off.

## 4.2 Recording Video

Press the 'SAVE=VIDEO' button to start video recording. Press it again to stop and save the recording.

## 4.3 Recording Audio Only

Press the 'AUDIO=SAVE' button to start audio-only recording. Press it again to stop and save the audio file.

## 4.4 Taking Photos

While in standby mode, press the designated photo button (if available, or refer to on-screen menu) to capture a still image.

## 4.5 Playback

Use the 'PLAY' button to enter playback mode. Use 'PREV' and 'NEXT' buttons to navigate through recorded files. Adjust volume with 'VOL+' and 'VOL-' buttons.

## 4.6 Menu Navigation

Press the 'MENU' button to access camera settings. Use the navigation buttons to scroll and select options.

## 4.7 180° Rotatable Lens

The camera features a lens that can be manually rotated 180 degrees to capture footage from different angles without repositioning the entire device.

# 180° Rotatable Lens



Image 5: Illustration of the camera's 180-degree rotatable lens, allowing for flexible recording perspectives.

## 5. FILE TRANSFER & PC CAMERA MODE

To transfer files or use the camera as a PC webcam:

1. Connect the camera to your computer using the USB cable.
2. The camera will appear as a removable disk drive on your computer. You can then access, copy, or delete recorded files.
3. Some operating systems may prompt you to select a mode (e.g., Mass Storage or PC Camera). Select 'PC Camera' to use it as a webcam.

## 6. MAINTENANCE

- Keep the camera clean. Use a soft, dry cloth to wipe the body.
- For the lens, use a specialized lens cleaning cloth.
- Avoid exposing the camera to extreme temperatures, direct sunlight, or moisture.
- Do not attempt to disassemble the camera, as this will void the warranty.

## 7. TROUBLESHOOTING

---

### 7.1 Camera Not Turning On

- Ensure the battery is charged. Connect to a power source and allow it to charge for at least 30 minutes before attempting to power on.
- If unresponsive, try pressing the 'Reset' button (if available, often a small pinhole).

### 7.2 Cannot Record

- Check if a MicroSD card is properly inserted.
- Ensure the MicroSD card has sufficient free space.
- Format the MicroSD card (via camera menu or computer) if it's a new card or experiencing issues.

### 7.3 Poor Video Quality

- Ensure the lens is clean and free from smudges.
- Check lighting conditions.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	A32
High Definition Support	1080P (Full-HD)
Sensor Technology	CMOS
Memory Card Type	MicroSD / TF
Max Memory Card Support	Up to 128GB
Charging Time	Approx. 3 hours
Recording Time	Up to 10 hours (estimated)
Lens Rotation	180 degrees
Certifications	CE, FCC
Material	Other
Included Components	Memory Card (if purchased with 64GB TF Card option)

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

This product comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures a full refund or replacement for eligible issues.

### 9.2 Customer Support

If you encounter any problems or have questions regarding your Vandlion A32 camera, please do not hesitate to contact our customer support. We are committed to replying to your inquiries within 24 hours.

For support, please refer to the contact information provided with your purchase or on the product's official sales page.

© 2023 Vandlion. All rights reserved.

### Related Documents - A32

<p>Digital Mini Camera</p>  <p>User's Manual</p>	<p><a href="#">Vandlion A22 Digital Mini Camera User Manual</a></p> <p>User manual for the Vandlion A22 digital mini camera, detailing its features, operation, settings, troubleshooting, and technical specifications.</p>
<p>Digital voice recorder</p>  <p>V11 Digital Voice Recorder Manual Before using product please read the manual carefully</p>	<p><a href="#">V11 Digital Voice Recorder User Manual</a></p> <p>Comprehensive user manual for the V11 Digital Voice Recorder by Vandlion, covering setup, operation, features, settings, troubleshooting, and specifications.</p>

<p>Digital Voice Recorder</p>  <p>User Manual</p>	<p><a href="#"><u>Vandlion V90C Digital Voice Recorder User Manual</u></a></p> <p>Comprehensive user manual for the Vandlion V90C digital voice recorder, covering setup, operations, settings, troubleshooting, and technical specifications for reliable audio capture.</p>
<p>Voice Recorder</p>  <p>User Manual</p>	<p><a href="#"><u>Vandlion Voice Recorder User Manual - Features, Operation, and Specifications</u></a></p> <p>Comprehensive user manual for the Vandlion voice recorder. Learn about its features, operating instructions, settings, troubleshooting, and technical specifications.</p>
<p>Digital voice recorder</p>  <p>User Manual</p>	<p><a href="#"><u>Vandlion V13 Digital Voice Recorder User Manual</u></a></p> <p>User manual for the Vandlion V13 digital voice recorder, detailing its features, operation, specifications, and troubleshooting guide.</p>
 <p>User Manual</p>	<p><a href="#"><u>Vandlion X19 Digital Media Player User Manual</u></a></p> <p>Comprehensive user manual for the Vandlion X19 digital media player, covering features, operation, troubleshooting, and technical specifications. Learn how to use music playback, video, e-books, voice recording, FM radio, and more.</p>