

Acer OMR050

Acer OMR050 Rechargeable Dual Bluetooth and 2.4G Wireless Mouse User Manual

Model: OMR050

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Acer OMR050 Rechargeable Dual Bluetooth and 2.4G Wireless Mouse. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Acer OMR050 Wireless Mouse
- USB Charging Cable
- 2.4G USB Receiver (typically stored inside the mouse)
- User Manual (this document)



Image: The Acer OMR050 wireless mouse shown next to its retail packaging. The packaging displays the Acer logo and mouse outline.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Acer OMR050 mouse:

- **Left Button:** Standard click function.
- **Right Button:** Standard right-click function.
- **Scroll Wheel:** For vertical scrolling and middle-click.
- **DPI Button:** Adjusts cursor sensitivity (DPI).

- **Mode Switch/Connect Button:** Switches between 2.4G and Bluetooth modes, and initiates Bluetooth pairing.
- **USB Charging Port:** For recharging the internal battery.
- **2.4G USB Receiver Slot:** Storage for the USB receiver when not in use.



Image: The underside of the Acer OMR050 mouse, revealing the slot for the 2.4G USB receiver and the mode switch.

SETUP

2.4G Wireless Connection

1. Locate the 2.4G USB receiver, usually stored in a compartment on the underside of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse using the power switch (if present) or ensure it is in 2.4G mode (indicated by a specific LED color or position on the mode switch).
4. Your computer should automatically detect and install the necessary drivers. The mouse will be ready for use.

Bluetooth Connection

1. Ensure your computer's Bluetooth function is enabled.
2. Switch the mouse to Bluetooth mode using the mode switch. An indicator light will typically flash, signifying pairing mode.
3. On your computer, go to Bluetooth settings and search for new devices.
4. Select "Acer OMR050" (or similar name) from the list of available devices to pair.
5. Once paired, the indicator light on the mouse will stop flashing and remain solid, or turn off. The mouse is now ready for use.

OPERATING INSTRUCTIONS

DPI Adjustment

Press the DPI button (usually located behind the scroll wheel) to cycle through different cursor sensitivity levels. This allows you to adjust the mouse speed to your preference.

Mode Switching

Use the mode switch on the underside of the mouse to toggle between 2.4G wireless and Bluetooth connectivity. This is useful for connecting to multiple devices.

CHARGING

The Acer OMR050 mouse features a built-in rechargeable battery.

1. When the battery is low, an indicator light on the mouse may flash or change color.
2. Connect the provided USB charging cable to the charging port on the front of the mouse.
3. Plug the other end of the USB cable into a powered USB port on your computer or a USB wall adapter.
4. The indicator light will typically show charging status (e.g., solid red while charging, off or green when fully charged).
5. A full charge usually takes a few hours. Avoid overcharging by disconnecting the cable once fully charged.



Image: The Acer OMR050 mouse with a USB charging cable connected to its front port, illustrating the charging process.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store the 2.4G USB receiver inside the mouse's designated slot to prevent loss.
- **Battery Care:** To prolong battery life, avoid fully discharging the mouse frequently. Recharge when the low battery indicator appears.

TROUBLESHOOTING

Problem	Solution
Mouse not responding (2.4G)	<ol style="list-style-type: none">1. Ensure the USB receiver is securely plugged into a working USB port.2. Check if the mouse is turned on and in 2.4G mode.3. Recharge the mouse battery.4. Try a different USB port or computer.
Mouse not responding (Bluetooth)	<ol style="list-style-type: none">1. Ensure the mouse is in Bluetooth mode and pairing mode is active.2. Verify Bluetooth is enabled on your computer.3. Remove the mouse from your computer's Bluetooth device list and re-pair it.4. Recharge the mouse battery.
Cursor movement is erratic or slow	<ol style="list-style-type: none">1. Clean the optical sensor on the underside of the mouse.2. Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).3. Adjust the DPI setting using the DPI button.4. Recharge the mouse battery.

SPECIFICATIONS

Brand	Acer
Model	OMR050
Connectivity Technology	Bluetooth, 2.4G Wireless
Movement Detection Technology	Laser, Optical
Special Features	Rechargeable, Wireless
Compatible Devices	Laptop, Personal Computer
Operating Systems	Linux, Windows XP (and newer)
Power Source	Battery Powered (Lithium)
Battery Average Life	3 months (approx.)
Hand Orientation	Right
Rated Voltage/Current	3.7V / ~5mA
Buttons	3 keys
Resolution	1000DPI

Note: Specifications are subject to change without prior notice.

WARRANTY AND SUPPORT

Acer products are backed by a limited warranty. For detailed warranty information, technical support, or service inquiries, please visit the official Acer website or contact Acer customer service in your region. Please retain your proof of purchase for warranty claims.
For further assistance, please visit: www.acer.com/support