LSC Smart Connect Video Doorbell

LSC Smart Connect Video Doorbell User Manual

Model: LSC Smart Connect Video Doorbell

1. INTRODUCTION

Thank you for choosing the LSC Smart Connect Video Doorbell. This device provides enhanced home security and convenience by allowing you to see, hear, and speak to visitors from anywhere using your smartphone. It features motion detection, two-way audio, and a clear video feed, ensuring you never miss a visitor or important delivery. Please read this manual thoroughly before installation and use to ensure proper operation and safety.

2. SAFETY INFORMATION

- Ensure the installation location is secure and stable.

- Do not expose the device to extreme temperatures, direct sunlight, or excessive moisture.

- Use only the specified power adapter and batteries. Incorrect power sources may damage the device or cause fire.

- Keep the device away from children and pets.

- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.

- Dispose of batteries according to local regulations. Do not incinerate batteries.

3. PACKAGE CONTENTS

Please check the package for the following items:

- LSC Smart Connect Video Doorbell Unit

- Indoor Chime Unit

- USB-C Charging Cable

- Mounting Screws and Wall Anchors

- Rechargeable Batteries (2x)

- User Manual (this document)

4. PRODUCT OVERVIEW

4.1 Video Doorbell Unit

Image: Front view of the LSC Smart Connect Video Doorbell, showcasing its sleek black design within a protective grey housing. The camera lens, motion sensor, and main doorbell button with a bell icon are clearly visible.

- **Camera Lens:** Captures video footage.

- **Motion Sensor (PIR):** Detects movement in front of the doorbell.

- **Microphone:** Captures audio for two-way communication.

- **Speaker:** Outputs audio for two-way communication.

- **Doorbell Button:** Activates the chime and sends a notification to your smartphone.

- **LED Indicator:** Shows device status (e.g., charging, connected, motion detected).

4.2 Indoor Chime Unit

Image: Front view of the LSC Smart Connect Indoor Chime Unit, a compact black device with three circular buttons. The top button features a music note icon, the middle button has a speaker icon with a blue LED ring, and the bottom button has a play/pause icon.

- **Speaker:** Emits the doorbell sound.

- **Melody Button:** Cycles through available chime melodies.

- **Volume Button:** Adjusts the chime volume.

- **Pairing Button:** Used to pair the chime with the doorbell unit.

5. SETUP

5.1 Charging and Inserting Batteries

Image: Two blue cylindrical rechargeable batteries, likely 18650 type, shown on a white background. These batteries power the video doorbell unit.

1. Fully charge the provided rechargeable batteries using the USB-C cable and a compatible USB power adapter (not included). The LED indicator on the doorbell will show charging status.

2. Open the battery compartment on the back of the doorbell unit.

3. Insert the two charged batteries, ensuring correct polarity (+/-).

4. Close the battery compartment securely.

5.2 Mounting the Video Doorbell

Image: Rear view of the LSC Smart Connect Video Doorbell's mounting plate, showing the screw holes and the ABS plastic material marking. This plate is used to securely attach the doorbell to a wall.

1. Choose a suitable location near your door, ensuring a clear view and good Wi-Fi signal.

2. Use the mounting plate as a template to mark drill holes on the wall.

3. Drill holes and insert wall anchors if necessary.

4. Secure the mounting plate to the wall using the provided screws.

5. Attach the video doorbell unit to the mounting plate, ensuring it clicks into place securely.

Image: The LSC Smart Connect Video Doorbell is shown installed on a brick wall, positioned to the right of a dark wooden front door with ornate metalwork. This image demonstrates a typical installation scenario.

5.3 Pairing the Indoor Chime

Image: The LSC Smart Connect Video Doorbell unit and its corresponding indoor chime unit are displayed side-by-side. The doorbell is on the left, and the chime, which plugs into a wall outlet, is on the right.

1. Plug the Indoor Chime Unit into a standard wall outlet within range of the doorbell.

2. Press and hold the pairing button on the chime unit until its LED indicator flashes.

3. Press the doorbell button on the video doorbell unit. The chime should ring, indicating successful pairing.

4. If pairing fails, repeat the steps.

Image: Side view of the LSC Smart Connect Indoor Chime Unit, showing its integrated power plug designed for direct insertion into a wall socket. This highlights its compact and plug-and-play design.

5.4 App Connection (LSC Smart Connect App)

Download the "LSC Smart Connect" app from your smartphone's app store (iOS or Android). Follow the in-app instructions to add your new video doorbell. This typically involves creating an account, selecting "Add Device," choosing the doorbell category, and following prompts to connect to your home Wi-Fi network.

6. OPERATING INSTRUCTIONS

6.1 Answering a Doorbell Call

- When a visitor presses the doorbell button, your indoor chime will ring, and you will receive a push notification on your smartphone.

- Tap the notification to open the LSC Smart Connect app and view the live video feed.

- Use the microphone icon in the app to enable two-way audio and speak with your visitor. Tap again to mute.

- You can also take screenshots or record video directly from the live view.

6.2 Motion Detection

- The doorbell's PIR sensor detects motion in its field of view.
- When motion is detected, you will receive a notification on your smartphone.
- You can adjust motion sensitivity and detection zones within the LSC Smart Connect app settings to minimize false alerts.

6.3 Chime Settings

- **Melody Selection:** Press the melody button on the indoor chime unit to cycle through different ringtones.
- **Volume Adjustment:** Press the volume button on the indoor chime unit to increase or decrease the volume.

7. MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the doorbell lens and body. Do not use abrasive cleaners or solvents.
- **Battery Care:** Recharge batteries when the app indicates low battery. Avoid fully draining batteries frequently to prolong their lifespan.
- **Firmware Updates:** Periodically check the LSC Smart Connect app for available firmware updates for your doorbell to ensure optimal performance and security.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Doorbell not powering on.	Batteries are dead or incorrectly inserted.	Recharge batteries fully. Ensure batteries are inserted with correct polarity.
Indoor chime not ringing.	Chime not paired or out of range.	Ensure chime is plugged in. Re-pair the chime with the doorbell. Move chime closer to the doorbell.
Poor video quality or no video.	Weak Wi-Fi signal; dirty camera lens.	Ensure strong Wi-Fi signal at doorbell location. Clean camera lens with a soft cloth.
App not receiving notifications.	App permissions not enabled; network issues.	Check app notification settings on your phone. Ensure doorbell is connected to Wi-Fi. Restart doorbell and router.

9. SPECIFICATIONS

Feature	Detail
Model	LSC Smart Connect Video Doorbell
Manufacturer	Mopro

Feature	Detail
ASIN	B0CC427RH6
Connectivity	Wi-Fi (2.4GHz)
Power Source	Rechargeable Batteries (2x, type 18650 implied)
Chime Power	AC 100-240V (Plug-in)
Camera Resolution	HD (e.g., 1080p, common for such devices, not specified in input)
Motion Detection	PIR Sensor
Two-Way Audio	Supported
App Compatibility	LSC Smart Connect (iOS & Android)

10. WARRANTY AND SUPPORT

This LSC Smart Connect Video Doorbell comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official LSC Smart Connect website.

For technical support, troubleshooting assistance, or any product-related inquiries, please contact the manufacturer's customer service. Contact information can typically be found on the product packaging, the official website, or within the LSC Smart Connect application.

Related Documents - **LSC Smart Connect Video Doorbell**

[LSC Smart Connect Video Doorbell: Setup and User Guide](#)
Learn how to set up and use your LSC Smart Connect video doorbell. This guide provides step-by-step instructions for installation, app setup, pairing, and safety information for the LSC Smart Connect video doorbell.

LSC Smart Connect Battery-Powered Video Doorbell User Manual
Comprehensive guide to installing, setting up, and using the LSC Smart Connect battery-powered video doorbell. Learn about features, troubleshooting, and specifications for model 5525000800.

LSC Smart Connect 5525000800 Video Doorbell User Manual
Comprehensive user manual for the LSC Smart Connect 5525000800 video doorbell, covering installation, setup, features, and troubleshooting. Enhance your home security and convenience with smart, connected technology.

LSC Smart Connect Video Doorbell User Manual
User manual and setup guide for the LSC Smart Connect Video Doorbell (Art. code 3209705), detailing installation, app setup, safety information, and compliance.

Ring Playbook: Ontdek Slimme Deurbellen, Camera's en Beveiligingssystemen
Verken het Ring Playbook voor een uitgebreid overzicht van Ring's slimme deurbellen, beveiligingscamera's, Ring Alarm en accessoires. Leer hoe Ring je huis veiliger maakt.

LSC Smart Connect Doorbell Quick Guide
Quick guide for the LSC Smart Connect Doorbell, covering setup, features, and installation. Learn how to connect your smart doorbell to your WiFi network and get started.