


WLIVE ADSG036DHS



INTRODUCTION

This user manual provides comprehensive instructions for the assembly, operation, and maintenance of your WLIVE Mid-Century TV Stand. Designed for TVs up to 55 inches, this entertainment center offers spacious storage and a durable structure, enhancing your living space with both functionality and style. Please read this manual thoroughly before beginning assembly or use to ensure safe and proper handling of the product.

SAFETY INFORMATION

For safe use and to prevent injury or damage, please adhere to the following guidelines:

- **Weight Limit:** Do not exceed the maximum weight limit of 110 lbs (50 kg) on the top surface of the TV stand. Overloading can cause structural failure and potential injury.
- **Assembly:** Follow all assembly instructions carefully. Ensure all fasteners are securely tightened before use.
- **Adjustable Shelves:** Exercise caution when adjusting shelves to avoid pinching fingers. Ensure shelves are properly seated on their supports.
- **Stability:** Place the TV stand on a flat, level, and stable surface. Uneven surfaces can lead to instability and tipping.
- **Children and Pets:** Keep small children and pets away from the product during assembly. Do not allow children to climb or play on the TV stand.
- **Ventilation:** Ensure adequate ventilation around electronic devices placed within the stand's compartments to prevent overheating.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Engineered Wood Panels (Top, Bottom, Side, Back, Shelves, Cabinet Door)
- Tapered Angled Legs (x5)
- Hardware Pack (Screws, Dowels, Cam Locks, Hinges, Shelf Pins, Cable Management Grommets)
- Assembly Tools (Hex Key/Allen Wrench, Screwdriver - typically included or required)

- Instruction Manual (This document)

SETUP AND ASSEMBLY

This TV stand is designed for easy assembly. Each part is numbered, and a detailed installation manual is included with the product. Please follow the step-by-step instructions provided in the separate assembly guide for optimal results.

1. **Unpack:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches.
2. **Identify Parts:** Match each part to its corresponding number in the assembly guide.
3. **Assemble Frame:** Begin by assembling the main frame of the TV stand according to the diagrams.
4. **Install Shelves:** Insert shelf pins into the desired height for the adjustable shelves.
5. **Attach Legs:** Securely attach the tapered angled legs to the base of the stand. Ensure the central support leg is also installed for added stability.
6. **Install Cabinet Door:** Attach the cabinet door using the provided hinges. Ensure it opens and closes smoothly.
7. **Cable Management:** Utilize the pre-drilled cable holes in the back panels to route and organize your electronic device cables.
8. **Final Check:** Double-check all connections and fasteners to ensure they are tight and secure before placing any items on the stand.

PRODUCT SIZE

110
lbs

Max Weight Capacity



Figure 1: Product Dimensions and Weight Capacity. This diagram illustrates the overall dimensions of the TV stand and its maximum load capacity.



Figure 2: Adjustable Shelf Mechanism. The shelves can be adjusted to three different height levels to accommodate various items.



Figure 3: Stable Structure and Support. The TV stand features a robust design with a central support leg for enhanced stability, suitable for televisions up to 55 inches.

OPERATING INSTRUCTIONS

The WLIVE TV Stand is designed for versatile use in your living room or bedroom.

- **TV Placement:** Place your television centrally on the top surface. Ensure the TV base fits within the dimensions of the stand.
- **Open Storage:** Utilize the open shelves for media devices such as game consoles, soundbars, or streaming boxes. These shelves also provide space for decorative items, books, or small plants.
- **Hidden Storage:** The enclosed cabinet provides discreet storage for items you wish to keep out of sight, such as DVDs, remote controls, or other accessories.
- **Cable Organization:** Route power cords and signal cables through the designated cable holes at the back of each compartment to maintain a tidy and organized appearance.



AMPLE STORAGE SPACE

Figure 4: Ample Storage Space. The stand features both open shelving and a spacious enclosed cabinet for diverse storage needs.

Your browser does not support the video tag.

Video 1: WLIVE TV Stand Overview. This video provides a general overview of the TV stand's features and design.

Your browser does not support the video tag.

Video 2: WLIVE TV Stand Features. This video highlights specific features of the TV stand, including storage and cable management.

MAINTENANCE

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the laminate finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage or staining.
- **Dusting:** Regularly dust with a soft, dry cloth to prevent buildup.

- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.



Figure 5: Easy Cleaning Design. The elevated design with 5.9-inch feet allows for convenient cleaning underneath the stand.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stand is wobbly/unstable.	Uneven floor; loose fasteners; missing support leg.	Ensure stand is on a level surface. Re-tighten all screws. Verify the central support leg is installed and making contact with the floor.
Cabinet door does not close properly.	Misaligned hinges; obstruction.	Adjust hinges as per assembly guide. Check for any items blocking the door's path.

Problem	Possible Cause	Solution
Shelves are not level.	Shelf pins not fully inserted or unevenly placed.	Ensure all shelf pins are fully inserted into the corresponding holes and are at the same height.

SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Number	ADSG036DHS
Material	Engineered Wood
Color	Rustic Brown
Product Dimensions (L x W x H)	47.44 x 15.75 x 21.81 inches
Item Weight	37.8 pounds
Maximum Load Weight	110 lbs
Number of Shelves	3 (including top surface and bottom base)
Number of Cabinets	1
TV Size Compatibility	Up to 55 inches
Special Feature	Durable, Cable Management, Adjustable Shelf

WARRANTY AND SUPPORT

WLIVE stands behind the quality of its products. For specific warranty information and customer support, please refer to the warranty card included with your purchase or visit the official WLIVE website. If you have any questions regarding assembly, missing parts, or product functionality, do not hesitate to contact WLIVE customer service for assistance. You can visit the WLIVE Store for more information: [WLIVE Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CC4PRT2F>

More documents and user manuals: <https://manuals.plus/>