

## STARSEEKER EDGE Plus

# STARSEEKER EDGE Plus Electric Coffee Grinder

## Instruction Manual

### IMPORTANT SAFEGUARDS

---

Please read all instructions carefully before using the STARSEEKER EDGE Plus Electric Coffee Grinder. Retain this manual for future reference.

- Ensure the grinder is placed on a stable, flat surface.
- Do not immerse the motor unit in water or any other liquid.
- Unplug the grinder from the power outlet when not in use, before cleaning, or when assembling/disassembling parts.
- Keep hands and utensils out of the bean hopper and grind chute during operation to prevent injury.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the grinder with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- For household use only.

### PRODUCT OVERVIEW

---

The STARSEEKER EDGE Plus Electric Coffee Grinder is designed for precision grinding with a durable aluminum body and a 63mm titanium-plated conical burr.

# PROFESSIONAL FINE GRINDING HELP 『GOLD CUP』 BIRTH



Figure 1: STARSEEKER EDGE Plus Electric Coffee Grinder. This image shows the sleek, modern design of the grinder in a silver finish, highlighting its compact footprint.

# Low speed high torque motor Fine grinding without loss of flavor



Figure 2: Key components of the grinder. This image details the 63mm octagonal conical burr, the low-speed high-torque motor, and the magnetic powder outlet, emphasizing the quality materials and design.

## Key Features:

- **63mm Octagonal Conical Burr:** Titanium-plated for durability and consistent grinding.
- **Stepless Fineness Adjustment:** Offers 60 stages of precise 0.01mm adjustments for various brewing methods.
- **Low Speed, Low Noise Motor:** Operates at 220R/Min for fine grinding without excessive heat or noise.
- **Magnetic Powder Outlet:** Removable for easy cleaning and mess-free operation.
- **Durable Construction:** Made of high-quality aluminum.

## SETUP

---

Follow these steps for initial setup of your coffee grinder.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the grinder on a clean, dry, and stable surface.
3. **Power Connection:** Connect the power cable to the grinder and then to a suitable power outlet.
4. **Assemble Powder Cup:** Ensure the magnetic powder cup is correctly attached to the grinder's outlet.

**Two colors are available**  
**The collision of black and silver**



Figure 3: The grinder set up in a kitchen. This image shows the grinder ready for use on a countertop, emphasizing its aesthetic integration into a home coffee corner.

## Setup Video:

Video 1: STARSEEKER EDGE Plus 63MM Burr Coffee Grinder. This video provides a visual guide to the initial setup and components of the grinder.

Video 2: EDGE+ Electric Coffee Bean Grinder. This video demonstrates the grinder's features and initial preparation for use.

## OPERATING INSTRUCTIONS

---

Achieve the perfect grind for your preferred coffee brewing method.

1. **Add Coffee Beans:** Open the top lid and pour your desired amount of whole coffee beans into the hopper.
2. **Adjust Fineness:** Rotate the stepless adjustment dial to select your desired grind size. Finer settings (lower numbers) are suitable for espresso, while coarser settings (higher numbers) are for pour-over or French press. The grinder offers 60 stages of precise adjustment.
3. **Start Grinding:** Press the power button to begin grinding. The low-speed motor (220R/Min) ensures fine grinding with minimal noise and heat.
4. **Collect Grounds:** The ground coffee will be dispensed into the magnetic powder cup. The magnetic attachment prevents mess and ensures quick powder collection.



Figure 4: Close-up of the fineness adjustment dial. This image highlights the stepless adjustment mechanism, allowing users to precisely control their grind size.

### **Operation Video:**

Video 3: Discovering the Coffee Grinder for Perfect Beans Every Time! This video showcases the grinder in action, demonstrating its ease of use and the quality of the grind.

Video 4: STARSEEKER EDGE Plus Coffee Grinder. This video provides a general overview of the grinder's operation and features.

## **MAINTENANCE AND CLEANING**

Proper maintenance ensures the longevity and optimal performance of your grinder.

- **Daily Cleaning:** After each use, remove the magnetic powder cup and tap out any residual grounds. Use the accompanying cleaning brush to clear the powder outlet and burrs.
- **Disassembly for Deep Cleaning:** The grinder is designed for easy installation and disassembly. Refer to the manual for detailed instructions on how to safely remove the burr set for deeper cleaning.
- **IMPORTANT: DO NOT WASH WITH WATER!** The grinder is an electrical appliance. Use only the provided brush or a dry cloth for cleaning.
- **Storage:** Store the grinder in a dry place away from direct sunlight and moisture.



Figure 5: The included cleaning brush. This brush is essential for removing coffee grounds from the burrs and chute, ensuring proper hygiene and function.

## TROUBLESHOOTING

---

If you encounter any issues with your grinder, please refer to the following common problems and solutions:

- **Grinder not turning on:** Check if the power cable is securely plugged into both the grinder and the wall outlet. Ensure the power switch is in the 'On' position.
- **Beans not grinding:** Verify that there are coffee beans in the hopper. Check if the burrs are clear of any blockages.
- **Inconsistent grind:** Ensure the burrs are clean and free from old coffee residue. Adjust the fineness setting as needed.
- **Excessive noise:** This may indicate a foreign object in the burrs or a blockage. Unplug the unit and inspect the burrs carefully.

For further assistance, please contact STARSEEKER customer support.

## SPECIFICATIONS

<b>Brand</b>	STARSEEKER
<b>Model</b>	EDGE Plus
<b>Material</b>	Aluminum
<b>Burr Type</b>	63mm Octagonal Conical Burr (Titanium Plated)
<b>Fineness Adjustment</b>	0.01mm Stepless Adjustment (60 stages)
<b>Motor Speed</b>	220 R/Min
<b>Product Dimensions</b>	5.9 x 11 x 14 inches
<b>Item Weight</b>	9 pounds
<b>Color</b>	Silver

## WARRANTY AND SUPPORT

STARSEEKER products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty covering defects in materials and workmanship from the date of purchase.

For warranty claims, technical support, or any questions regarding your STARSEEKER EDGE Plus Electric Coffee Grinder, please contact our customer service team through the retailer's platform or visit the official STARSEEKER website for contact information.