

[Manuals.plus](#) /

> [Aosom](#) /

> Aosom Kids Pedal Go Kart Adjustable Seat - Instruction Manual for Model US370-276V00BK

Aosom US370-276V00BK

Aosom Kids Pedal Go Kart Instruction Manual

Model: US370-276V00BK

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and safety warnings before assembly and use of the Aosom Kids Pedal Go Kart. Failure to follow these instructions may result in serious injury.

- **Adult Assembly Required:** This product requires adult assembly. Ensure all parts are correctly installed and secured before allowing a child to use the go kart.
- **Supervision:** Always supervise children when they are operating the go kart.
- **Protective Gear:** Ensure the child wears appropriate protective gear, including a helmet, knee pads, and elbow pads, during use.
- **Weight and Age Limits:** This go kart is suitable for children aged 5-12 years with a maximum weight capacity of 110 lbs (50 kg). Do not exceed these limits.
- **Operating Environment:** Use the go kart on flat, even surfaces away from traffic, steep inclines, swimming pools, or other hazards.
- **Braking:** Instruct the child on the proper use of the handbrake.
- **Moving Parts:** Keep hands, feet, and clothing away from moving parts, especially the wheels and pedal mechanism.

PRODUCT OVERVIEW

The Aosom Kids Pedal Go Kart is designed for active play, featuring an adjustable seat, handbrake, and durable construction. It promotes physical activity and coordination.



Image: The Aosom Kids Pedal Go Kart, black model, showcasing its overall design and structure.



Image: Multiple views of the black pedal go-kart, highlighting its sporty design and construction on a paved surface.

SETUP AND ASSEMBLY

This go kart requires assembly. Please follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all components are present and undamaged before beginning assembly.

Key Assembly Steps:

1. Unpack all components and verify against the parts list in the assembly guide.
2. Attach the wheels securely, ensuring all fasteners are tightened.
3. Install the steering column and connect it to the front axle.
4. Mount the seat and adjust it to the desired position.
5. Connect the pedal mechanism and chain. Ensure the chain has proper tension (refer to the maintenance section for chain adjustment).
6. Attach the handbrake lever and connect it to the braking mechanism.
7. Perform a final check to ensure all nuts, bolts, and screws are securely fastened and all moving parts operate smoothly.

ENCLOSED CHAIN

No exposed chain, clean appearance, safer driving



Image: Detail of the enclosed chain, which contributes to safer operation and a cleaner appearance.

OPERATING INSTRUCTIONS

Adjusting the Seat:

The go kart features a 3-position adjustable seat, allowing for a comfortable fit for children between 39.4" and 59.1" tall. To adjust the seat, locate the adjustment mechanism beneath the seat and slide it forwards or backwards up to 2.25 inches. Ensure the seat is securely locked in place before use.

3-POSITION ADJUSTABLE SEAT

Flexibly adjusted forwards or backwards



Image: Illustration demonstrating the 3-position adjustable seat, which can move forward or backward by 2.25 inches for optimal rider comfort.

Pedaling and Steering:

The go kart is powered by foot pedals. Children can steer using the steering wheel and control their speed by pedaling. The freewheel design allows the go kart to glide when pedaling stops, conserving energy. It also supports reverse drive for enhanced maneuverability.

EASY TO USE



Hand Brake



Anti-slip Foot Pedals



Image: Visual guide to the go kart's controls, including the handbrake, anti-slip pedals, and the ability to drive both forward and in reverse.

Braking:

The go kart is equipped with a handbrake for controlled stopping. Instruct the child to firmly pull the handbrake lever to engage the brakes. Practice braking in a safe, open area before regular use.

Terrain Use:

The shock-absorbing rubber wheels are designed to provide a smooth and stable ride on various surfaces, including cement, brick, gravel, and asphalt roads. Avoid excessively rough terrain or steep slopes.

RUBBER WHEELS

Suit for different road conditions



Shock Absorption



Image: Close-up of the go kart's rubber wheels, emphasizing their design for shock absorption and suitability for various road conditions.

MAINTENANCE

- **Regular Cleaning:** Clean the go kart regularly with a damp cloth. Avoid using harsh chemicals that may damage the finish or components.
- **Chain Maintenance:** Periodically check the chain tension. If the chain appears loose or frequently falls off, it may need adjustment. Refer to the assembly guide for specific instructions on how to tighten the chain. Proper chain tension ensures smooth pedaling and prevents issues.
- **Tire Pressure:** Ensure tires are adequately inflated according to the recommended pressure (if applicable, check tire sidewall for details).
- **Fastener Checks:** Regularly inspect all nuts, bolts, and screws to ensure they are tight. Re-tighten any loose fasteners to prevent accidents and ensure structural integrity.
- **Storage:** Store the go kart in a dry, covered area to protect it from weather elements when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pedals lock up or chain falls off frequently.	Loose or improperly tensioned chain.	Check chain tension and adjust as per assembly instructions. Ensure the chain is properly seated on the sprockets.
Difficulty gaining speed or lack of torque.	Incorrect chain tension, worn pedals, or operating on unsuitable terrain.	Verify chain tension. Ensure pedals are functioning correctly. Use the go kart on flat, smooth surfaces.
Steering feels locked or stiff.	Obstruction in steering mechanism, loose connections, or damaged parts.	Inspect the steering column and connections for any obstructions or loose fasteners. Ensure no parts are bent or damaged.
Go kart feels unstable or wobbly.	Loose wheel fasteners or damaged wheels/axles.	Check all wheel fasteners and ensure they are securely tightened. Inspect wheels and axles for any damage.

SPECIFICATIONS



Recommended Age:
5-12 years



Weight Limit:
110 lbs.



39.4"-59.1"



Image: Visual representation of the go kart's dimensions, including length, width, height, and seat measurements, along with recommended age and weight limits.

- **Model Number:** US370-276V00BK
- **Overall Dimensions (L x W x H):** 47.6" x 22.8" x 24" (120.9 cm x 57.9 cm x 61 cm)
- **Seat Dimensions (W x D x H):** 13.8" x 11" x 12" (35 cm x 28 cm x 30.5 cm)
- **Adjustable Seat Range:** Up to 2.25" (5.7 cm)
- **Recommended Age:** 5-12 years
- **Recommended Height:** 39.4" - 59.1" (100 cm - 150 cm)
- **Weight Capacity:** 110 lbs (50 kg)
- **Item Weight:** 30.4 lbs (13.8 kg)
- **Material:** Polypropylene
- **Included Components:** Adjustable Seat
- **Certifications:** ASTM F963, CPSIA

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Aosom customer service directly. Standard warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

If you encounter any issues not covered in the troubleshooting section or require replacement parts, please contact Aosom customer support. Have your model number (US370-276V00BK) and proof of purchase ready when contacting support.

Aosom Customer Service: Please visit the official Aosom website for contact details and support resources.

© 2024 Aosom. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CC599NRP>

More documents and user manuals: <https://manuals.plus/>