

[manuals.plus](#) /

› [IRRADIO](#) /

› [IRRADIO Universal Stretchable Rubber Remote Control Cover User Manual](#)

IRRADIO b4a28e8e-61e9-48db-94c0-19ec79488d0e

IRRADIO Universal Stretchable Rubber Remote Control Cover User Manual

Model: b4a28e8e-61e9-48db-94c0-19ec79488d0e

1. PRODUCT OVERVIEW

The IRRADIO Universal Stretchable Rubber Remote Control Cover is designed to protect your remote control from impacts, accidental drops, and general wear over time. Its elastic rubber construction provides a secure fit and acts as an effective shock absorber, extending the lifespan of your remote. This cover is compatible with a wide range of remote controls for devices such as TVs, set-top boxes, stereo systems, and air conditioners, provided they fit within the specified dimensions.

2. INSTALLATION INSTRUCTIONS

Follow these steps to properly install the protective cover on your remote control:

- 1. Prepare your remote:** Ensure your remote control is clean and dry before installation.
- 2. Insert one corner:** Gently insert one corner of your remote control into the cover.
- 3. Stretch and pull:** Carefully stretch the rubber material and pull it over the remaining parts of your remote control. Utilize the elasticity of the material, ensuring not to tear it.
- 4. Adjust for fit:** Once the remote is fully inside the cover, adjust its position to ensure a snug and even fit. The cover should not obstruct any buttons or infrared sensors.



Image 1: Top view of the IRRADIO remote control cover, highlighting its textured interior designed to enhance grip and prevent slipping.

3. USAGE AND PROTECTION

Once installed, the IRRADIO remote control cover provides continuous protection. The elastic rubber material absorbs impacts from drops and prevents scratches and scuffs from daily use. The ergonomic design also contributes to a comfortable grip.

The cover is designed to allow full functionality of your remote control, including access to all buttons and unobstructed infrared signal transmission.



Image 2: Side view of the IRRADIO remote control cover, illustrating its flexible and durable rubber construction.

4. MAINTENANCE

To ensure the longevity and cleanliness of your remote control cover:

- **Cleaning:** Wipe the cover periodically with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing and thorough drying.
- **Avoid harsh chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the rubber material.
- **Storage:** If removing the cover for extended periods, store it in a cool, dry place away from direct sunlight.

5. TROUBLESHOOTING

- **Cover does not fit:**

Ensure your remote control's dimensions are within the specified compatibility range (Width: 3.5 cm to 5.5 cm; Length: 14 cm to 19 cm). The cover is designed to stretch, but excessive stretching beyond these limits may cause damage or an improper fit.

- **Buttons are difficult to press:**

Adjust the cover's position to ensure it is not misaligned or bunched up over the buttons. The cover should sit smoothly over the remote.

- **Infrared signal is blocked:**

Verify that the cover is not obstructing the infrared emitter at the front of your remote control. The design typically accounts for this, but a misaligned cover could interfere.

6. SPECIFICATIONS

Feature	Detail
Brand	IRRADIO
Model Number	b4a28e8e-61e9-48db-94c0-19ec79488d0e
Material	Elastic Rubber
Color	Black
Product Dimensions	14 x 4 x 2 cm (approximate, unstretched)
Compatible Remote Width	3.5 cm to 5.5 cm
Compatible Remote Length	14 cm to 19 cm
Special Feature	Ergonomic, Stretchable, Protective
Compatible Devices	TV Set-top Box, Stereo System, Television, VCR remotes

7. WARRANTY AND SUPPORT

For information regarding warranty, returns, or technical support, please refer to the retailer's policy or contact IRRADIO customer service through their official channels. Specific warranty details are not provided in this manual.

