

## EUREKA ERGONOMIC ERK-HOSC-02WN-US

# EUREKA ERGONOMIC Curio Cabinet with LED Lighting and Adjustable Shelves

Model: ERK-HOSC-02WN-US

[Overview](#)

[Safety](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

## 1. PRODUCT OVERVIEW

---

The EUREKA ERGONOMIC Curio Cabinet is a versatile display and storage solution designed for various home and office environments. It features two adjustable shelves, integrated LED lighting with remote and app control, and durable tempered glass doors. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your cabinet.



Image 1.1: Front view of the EUREKA ERGONOMIC Curio Cabinet, showcasing its design and illuminated interior.

## 2. IMPORTANT SAFETY INFORMATION

**Please read all safety warnings and instructions carefully before assembly and use.**

- The product is heavy and requires caution during assembly and movement. It is recommended that two or more people handle the cabinet during assembly and relocation.
- Adjustable shelves have a maximum weight capacity of 30 lbs (13.6 kg) each. Do not overload shelves to prevent damage or injury.

- Keep cabinet keys (if applicable) and small parts out of reach of children to prevent choking hazards.
- Ensure all connections for the LED lighting system are secure and follow electrical safety guidelines. Do not expose electrical components to moisture.
- Tempered glass, while durable, can break under extreme impact. Handle glass components with care.
- For stability, ensure the cabinet is placed on a level surface. Consider using wall anchor kits (not included) for added stability, especially in homes with children or pets.

### 3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the packing list included with your product for a detailed inventory. Typically, the package includes:

- Cabinet panels (top, bottom, sides, back)
- Tempered glass doors
- Adjustable glass shelves (2 units)
- LED lighting kit (light strips, spotlights, power adapter, remote control)
- Metal legs and frame components
- Assembly hardware (screws, hinges, shelf pins, etc.)
- Instruction manual



Image 3.1: Included power adapter and remote control for the LED lighting system.

## 4. SETUP AND ASSEMBLY

---

Assembly of the EUREKA ERGONOMIC Curio Cabinet is required. Detailed instructions are provided in the included assembly guide. Please follow these steps carefully for a smooth and correct setup.

### 4.1 General Assembly Steps:

1. **Unpack and Organize:** Lay out all components on a clean, soft surface to prevent scratches. Group similar hardware.
2. **Assemble Frame:** Follow the diagrams to connect the main cabinet panels and metal frame components.
3. **Install Doors:** Attach the tempered glass doors using the provided hinges. Ensure they open and close smoothly.
4. **Install LED Lighting:** Secure the LED light strips and spotlights according to the instructions. Connect the power adapter.
5. **Insert Shelves:** Place the adjustable shelf pins at your desired height and carefully insert the glass shelves.
6. **Final Placement:** Move the assembled cabinet to its final location. Due to its weight, it is recommended to have assistance.

### 4.2 Adjustable Shelves Installation:

The cabinet includes two adjustable shelves, allowing customization of storage space. Each shelf can support up to 30 lbs.

1. Identify the pre-drilled holes on the interior sides of the cabinet.
2. Insert the shelf pins into the desired holes at equal heights on both sides.
3. Carefully slide the tempered glass shelf onto the pins, ensuring it is level and secure.
4. To adjust, simply lift the shelf, remove the pins, reposition them, and re-insert the shelf.



Image 4.1: Demonstrating the adjustment of a glass shelf within the cabinet.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 LED Lighting Control:

The integrated LED lighting system can be controlled via the included remote control or a dedicated smartphone application.

- **Power On/Off:** Use the 'ON' and 'OFF' buttons on the remote or the power toggle in the app.
- **Brightness Adjustment:** Use the brightness up/down buttons on the remote or the slider in the app to adjust light intensity (e.g., 25%, 50%, 75%, 100%).
- **Color Temperature Selection:** Choose between three color temperature options:
  - **Warm Light (3000K):** For a cozy and inviting ambiance.
  - **Neutral Light (4000K):** A balanced, natural light suitable for most displays.
  - **White Light (6000K):** Bright, crisp light for maximum visibility.
- **Spotlight Adjustment:** The three small spotlights on the top of the cabinet can be rotated 360 degrees and swung 45 degrees to direct light precisely onto specific items.

- **App Control:** Download the EUREKA ERGONOMIC lighting app (refer to the LED kit instructions for app name and QR code) to control the lights from your smartphone, offering additional customization options.




Image 5.1: Illustration of the three adjustable color temperatures for the LED lighting.

## 6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your curio cabinet.

- **Cleaning Glass Surfaces:** Use a soft, lint-free cloth and a non-abrasive glass cleaner. Spray cleaner onto the cloth, not directly onto the glass, to avoid liquid seeping into seams.
- **Cleaning Cabinet Surfaces:** Wipe wooden or metal surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that can damage the finish.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth to prevent buildup.
- **Hinge Maintenance:** The silent hinges are designed for smooth operation. If doors become stiff, a small amount of silicone-based lubricant can be applied to the hinge points (avoiding contact with wood).
- **Electrical Components:** Ensure the power adapter and LED connections remain dry and free from dust. Do not attempt to repair electrical components yourself.

## 7. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your curio cabinet.

Problem	Possible Cause	Solution
LED lights do not turn on.	Power adapter unplugged; remote control battery dead; loose connection; app not paired.	Check if the power adapter is securely plugged into an outlet and the cabinet. Replace remote control batteries. Verify all LED strip connections. Re-pair the app if necessary.
LED lights turn off unexpectedly.	Loose power connection; timer setting activated; remote interference.	Ensure all power connections are firm. Check if a timer function is active on the remote or app. Move other remote-controlled devices away.
Doors do not close smoothly or are misaligned.	Hinges not properly adjusted; cabinet not level; assembly error.	Adjust the screws on the hinges to align the doors. Ensure the cabinet is on a level surface. Review assembly instructions for correct hinge installation.
Shelves are wobbly or uneven.	Shelf pins not fully inserted; pins not at equal height; shelf overloaded.	Ensure shelf pins are fully inserted into the holes. Verify that pins on opposing sides are at the same height. Reduce weight on the shelf if it exceeds 30 lbs.
Cabinet feels unstable.	Uneven floor; loose assembly screws.	Place the cabinet on a level surface. Tighten all assembly screws. Consider using anti-tip hardware for added security.

## 8. PRODUCT SPECIFICATIONS

---

**Brand:** EUREKA ERGONOMIC

**Model Name:** Curio Cabinet

**Item Model Number:** ERK-HOSC-02WN-US

**Color:** Walnut

**Product Dimensions:** 15.7"D x 31.5"W x 47.2"H (40cm D x 80cm W x 120cm H)

**Item Weight:** Approximately 105.8 pounds (48 kg)

**Material:** Manufactured Wood, Steel, Tempered Glass

**Number of Shelves:** 2 (Adjustable)

**Shelf Weight Limit:** 30 lbs (13.6 kg) per shelf

**Special Features:** Adjustable Shelf, Scratch Resistant Tempered Glass, LED Lighting (3 color temperatures, remote/app control, 360° rotating spotlights)

**Mounting Type:** Floor Mount (Freestanding)

**Assembly Required:** Yes



Image 8.1: Detailed dimensions of the EUREKA ERGONOMIC Curio Cabinet.

## 9. WARRANTY AND CUSTOMER SUPPORT

### 9.1 Limited Warranty:

This EUREKA ERGONOMIC Curio Cabinet is covered by a **1-YEAR Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage resulting from improper assembly, misuse, accidents, or unauthorized modifications.

### 9.2 Customer Support:

For any questions, concerns, or assistance with assembly, missing parts, or warranty claims, please contact our dedicated customer service team.

#### **EUREKA ERGONOMIC Customer Service:**

- Available: 24-hour USA customer service

- Contact Information: Refer to the contact details provided in your product packaging or visit the official EUREKA ERGONOMIC website.

Please have your model number (ERK-HOSC-02WN-US) and proof of purchase ready when contacting support.

© 2025 EUREKA ERGONOMIC. All rights reserved.