

[Manuals.plus](#) /

› [Ariete](#) /

› Ariete Breakfast Blender Dark Grey 500W - Instruction Manual

Ariete 00C057603AR0

Ariete Breakfast Blender Dark Grey 500W - Instruction Manual

Model: 00C057603AR0

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Ariete Breakfast Blender. Designed for versatility, this 500W blender features 4 stainless steel blades and two speeds with a Pulse function, making it ideal for preparing smoothies, shakes, and crushing ice. Please read these instructions carefully before first use and keep them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the blender from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the blending jar while blending to prevent injury and damage to the appliance. Use a tamper only when the lid is in place.
- Ensure the lid is securely locked in place before operating the blender.
- Do not blend hot liquids, as pressure buildup can cause the lid to eject and result in burns.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children to ensure they do not play with the appliance.
- Do not operate the blender with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Place the blender on a stable, flat, and dry surface during operation.
- Avoid contact with moving parts.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Ariete Breakfast Blender:

1. Motor Base with Control Dial
2. 1.5 Liter Plastic Blending Jar
3. Blade Assembly (4 stainless steel blades)
4. Lid
5. Measuring Cup/Filler Cap (removable from lid)



Image: All components of the Ariete Breakfast Blender, including the motor base, 1.5L plastic jug, lid, and small filler cap, laid out separately.



Image: A close-up, top-down view of the blending jug, clearly showing the four stainless steel blades at the bottom.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the blending jar, lid, and filler cap in warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Assemble:**
 - Place the motor base on a clean, dry, and stable surface.
 - Ensure the blade assembly is securely fitted into the bottom of the blending jar.
 - Place the blending jar onto the motor base, aligning it correctly until it locks into position.
4. **Power Connection:** Ensure the control dial is in the "0" (off) position before plugging the blender into a 220V electrical outlet.



Image: The Ariete Breakfast Blender fully assembled with the jug on the motor base and the lid secured.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut solid ingredients into small pieces (approx. 2-3 cm). For best results, add liquids first, then soft ingredients, followed by harder ingredients and ice. Do not exceed the maximum fill line (1.5L) indicated on the blending jar.
2. **Secure Lid:** Place the lid firmly onto the blending jar. Ensure the filler cap is inserted into the lid opening.
3. **Select Speed:** Turn the control dial to your desired speed setting (1 or 2).
 - **Speed 1:** For lighter blending tasks, such as mixing soft fruits or liquids.
 - **Speed 2:** For tougher ingredients, thicker mixtures, or faster blending.
4. **Pulse Function:** For short bursts of power, turn the dial to the "P" (Pulse) position and release. This is ideal for chopping, crushing ice, or when you need more control over the blending consistency. Do not hold the Pulse function for extended periods.
5. **Blending Time:** Do not operate the blender continuously for more than 60 seconds. Allow the appliance to rest for a few minutes between cycles to prevent overheating.
6. **Adding Ingredients During Blending:** For adding ingredients while blending, remove the filler cap from the lid and carefully add items through the opening. Replace the filler cap immediately.
7. **Finish Blending:** Once desired consistency is reached, turn the control dial back to the "0" (off) position. Unplug the blender before removing the blending jar.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your blender.

1. **Unplug:** Always ensure the blender is unplugged from the power outlet before cleaning.
2. **Disassemble:** Remove the blending jar from the motor base. Carefully separate the lid and blade assembly from the jar.

3. **Jar, Lid, and Blades:** These parts are dishwasher safe. Alternatively, wash them in warm, soapy water using a brush for the blades to ensure thorough cleaning. Rinse well and dry completely. Handle blades with extreme care as they are sharp.
4. **Motor Base:** Wipe the motor base with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor base in water.
5. **Storage:** Store the assembled blender in a dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; jar not correctly seated; control dial not on a speed setting.	Check power connection; test outlet with another appliance; ensure jar is securely locked onto the base; turn dial to Speed 1 or 2.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients too large; blades jammed.	Add more liquid; reduce ingredient quantity; cut ingredients into smaller pieces; use Pulse function or stir with a non-metallic utensil (with blender off and unplugged).
Blender stops during operation.	Overheating due to continuous use or overload.	Turn off and unplug the blender. Allow it to cool down for at least 15-20 minutes. Reduce load before restarting.
Loud noise or vibration.	Jar not seated correctly; uneven surface; foreign object in jar.	Ensure jar is securely locked; place blender on a flat, stable surface; check for and remove any foreign objects (with blender off and unplugged).

TECHNICAL SPECIFICATIONS

Brand: Ariete

Model Number: 00C057603AR0

Part Number: 0576

Power: 500 Watts

Voltage: 220 Volts

Capacity: 1.5 Liters

Number of Speeds: 2 + Pulse Function

Blade Material: Stainless Steel (4 blades)

Jar Material: Plastic

Special Features: Ice Crushing Function, Anti-slip feet

Dishwasher Safe Parts: Yes (Jar, Lid, Blades)

Product Weight: 2.2 Kilograms

Color: Dark Grey

WARRANTY INFORMATION

Specific warranty details are not provided in the product information. Please refer to the warranty card included with your purchase or contact the retailer/manufacturer directly for warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Ariete Breakfast Blender, please contact Ariete customer service or your local distributor. Contact information can typically be found on the manufacturer's official website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0CC5TV1N7>

More documents and user manuals: <https://manuals.plus/>