

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ClimaTek](#) /

› [ClimaTek M222-5 Washer Drain Pump Instruction Manual](#)

ClimaTek M222-5

ClimaTek M222-5 Washer Drain Pump Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your new ClimaTek M222-5 Washer Drain Pump. This high-quality replacement part is designed to fit Frigidaire washing machines and other compatible models, directly replacing part # M222-5. Please read these instructions thoroughly before proceeding with installation or use.

The ClimaTek M222-5 Washer Drain Pump is built to last, ensuring reliable performance for your appliance.

SAFETY INFORMATION

- **Disconnect Power:** Always disconnect the washing machine from its power source before attempting any installation, maintenance, or repair. Failure to do so can result in electric shock or serious injury.
- **Shut Off Water Supply:** Turn off the water supply to the washing machine before beginning any work to prevent water damage.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and eye protection, during installation and maintenance.
- **Drain Water:** Ensure all water is drained from the washing machine before removing the old pump to avoid spills.
- **Professional Installation:** If you are unsure about any step, it is recommended to consult a qualified appliance technician.

PACKAGE CONTENTS

- 1 x ClimaTek M222-5 Washer Drain Pump

INSTALLATION INSTRUCTIONS

Follow these general steps for replacing your washing machine's drain pump. Specific steps may vary slightly depending on your washing machine model. Always refer to your appliance's service manual for detailed instructions.

1. **Prepare the Appliance:** Disconnect the washing machine from the power outlet and turn off the water

supply. Move the washing machine away from the wall to access the rear or bottom panel.

2. **Access the Pump:** Depending on your washer model, you may need to tilt the machine, remove a front access panel, or remove a rear panel to gain access to the drain pump.
3. **Drain Residual Water:** Place a shallow pan or towels under the pump area to catch any remaining water when disconnecting hoses.
4. **Disconnect Hoses and Wiring:** Carefully disconnect the inlet and outlet hoses from the old drain pump. Note their positions for reinstallation. Disconnect any electrical wiring connected to the pump.
5. **Remove Old Pump:** Unmount the old drain pump from its housing or brackets.
6. **Install New Pump:** Position the new ClimaTek M222-5 drain pump in the same location as the old one. Secure it with the appropriate screws or clips.
7. **Reconnect Components:** Reconnect the inlet and outlet hoses to the new pump, ensuring they are securely fastened to prevent leaks. Reattach the electrical wiring.
8. **Test Installation:** Restore power and water supply to the washing machine. Run a short drain cycle to check for proper operation and any leaks before pushing the machine back into place.



Image of the ClimaTek M222-5 Washer Drain Pump, showing its compact design and connection points for hoses and electrical wiring.

OPERATING INSTRUCTIONS

The ClimaTek M222-5 Washer Drain Pump operates automatically as part of your washing machine's normal cycle. Once installed correctly, no manual intervention is required for its operation. The pump will activate during the drain and spin cycles to remove water from the wash tub.

MAINTENANCE

To ensure the longevity and efficient operation of your drain pump, consider the following maintenance tips:

- **Regular Cleaning:** Periodically check the pump's filter (if accessible on your washer model) for lint, debris, or small objects that could obstruct the pump or damage its impeller. Clean as necessary.
- **Avoid Overloading:** Overloading your washing machine can put undue stress on the drain system, including the pump.
- **Inspect Hoses:** Occasionally inspect the drain hoses connected to the pump for kinks, cracks, or blockages.

TROUBLESHOOTING

If you experience issues with your washing machine's draining function, consider these common troubleshooting steps:

- **Washer Not Draining:**
 - Check for kinks or blockages in the drain hose.
 - Inspect the pump filter for debris.
 - Ensure the washing machine door/lid is properly closed and latched.
- **Slow Draining:**
 - Partial blockage in the drain hose or pump filter.
 - Check for proper vent in the drain system.
- **Unusual Noises During Drain Cycle:**
 - Small objects (coins, buttons) may be trapped in the pump impeller. Disconnect power and inspect the pump.
 - Worn bearings (less common for new pumps).

If these steps do not resolve the issue, it is advisable to contact a qualified appliance repair technician.

SPECIFICATIONS

Model Number	M222-5
Brand	ClimaTek
Product Dimensions	7 x 7 x 7 inches
Item Weight	1.81 pounds (29 Ounces)
Manufacturer	ClimaTek
Compatibility	Directly replaces Part # M222-5, fits Frigidaire and more.

WARRANTY AND SUPPORT

ClimaTek products are manufactured to high standards. For specific warranty information regarding your M222-5 Washer Drain Pump, please refer to the documentation provided with your purchase or contact ClimaTek customer support directly. Keep your proof of purchase for warranty claims.

For technical assistance or further inquiries, please visit the official ClimaTek website or contact their customer service department.

