

STF ICON

STF Icon TWS Wireless Earbuds User Manual

Model: ICON

INTRODUCTION

Thank you for choosing the STF Icon TWS Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- STF Icon TWS Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



Image: STF Icon TWS Wireless Earbuds inside their open charging case.

PRODUCT OVERVIEW

The STF Icon TWS Wireless Earbuds are designed for a comfortable in-ear fit, providing high-definition audio and Environmental Noise Cancellation (ENC) for clear calls. Each earbud features touch controls for easy management of music and calls.



Image: Close-up view of the individual STF Icon TWS Wireless Earbuds, showing their ergonomic design.

Components:

- **Earbuds:** Left and Right, with integrated microphones and touch sensors.
- **Charging Case:** Stores and charges the earbuds, with a battery indicator.
- **USB-C Port:** For charging the case.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the charging case to a power source using the provided USB charging cable.
3. The indicator light on the case will show charging status. A full charge typically takes a few hours. A 10-minute quick charge provides approximately 2 hours of playback.

2. Pairing with a Bluetooth Device

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "STF ICON" in the list of available Bluetooth devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing, and the earbud lights will turn off or flash slowly.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Gently insert each earbud into your ear canal and rotate it slightly to find a secure and comfortable fit. This ensures optimal sound quality and noise isolation.



Image: A person wearing an STF Icon TWS Wireless Earbud, demonstrating proper fit.

Touch Controls

The STF Icon earbuds feature intuitive touch controls on each earbud. Functions may vary slightly depending on the operating system of your connected device.

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (2 seconds)	Reject Call
Long Press (3 seconds)	Toggle Environmental Noise Cancellation (ENC)

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Regularly clean the ear tips and mesh to prevent wax buildup, which can affect sound quality.

Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Earbuds not pairing or connecting:

- Ensure both earbuds are charged.
- Turn off and on your device's Bluetooth.
- Forget "STF ICON" from your device's Bluetooth list and try pairing again.
- Place earbuds back in the case, close it, wait a few seconds, then open it again to reset pairing mode.

One earbud has no sound:

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then open it again. This often re-syncs them.
- Try resetting the earbuds (refer to the full manual for specific reset instructions if available).

Poor sound quality:

- Ensure the earbuds are clean and free of debris.
- Check the fit of the earbuds in your ears. A proper seal is crucial for sound quality.
- Move closer to your connected device to avoid interference.

SPECIFICATIONS

Feature	Detail
Brand	STF
Model Name	ICON
Ear Placement	In-Ear

Feature	Detail
Form Factor	In-Ear
Color	Black
Impedance	16 Ohms
Control Method	Touch
Noise Control	Environmental Noise Cancellation (ENC)
Audio Driver Type	Dynamic Driver
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Earbud Battery Life	Up to 10 Hours
Total Battery Life (with case)	Up to 40 Hours
Quick Charge	10 minutes for 2 hours playback
Compatible Devices	Bluetooth Devices
Manufacturer	Stuffactory

WARRANTY AND SUPPORT

Warranty Information

The STF Icon TWS Wireless Earbuds come with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or further inquiries, please contact STF customer support through their official website or the retailer where the product was purchased.

For more information, visit the [STF Brand Store on Amazon](#).