

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Timex](#) /

› [Timex Expedition Acadia 40mm Watch Instruction Manual](#)

Timex TW4B293009J

Timex Expedition Acadia 40mm Watch Instruction Manual

Model: TW4B293009J

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the Timex Expedition Acadia 40mm Watch, model TW4B293009J. The Expedition Acadia is a lightweight, outdoor utility watch designed for durability and ease of use. It features an INDIGLO backlight, luminescent hands, a fast wrap strap, and is water resistant to 50 meters.



Figure 1: Front view of the Timex Expedition Acadia 40mm Watch.

2. SETUP

2.1 Setting the Time

1. Pull the crown (the small knob on the side of the watch) out to position 2.
2. Turn the crown in either direction to move the hands to the correct time.
3. Push the crown back in to position 1 to start the watch.



Figure 2: Side view of the watch, showing the crown.

2.2 Adjusting the Fast Wrap Strap

The watch features a fast wrap strap for easy adjustment. Simply wrap the strap around your wrist and secure it using the hook and loop closure for a comfortable fit. Ensure the watch is snug but not too tight to allow for proper circulation.





Figure 3: Back view of the watch, illustrating the fast wrap strap.

3. OPERATION

3.1 INDIGLO Night-Light

To illuminate the watch dial in low-light conditions, press and hold the crown. The INDIGLO night-light will activate, providing even illumination across the dial for easy readability. Release the crown to turn off the light.

3.2 Water Resistance

This watch is water resistant to 50 meters (164 feet). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. To maintain water resistance, ensure the crown is fully pushed in before any contact with water. Do not operate the crown while the watch is wet or submerged.

4. MAINTENANCE

4.1 Cleaning Your Watch

To clean your watch, wipe the case and crystal with a soft, damp cloth. For the fabric strap, a mild soap solution can be used, followed by rinsing with clean water and air drying. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or water resistance seals.

4.2 Battery Replacement

The watch is powered by one Lithium Metal battery (included). When the watch stops running, the battery may need replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance. Refer to the Timex website or an authorized service center for assistance.

5. TROUBLESHOOTING

5.1 Watch Not Running

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- If the crown is in and the watch is still not running, the battery may need to be replaced.

5.2 INDIGLO Night-Light Not Activating

- Ensure you are pressing and holding the crown firmly.
- If the light still does not activate, the battery may be low or depleted.

5.3 Water Inside the Watch

- If moisture appears inside the watch, it indicates a breach in the water resistance. Immediately take the watch to an authorized service center for inspection and repair to prevent further damage.

6. SPECIFICATIONS

| Feature | Detail |
|---------------------|----------------|
| Model Number | TW4B293009J |
| Display Type | Analog |
| Watch Movement Type | Quartz |
| Case Diameter | 40 Millimeters |
| Case Thickness | 11 Millimeters |
| Band Width | 20 Millimeters |

| Feature | Detail |
|------------------------|----------------------------------------------------|
| Band Length | 8 Inches |
| Water Resistance Depth | 50 Meters (164 Feet) |
| Case Material Type | Resin |
| Band Material Type | Fabric |
| Crystal Type | Acrylic |
| Power Source | Battery Powered (1 Lithium Metal battery included) |
| Special Features | INDIGLO® night-light, Glow In The Dark hands |
| Item Weight | 0.08 Kilograms (2.65 ounces) |

7. WARRANTY & SUPPORT

7.1 Limited Warranty

This Timex watch is covered by a Limited Warranty. For specific details regarding the terms and conditions of your warranty, please refer to the warranty card included with your purchase or visit the official Timex website.

7.2 Customer Support

For further assistance, service, or to purchase replacement parts, please contact Timex customer support or visit the official Timex website. You can find contact information and service center locations on their website.

Official Timex Website: www.timex.com