

[Manuals.plus](#) /

> [Dyson](#) /

> Dyson Purifier Hot + Cool User Manual

Dyson HP07 SB

Dyson Purifier Hot + Cool User Manual

Model: HP07 SB | Brand: Dyson

1. INTRODUCTION

Welcome to the user manual for your Dyson Purifier Hot + Cool (Model: HP07 SB). This innovative device is designed to provide high-performance 3-in-1 functionality: air purification, heating, and cooling. Please read this manual thoroughly before operating your appliance to ensure safe and efficient use.



Image: The Dyson Purifier Hot + Cool, featuring a silver loop amplifier and a blue perforated base, designed for air purification, heating, and cooling.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only Dyson recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped,

damaged, left outdoors, or dropped into water, return it to a service center.

- Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters in place.
- This appliance is for household use only.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- Dyson Purifier Hot + Cool (Main Unit)
- Remote Control
- Combination Filter (HEPA and Activated Carbon)
- Power Cord
- User Manual (this document)

4. SETUP GUIDE

4.1 Unpacking

1. Carefully remove the appliance and all accessories from the packaging.
2. Retain the packaging for future storage or transport.

4.2 Installing the Filter

1. Locate the filter cover on the base of the appliance.
2. Press the release buttons on either side of the filter cover and lift it off.
3. Place the combination filter into the base, ensuring it clicks securely into place.
4. Replace the filter cover, aligning it correctly and pressing firmly until it clicks into position.

4.3 Power Connection

1. Place the appliance on a stable, level surface, ensuring adequate clearance around it for optimal airflow.
2. Insert the power cord into the power inlet at the back of the appliance.
3. Plug the other end of the power cord into a suitable wall outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button on the remote control or on the base of the appliance to turn it on or off.

5.2 Modes of Operation

- **Auto Mode:** The appliance automatically monitors air quality and adjusts airflow to maintain target air quality and temperature.
- **Purification Mode:** Cleans the air without heating or cooling. Adjust fan speed manually.
- **Heating Mode:** Heats the room to a set target temperature while purifying the air.
- **Cooling Mode:** Provides a stream of purified air for cooling, similar to a fan.

5.3 Adjusting Settings

- **Fan Speed:** Use the fan speed buttons on the remote to increase or decrease airflow.
- **Temperature:** In heating mode, use the temperature buttons to set your desired room temperature.
- **Oscillation:** Press the oscillation button to enable or disable the appliance's rotation. The oscillation angle can be adjusted.
- **Night Mode:** Activates quietest settings and dims the display.
- **Timer:** Set a sleep timer for the appliance to turn off automatically after a set period.

6. MAINTENANCE

6.1 Cleaning the Appliance

- Always unplug the appliance before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use detergents or polishes.
- Clean the air inlet holes with a soft brush to remove dust.

6.2 Filter Replacement

The appliance will display an alert when the filter needs to be replaced. Filter life varies depending on usage and air quality.

1. Unplug the appliance.
2. Press the filter release buttons and remove the filter cover.
3. Remove the old filter and dispose of it according to local regulations.
4. Unpack the new filter and install it, ensuring it clicks into place.
5. Replace the filter cover.
6. Plug in the appliance. Reset the filter life counter by holding the 'Night Mode' button on the remote for 5 seconds.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance not turning on.	Not plugged in; power outlet issue; remote control battery low.	Check power cord connection; try a different outlet; replace remote control batteries.
No airflow or weak airflow.	Air inlet blocked; filter clogged; fan speed too low.	Clean air inlets; replace filter; increase fan speed.
Appliance not heating/cooling effectively.	Room size too large; settings incorrect; air inlets blocked.	Ensure appliance is suitable for room size; check temperature/mode settings; clean air inlets.
Unusual noise.	Foreign object inside; filter not installed correctly.	Unplug and check for obstructions; re-install filter. If noise persists, contact support.

8. SPECIFICATIONS

Feature	Detail
Brand	Dyson
Model Number	HP07 SB
Product Dimensions (L x W x H)	24.8 cm x 24.8 cm x 76.4 cm
Package Dimensions (L x W x H)	104.5 cm x 28 cm x 28 cm
Color	Silver/Blue
Wattage	40 W
Noise Level	48.9 dB
Package Weight	8.41 kg
Safety Standards	Electrical Appliance and Material Safety Law, Radio Law Technical Standards

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Dyson appliances come with a limited warranty. Please refer to the warranty card included with your product or visit the official Dyson website for detailed terms and conditions specific to your region.

9.2 Customer Support

For further assistance, troubleshooting not covered in this manual, or to purchase replacement parts and filters, please contact Dyson customer support:

- **Website:** www.dyson.com (Check your regional Dyson website for specific contact details)
- **Phone:** Refer to your product registration card or regional Dyson website for local contact numbers.

Please have your model number (HP07 SB) and serial number ready when contacting support.

10. PRODUCT VIDEOS

No official product videos from the seller are available for embedding in this manual.