

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Xbeauty](#) /

› [Xbeauty 44" Electric Fireplace with Mantel - Instruction Manual](#)

## Xbeauty Gary

# Xbeauty 44" Electric Fireplace with Mantel - Instruction Manual

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read and understand this entire instruction manual before attempting to assemble, operate, or install this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Always connect this appliance to a properly grounded outlet.
- Do not operate any fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the fireplace.
- The fireplace is equipped with an overheat protection feature. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool down before restarting.

## 2. PRODUCT OVERVIEW

---

### Components

The Xbeauty 44" Electric Fireplace with Mantel includes the following main components:

- Electric Firebox Insert
- Mantel Surround
- Remote Control
- Assembly Hardware

### Features

- **Elegant Woodgrain Mantel Design:** Crafted from premium MDF and hardwood with delicate carving details.
- **7-Level Adjustable LED Flame Brightness:** Realistic LED flames with glowing logs and dynamic lighting effects.
- **Dual Heating Modes:** 750W and 1500W options for efficient warmth in rooms up to 400 sq.ft.
- **Quiet Blower:** Operates at less than 40dB for gentle, even heat distribution.
- **Safe Operation:** Built-in overheat protection for enhanced safety.
- **Convenient Remote Control:** Adjust flame brightness, power, and heat modes from a distance.



Figure 1: Xbeauty 44" Electric Fireplace with Mantel (Model Gary)



Figure 2: Product Dimensions

### 3. SETUP AND ASSEMBLY

---

#### Unpacking

1. Carefully remove all components from the packaging. The fireplace insert and mantel are packed in separate boxes.
2. Inspect all parts for any damage that may have occurred during shipping. Contact customer support immediately if any parts are damaged or missing.
3. Keep all packaging materials until you are satisfied with the product and its operation.

#### Assembly

The Xbeauty electric fireplace is designed for hassle-free setup. All parts are pre-drilled and labeled for quick and effortless assembly. No professional installation is required.

1. Follow the step-by-step instructions provided in the separate assembly guide included with your product.
2. Ensure all connections are secure before plugging the unit into a power outlet.

3. Place the assembled fireplace on a stable, level surface.

## 4. OPERATING INSTRUCTIONS

---

### Control Panel and Remote Control

The fireplace can be operated using the control panel located on the unit or the included remote control.



Figure 3: Remote Control

## Temperature:500W /1500W



Figure 4: Remote Control in Use

### Remote Control Functions:

- **POWER:** Turns the fireplace ON or OFF.
- **FLAME:** Adjusts the flame brightness (7 levels).
- **HEATER:** Activates the heating function and switches between 750W and 1500W modes.

### Flame Effects

The LED flame effects can be operated independently of the heating function, allowing for year-round ambiance.

- Press the **FLAME** button on the remote control or control panel to cycle through the 7 brightness levels.
- Select the desired brightness to create the perfect atmosphere.

## Seven Flame Brightness Settings are Available



Figure 5: Seven Flame Brightness Settings

## Over-Heating Protection



Figure 6: Flame Brightness Levels (L1-L7)

**Heating Function**

The fireplace offers two heating modes to provide supplemental warmth.

- Press the **HEATER** button on the remote control or control panel to activate the heating function.
- Press again to switch between 750W (low heat) and 1500W (high heat) settings.
- The heater is designed to warm rooms up to 400 sq.ft.



Figure 7: Dual Heating Modes (750W/1500W)

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace.

- **Cleaning:** Ensure the unit is turned OFF and unplugged before cleaning. Use a soft, damp cloth to wipe surfaces. Do not use abrasive cleaners or sprays.
- **Air Vents:** Keep the air intake and exhaust vents clear of dust and debris to ensure proper airflow and prevent overheating.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location.

## 6. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Fireplace does not turn ON.	No power to the unit.	Ensure the power cord is securely plugged into a grounded outlet. Check the circuit breaker.
No heat output.	Heater function is OFF or unit is in flame-only mode.	Press the HEATER button to activate the heating function. Ensure the flame-only mode is not selected.
Flames are not visible or dim.	Flame brightness is set too low.	Press the FLAME button to increase the brightness level.

Problem	Possible Cause	Solution
Remote control not working.	Dead batteries or obstruction.	Replace batteries in the remote control. Ensure there is no obstruction between the remote and the fireplace sensor.
Unit shuts off automatically.	Overheat protection activated.	Unplug the unit, clear any obstructions from vents, and allow it to cool for at least 15 minutes before plugging back in.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Xbeauty
Model Name	Gary
Power Source	Corded Electric
Product Dimensions	12.6"D x 43.39"W x 39.68"H
Material	Engineered Wood, Glass, Metal, Wood
Finish Type	Woodgrain
Installation Type	Freestanding
Heat Output	5100 British Thermal Units
Heating Coverage	400 sq. ft.
Special Feature	Bookshelves, Flame Effect
Color	Gray
Included Components	Firebox, Remote Control
Burner Type	Quartz

## 8. WARRANTY INFORMATION

The Xbeauty 44" Electric Fireplace with Mantel comes with a **Limited Warranty**. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your purchase receipt as proof of purchase for any warranty claims.

## 9. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report a problem with your Xbeauty electric fireplace, please contact our customer support team. For the most up-to-date contact information, please visit the official Xbeauty website or refer to the contact details provided in your product packaging.

We are committed to providing excellent service and support for your Xbeauty product.