Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dyberg Larsen 7200

Dyberg Larsen Haipot 17 cm Rechargeable Desk Lamp Model 7200 User Manual

Your guide to setup, operation, and maintenance

1. Introduction

Thank you for choosing the Dyberg Larsen Haipot 17 cm Rechargeable Desk Lamp, Model 7200. This lamp combines Danish design with practical functionality, offering a versatile lighting solution for both indoor and outdoor environments. Its rechargeable battery and touch control make it convenient for various uses, from a bedside lamp to an outdoor table light. This manual provides essential information for the safe and efficient use of your new lamp.

2. Safety Instructions

- **Read all instructions:** Before using the lamp, read and understand all safety and operating instructions.
- **Indoor/Outdoor Use:** The lamp is designed for both indoor and outdoor use with an IP44 rating, meaning it is protected against solid objects larger than 1mm and splashing water from any direction. However, avoid submerging the lamp in water.
- **Charging:** Use only the provided USB cable for charging. Do not use damaged cables or chargers. Ensure the charging port is dry before connecting the USB cable.
- **Battery Care:** Do not attempt to replace the built-in battery. Do not expose the lamp to extreme temperatures (hot or cold) or direct sunlight for extended periods, as this may affect battery life and performance.
- **Cleaning:** Disconnect the lamp from any power source before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Disassembly:** Do not attempt to disassemble, repair, or modify the lamp. This will void the warranty and may cause damage or injury.
- **Children:** Keep the lamp out of reach of children.

3. Package Contents

Verify that all items are present in the package:

- Dyberg Larsen Haipot 17 cm Rechargeable Desk Lamp (Model 7200)

- 1-meter USB Charging Cable



Image: The included 1-meter USB charging cable, black in color, used to recharge the lamp's internal battery.

4. Setup

4.1 Initial Charging

1. Unpack the lamp and the USB charging cable from the packaging.
2. Locate the charging port on the lamp's base.
3. Connect the small end of the USB cable to the lamp's charging port.
4. Connect the standard USB-A end of the cable to a compatible USB power adapter (not included) or a powered USB port (e.g., on a computer).
5. Allow the lamp to charge fully before its first use. A full charge typically takes several hours. The charging indicator (if present) will change or turn off once charging is complete.

4.2 Placement

Place the lamp on a stable, flat surface. Its compact design and rechargeable nature allow for flexible placement both indoors and outdoors, such as on a desk, bedside table, or garden table.



Image: The blue Haipot lamp placed on a white shelf next to a vase of white flowers, demonstrating typical indoor placement.

5. Operating Instructions

5.1 Power On/Off and Brightness Adjustment

The Haipot lamp features a touch-sensitive control for power and brightness adjustment.

1. **To Turn On:** Lightly touch the designated touch area on the lamp (usually on the top of the shade or base). The lamp will illuminate at its lowest brightness setting.
2. **To Adjust Brightness:** Continue to touch the control area to cycle through the 3 available brightness levels. Each touch will increase the brightness until the maximum level is reached.
3. **To Turn Off:** After cycling through all brightness levels, the next touch will turn the lamp off.



Image: The blue Haipot lamp illuminated, showcasing its light output and design.

5.2 Recharging the Battery

When the lamp's light dims significantly or it no longer turns on, it indicates that the battery needs recharging.

- Connect the lamp to a USB power source using the provided USB cable as described in Section 4.1.
- The lamp can operate while charging, but for optimal battery life, it is recommended to fully charge it before extended use.
- A full charge provides approximately 8 hours of light at the lowest brightness setting.

6. Maintenance

6.1 Cleaning

To maintain the appearance and functionality of your lamp:

- Ensure the lamp is turned off and disconnected from any charging cable.
- Wipe the exterior surfaces with a soft, dry, or slightly damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.

6.2 Storage

If storing the lamp for an extended period:

- Charge the battery to approximately 50-70% before storage to help preserve battery health.
- Store the lamp in a cool, dry place, away from direct sunlight and extreme temperatures.
- Recharge the lamp every 3-6 months during storage to prevent deep discharge.

7. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp using the provided USB cable.
Lamp does not turn on.	Touch control not responding.	Ensure your finger is making proper contact with the touch area. Try a different finger or clean the touch area.
Lamp is not charging.	USB cable or power adapter is faulty.	Try a different USB cable or power adapter. Ensure the power source is active.
Lamp is not charging.	Charging port is dirty or damaged.	Gently clean the charging port with a dry, soft brush. If damaged, do not attempt to repair.
Battery life is shorter than expected.	Lamp used at higher brightness levels.	Battery life is up to 8 hours at the lowest brightness setting. Higher settings consume more power.
Battery life is shorter than expected.	Battery degradation over time.	Rechargeable batteries naturally degrade over time. Ensure proper charging and storage practices.

8. Specifications




Image: Diagram illustrating the dimensions of the Haipot lamp, showing a height of 25.7 cm and a shade diameter of 17 cm.

Feature	Detail
Model Name	Haipot
Model Number	7200
Brand	Dyberg Larsen
Dimensions (H x D)	25.7 cm (10.12 inches) x 17 cm (6.69 inches)
Shade Diameter	17 cm (6.69 inches)
Base Diameter	12 cm (4.72 inches)
Item Weight	0.62 kg (1.36 pounds)
Material	Metal, Alloy Steel (Shade)

Feature	Detail
Light Source	Integrated LED
Wattage	3 Watts (LED), equivalent to 9 Watts incandescent
Power Source	Rechargeable Battery, Corded Electric (for charging)
Battery Life	Up to 8 hours (at lowest brightness setting)
Brightness Levels	3 levels (Touch Control)
Control Method	Touch
IP Rating	IP44 (Protected against splashing water)
Included Components	1m USB cable
Indoor/Outdoor Use	Yes

9. Warranty and Support

Information regarding specific warranty terms and customer support contacts for the Dyberg Larsen Haipot 17 cm Rechargeable Desk Lamp, Model 7200, is not provided within this manual. Please refer to your purchase documentation, the retailer's website, or the official Dyberg Larsen website for detailed warranty information and support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CC8ZGYWL

More documents and user manuals: **https://manuals.plus/**