

[Manuals.plus](#) /

› [Lava](#) /

› Lava A3 Vibe Dual Sim Keypad Mobile Phone User Manual

Lava A3 Vibe

Lava A3 Vibe Dual Sim Keypad Mobile Phone User Manual

Model: A3 Vibe

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Lava A3 Vibe Dual Sim Keypad Mobile Phone. Please read it carefully before using your device to ensure proper operation and to understand its features.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Lava A3 Vibe Mobile Phone
- Battery
- Power Adapter
- Headset
- User Manual

3. PRODUCT OVERVIEW

The Lava A3 Vibe is a reliable dual SIM keypad mobile phone designed for essential communication. It features a long-lasting battery, a clear display, and supports multiple languages.



Image: Front view of the Lava A3 Vibe mobile phone, showcasing its keypad and display.

Key Features:

- **1750 mAh Battery:** Provides extended usage and standby time.
- **1.8-inch Display:** A clear and adequately sized screen for daily use.
- **Dual SIM Support:** Allows for the use of two SIM cards simultaneously.
- **7 Languages Read & Write Support:** Enhances usability for diverse users.
- **Vibration Alert:** Notifies you of incoming calls and messages discreetly.
- **Wireless FM Radio:** Enjoy radio without needing wired headphones.
- **Expandable Storage:** Supports up to 32GB via a memory card.

4. SETUP

4.1 Inserting SIM Card(s) and Battery

1. Gently remove the back cover of the phone.

2. If the battery is already inserted, remove it.
3. Locate the SIM card slot(s). Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down.
4. Insert the battery, ensuring the gold contacts align with the phone's terminals.
5. Replace the back cover until it clicks into place.



Image: A side view of the Lava A3 Vibe, illustrating where the back cover can be removed to access SIM and battery compartments.

4.2 Charging the Phone

Before first use, fully charge the phone's battery.

1. Connect the power adapter to the charging port on your phone.
2. Plug the power adapter into a standard electrical outlet.
3. The charging indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger from the phone and the outlet.

LONG-LASTING POWER

6+ days Battery Backup



Image: The Lava A3 Vibe phone with a prominent battery icon on its screen, indicating long-lasting power.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Press and hold the Power/End Call key (**red button**) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call key (**red button**) until the power off options appear, then select 'Power Off'.

5.2 Making Calls

1. From the idle screen, enter the phone number using the keypad.
2. Press the Call key (**green button**) to initiate the call.
3. To end a call, press the Power/End Call key (**red button**).

5.3 Sending Messages

1. Go to 'Menu' > 'Messages' > 'Write Message'.
2. Enter your message using the keypad.
3. Enter the recipient's phone number or select from contacts.
4. Select 'Send'.

5.4 Using the Keypad

The keypad allows for number input, text entry, and navigation. Use the directional keys (up, down, left, right) and the center selection key to navigate menus. The left and right soft keys perform functions displayed on the screen above them.



Image: A detailed view of the Lava A3 Vibe's keypad and display, showing the layout for navigation and input.

5.5 Wireless FM Radio

Your Lava A3 Vibe supports wireless FM radio, allowing you to listen to your favorite stations without needing to plug in headphones as an antenna.

1. Go to 'Menu' > 'FM Radio'.

2. The phone will automatically scan for available stations or you can manually tune.
3. Adjust the volume using the navigation keys.

POWERFUL VIBRATION SUPPORT

Never Missed a Calls



Image: The Lava A3 Vibe phone screen showing the FM radio interface, with a classic radio icon in the background.

5.6 Camera Function

The phone includes a basic camera for capturing photos.

1. Go to 'Menu' > 'Camera'.
2. Frame your shot using the display.
3. Press the center selection key to take a picture.

LOUD & CLEAR SOUND

Unmatched Clarity, Unbeatable Volume!



Image: The back of the Lava A3 Vibe phone, highlighting the camera lens and speaker grill.

5.7 Language Settings

To change the display language:

1. Go to 'Menu' > 'Settings' > 'Phone Settings' > 'Language'.
2. Select your preferred language from the available options.

6. MAINTENANCE

- Keep the phone dry. Moisture can damage electronic circuits.
- Do not expose the phone to extreme temperatures.
- Clean the phone with a soft, dry cloth. Avoid using harsh chemicals.
- Do not drop, knock, or shake the phone. Rough handling can break internal circuit boards.
- Use only approved batteries, chargers, and accessories.

7. TROUBLESHOOTING

If you encounter issues with your phone, refer to the table below for common problems and solutions.

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly inserted and fully charged.
Cannot make or receive calls	Check if the SIM card is properly inserted and activated. Verify network signal strength.
Poor call quality	Move to an area with better network coverage. Check for obstructions.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background activities.
Keypad unresponsive	Restart the phone. Ensure no physical damage or debris is affecting the keys.

8. SPECIFICATIONS

Detailed technical specifications for the Lava A3 Vibe mobile phone:

Feature	Detail
Brand	Lava
Model	A3 Vibe
Operating System	RTOS
Screen Size	1.77 Inches
Display Type	LCD
Maximum Display Resolution	160x128 Pixels
Battery Capacity	1750 mAh (Lithium-Ion)
Phone Talk Time	Up to 27 Hours
SIM Card Slot Count	Dual SIM
Memory Storage Capacity	32 GB (Expandable)
Camera Description	Rear (5 MP Optical Sensor Resolution)
Connectivity	Bluetooth, USB, 3.5mm Jack
Cellular Technology	2G (GSM)
Human Interface Type	Keypad
Item Weight	109 Grams
Item Dimensions	11.8 x 1.5 x 5 Centimeters
Water Resistance Level	Not Water Resistant

9. WARRANTY AND SUPPORT

Your Lava A3 Vibe mobile phone comes with a **1-year manufacturer warranty** for the device itself, and a **6-month manufacturer warranty** for in-box accessories, including batteries, from the date of purchase.

For technical support or warranty claims, please contact Lava International Ltd. customer service. Refer to the contact information provided in your product packaging or visit the official Lava website for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question