Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Benkut W60-1BDC2

Benkut Modern LED Vanity Lights (2-Pack, 20-inch) Instruction Manual

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Benkut Modern LED Vanity Lights. These dimmable wall sconces feature remote control functionality, allowing for adjustable color temperature (3000K-6500K) and brightness. Designed for indoor use, they are suitable for various rooms including bedrooms, bathrooms, living rooms, and dining rooms.
Please read this manual thoroughly before installation and retain it for future reference.

2. Package Contents

Ensure all components are present and undamaged before proceeding with installation.

- 2 x Benkut Modern LED Vanity Lights
- 2 x Remote Controls
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual



Image 2.1: Contents of the Benkut Modern LED Vanity Lights package, showing two sconces and two remote controls.

3. Specifications

Feature	Specification
Model Number	W60-1BDC2
Dimensions (per light)	19.7"L x 7.5"W x 4.5"H (50cm L x 19cm W x 11.4cm H)
Input Voltage	110V-220V
Wattage	12W MAX (per light)
Light Source	Integrated LED Chips
Color Temperature	3000K-6500K (Adjustable)
Brightness	Up to 1000 Lumens

Dimmable	Yes, via Remote Control
Control Method	Remote Control (Infrared)
Material	Acrylic, Aluminum, Metal
Finish	Painted Black
Installation Type	Semi Flush Mount (Hardwired)
Indoor/Outdoor Usage	Indoor Only




Image 3.1: Detailed product specifications and dimensions of the Benkut LED Vanity Light.




Image 3.2: Visual representation of the light fixture's dimensions (19.7 inches high, 3.94 inches wide).




Image 3.3: Close-up view highlighting the acrylic light bar and durable aluminum construction.

4. Safety Information

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- All wiring connections must be in accordance with local and national electrical codes. If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.
- Do not use with dimmable wall switches. This fixture is designed for use with a standard ON/OFF switch, as dimming is controlled via the included remote.
- Ensure the mounting surface can support the weight of the fixture.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create a safety hazard.
- This product is for indoor use only. Do not expose to water or high humidity.

5. Installation

The Benkut LED Vanity Lights are designed for quick and easy hardwired installation. Follow these steps carefully:

1. **Prepare for Installation:** Turn off the power at the circuit breaker or fuse box to avoid electrical shock. Ensure the power is completely off before proceeding.
2. **Mount the Bracket:** Attach the mounting bracket to the wall junction box using the provided screws. Ensure the bracket is securely fastened.
3. **Connect Wiring:** Connect the fixture's wires to your household electrical wires. Typically, connect the black wire from the fixture to the black (live) wire from the wall, the white wire from the fixture to the white (neutral) wire from the wall, and the ground wire from the fixture to the ground wire from the wall. Secure connections with wire nuts.
4. **Secure the Fixture:** Carefully align the fixture with the mounting bracket and secure it in place using the provided screws. Ensure there are no loose wires or exposed connections.
5. **Restore Power:** Once the fixture is securely installed, restore power at the circuit breaker or fuse box.




Image 5.1: Hard wiring installation diagram illustrating the connection of the wall lamp to an outlet box.

6. Operation

Your Benkut LED Vanity Lights are operated using the included remote control. The remote allows you to adjust both the color temperature and brightness.

6.1 Remote Control Functions

- **ON/OFF:** Press the power button to turn the lights on or off.
- **Color Temperature Adjustment:** Use the dedicated buttons or slider on the remote to cycle through or select color temperatures from 3000K (warm white) to 6500K (cool white/daylight).
- **Brightness Adjustment:** Use the dimming buttons or slider to increase or decrease the light intensity (from 10% to 100%).
- **Memory Function:** The lights will typically remember the last used brightness and color temperature settings when turned off and on again.




Image 6.1: Illustration of the remote control's capabilities for adjusting color temperature and brightness.

6.2 Video Demonstration

Your browser does not support the video tag.

Video 6.1: A demonstration of the Benkut wall sconce's remote control functionality, showcasing color temperature and brightness adjustments.

7. Maintenance

- **Cleaning:** To clean the fixture, ensure power is off. Use a soft, dry cloth to wipe down the surfaces. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic.
- **Bulb Replacement:** The LED light source is integrated and not user-replaceable. The fixture is designed for long-term use.
- **Inspection:** Periodically check the wiring connections and mounting hardware to ensure they remain secure.

8. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Loose wiring connection. Remote control battery is dead.	Check circuit breaker/fuse. Verify all wiring connections are secure (ensure power is off first). Replace remote control battery.
Light flickers or dims unexpectedly.	Loose wiring connection. Incompatible wall dimmer switch.	Check wiring connections (power off). Ensure a standard ON/OFF switch is used, not a dimmer switch.
Remote control not working.	Battery is dead. Obstruction between remote and light. Remote not paired (if applicable).	Replace remote control battery. Ensure clear line of sight. Refer to remote pairing instructions (if provided separately).

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Benkut website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CC9FTC2H

More documents and user manuals: **https://manuals.plus/**