

Babymoov YOO Roll (Model A014431)

Babymoov YOO Roll Wireless Baby Monitor Instruction Manual

Model: YOO Roll (A014431) | Brand: Babymoov

1. INTRODUCTION

Thank you for choosing the Babymoov YOO Roll Wireless Baby Monitor. This device is designed to provide you with peace of mind by allowing you to monitor your baby from anywhere in your home. Featuring rechargeable batteries for both the camera and parent unit, a 3.5-inch infrared screen, and a range of up to 300 meters, the YOO Roll offers convenience and essential features like lullabies and two-way communication. Please read this manual carefully before use to ensure proper operation and safety.

2. SAFETY INFORMATION

- Strangulation Hazard:** Keep all cords out of reach of children (at least 1 meter / 3 feet away). Never place the camera or cords within a baby's crib or playpen.
- Water and Moisture:** Do not expose the units to water, rain, or moisture. Do not use near bathtubs, sinks, or swimming pools.
- Heat Sources:** Keep the units away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- Power Supply:** Use only the provided USB-C cables and compatible power adapters.
- Battery Safety:** Do not attempt to replace the internal rechargeable batteries. Contact customer support if battery issues arise.
- Interference:** This device operates on wireless frequencies. Other wireless devices may cause interference.
- Adult Supervision:** This baby monitor is an aid and should not replace proper adult supervision.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x YOO Roll Baby Unit (Camera)
- 1 x YOO Roll Parent Unit (Monitor)
- 2 x USB-C Charging Cables
- 1 x Instruction Manual (this document)



Figure 3.1: Package Contents - Baby Unit, Parent Unit, and USB-C cables.

4. PRODUCT OVERVIEW

The Babymoov YOO Roll consists of two main units: the Baby Unit (camera) and the Parent Unit (monitor).



Figure 4.1: Babymoov YOO Roll Baby Monitor - Camera and Parent Unit.

4.1 Baby Unit (Camera)

- **Camera Lens:** Captures video of your baby.
- **Infrared LEDs:** Enable night vision for clear viewing in low light or darkness.
- **Microphone:** Picks up sounds from your baby's room.
- **Speaker:** For two-way communication (Talkie-Walkie function).
- **Rechargeable Battery:** Provides wireless operation.




Figure 4.2: Baby Unit (Camera) in a nursery setting, highlighting night vision.

4.2 Parent Unit (Monitor)

- **3.5-inch Screen:** Displays live video feed from the camera.
- **Control Buttons:** For navigating menus, adjusting settings (volume, brightness), and activating features.
- **Speaker:** For listening to your baby and receiving audio alerts.
- **Microphone:** For two-way communication (Talkie-Walkie function).
- **Rechargeable Battery:** Provides portable monitoring.

Caméra de qualité

- Taille minimaliste adaptée
- Vision optimale de nuit comme de jour (infrarouge)
- Design tendance (couleurs pastelles)



Prise en main facile

Menu intuitif avec plusieurs fonctionnalités :

- réglage du volume et de la luminosité
- choix des berceuses
- ...

Figure 4.3: Parent Unit (Monitor) with screen dimensions.

5. SETUP

5.1 Charging the Units

Before first use, fully charge both the Baby Unit and Parent Unit. Use the provided USB-C cables to connect each unit to a compatible USB power adapter (not included) or a USB port.

- **Parent Unit:** Connect the USB-C cable to the charging port on the side of the monitor.
- **Baby Unit:** Connect the USB-C cable to the charging port on the back of the camera.

A full charge provides approximately 10 hours of continuous monitoring.

Vraie révolution :

- Babyphone sur batteries rechargeables, conçu pour vous accompagner dans tous vos déplacements.
- Autonomie de 10 heures, sans fil.



Figure 5.1: Both units are powered by rechargeable batteries for ultimate freedom.

5.2 Placing the Baby Unit (Camera)

Place the Baby Unit on a flat, stable surface in your baby's room, such as a dresser or shelf. Ensure it is at least 1 meter (3 feet) away from the crib or playpen to prevent any cord entanglement hazards. Position the camera to have a clear view of your baby. The camera's compact design allows for flexible placement.



Ultra nomade

- Sans fil (fonctionnement sur batteries rechargeables)
- 10h d'autonomie en mode continu



Ecran multifonctions 3.5"

- Fonction Talkie Walkie pour parler à bébé à distance (300m de portée)
- Alarme visuelle et sonore
- Choix parmi 8 berceuses
- Mise en veille automatique quand aucun son n'est émis



Figure 5.2: The YOO Roll is ultra-portable, ideal for travel.

5.3 Initial Connection

The Baby Unit and Parent Unit are pre-paired at the factory for immediate use. Simply turn on both units, and they should automatically connect. If connection issues occur, refer to the Troubleshooting section.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

- **To Power On:** Press and hold the Power button on both the Baby Unit and Parent Unit until the indicator light illuminates and the screen turns on.
- **To Power Off:** Press and hold the Power button on both units until the indicator light turns off and the screen goes blank.

6.2 Adjusting Settings

The Parent Unit features an intuitive menu for easy adjustments:

- **Volume Adjustment:** Use the dedicated volume buttons on the Parent Unit to increase or decrease the sound level from the Baby Unit.
- **Brightness Adjustment:** Access the menu to adjust the screen brightness for optimal viewing in different lighting conditions.
- **Microphone Sensitivity:** Adjust the microphone sensitivity in the menu to control how easily the Baby Unit picks up sounds.

6.3 Night Vision

The YOO Roll automatically activates infrared night vision in low-light conditions, providing a clear black-and-white image of your baby even in complete darkness.

6.4 Alarms and Alerts

The monitor provides two types of alarms and an out-of-range alert:

- **Audible Alarm:** An audible alert will sound on the Parent Unit when certain conditions are met (e.g., sound detected, out of range).
- **Visual Alarm:** The screen may flash or display an icon to visually indicate an alert.
- **Out-of-Range Alert:** If the Parent Unit moves too far from the Baby Unit (beyond 300m in open space), an alert will notify you of lost connection.

6.5 Sleep Technology (VOX Mode)

The Sleep Technology (VOX mode) is designed to conserve energy and reduce wave emissions. In this mode, the monitor's screen will turn off, and no waves will be emitted when no sound is detected from the baby's room. The unit will automatically reactivate and display video/audio as soon as your baby makes a sound.

6.6 Lullabies

The YOO Roll includes 8 integrated soft lullabies. You can select and play these lullabies from the Parent Unit to soothe your baby to sleep.

6.7 Talkie-Walkie Function (Two-Way Communication)

To reassure your baby remotely, use the Talkie-Walkie function. Press and hold the dedicated button on the Parent Unit to speak, and your voice will be transmitted through the Baby Unit's speaker. Release the button to listen to your baby.

7. MAINTENANCE

- **Cleaning:** Wipe the units with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure units are powered off and unplugged before cleaning.
- **Battery Care:** To prolong battery life, avoid fully discharging the units frequently. Recharge them regularly. If storing for an extended period, charge them to about 50% and store in a cool, dry place.
- **Storage:** Store the monitor in a dry place, away from extreme temperatures and direct sunlight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No image/sound on Parent Unit.	Units are not powered on, out of range, or battery is low.	Ensure both units are powered on. Move Parent Unit closer to Baby Unit. Charge both units.
Poor image quality.	Low light, camera lens dirty, or interference.	Ensure sufficient lighting or check night vision. Clean camera lens. Move away from other electronic devices.
Static or distorted sound.	Interference or units are too far apart.	Move Parent Unit closer to Baby Unit. Adjust microphone sensitivity. Move away from other wireless devices.
Battery not charging.	Cable or adapter issue, or charging port damage.	Ensure USB-C cables are securely connected. Try a different compatible USB power adapter. Contact customer support if problem persists.
Out-of-range alert constantly active.	Obstacles between units, or actual distance is too great.	Reduce distance between units. Minimize obstacles like thick walls.

9. SPECIFICATIONS

Feature	Specification
Model Name	YOO Roll
Model Number	A014431
Screen Size	3.5 inches (7.6 cm)
Video Recording Resolution	480p
Wireless Technology	Wireless (likely 2.4 GHz FHSS)
Range	Up to 300 meters (open space)
Battery Life (Continuous)	Up to 10 hours
Power Source	Rechargeable Lithium Batteries (USB-C included)
Material	Plastic (ABS)
Item Dimensions (L x W x H)	10 x 10 x 10 cm (approximate for each unit)
Item Weight	400 grams (total)
Special Features	Infrared Night Vision, Sleep Technology (VOX), 8 Lullabies, Two-Way Talkie-Walkie, Out-of-Range Alarm
Indoor/Outdoor Use	Indoor
Manufacturer	BABYMOOV

Feature	Specification
Country of Origin	China

10. WARRANTY AND SUPPORT

The Babymoov YOO Roll baby monitor is backed by a **Lifetime Warranty** as part of Babymoov's commitment to eco-responsible design and product longevity. To activate the lifetime warranty, product registration is required within 2 months of purchase. Please refer to the official Babymoov website for detailed terms and conditions regarding warranty registration and claims.



Figure 10.1: Babymoov YOO Roll with Lifetime Warranty.




Babymoov is dedicated to designing products with safe and durable materials, ensuring they are easily repairable if needed, further extending their lifespan and reducing environmental impact.

Customer Support

For technical assistance, warranty claims, or spare parts inquiries, please visit the official Babymoov website or contact their customer service department. Contact details can typically be found on the brand's official website or

product packaging.

Related Documents

	<p><u>Tabella Comparativa Baby Monitor Babymoov: Funzionalità e Modelli</u></p> <p>Questa tabella confronta le funzionalità, le specifiche tecniche, gli accessori e le opzioni di alimentazione dei vari modelli di baby monitor Babymoov, tra cui Simply Care, Easy Care, Esperto Care, Premium Care, Yoo-Start, Yoo-Roll, Yoo-Go(+) HD, Yoo-Master(+) HD e Yoo-Moov.</p>
	<p><u>Babymoov YOO Roll : Guide de la caméra additionnelle</u></p> <p>Ce guide présente les instructions pour l'installation et l'appairage de la caméra additionnelle Babymoov YOO Roll (Réf. A014432). Étendez la surveillance de votre bébé en toute simplicité pour une tranquillité d'esprit accrue.</p>
	<p><u>Babyphone YOO Go Plus User Manual</u></p> <p>Comprehensive user manual for the Babymoov YOO Go Plus baby monitor, covering setup, features, safety warnings, and troubleshooting. Available in multiple languages.</p>
	<p><u>Babymoov YOO Master+ HD Additional Camera Setup Guide</u></p> <p>A concise guide to setting up and pairing the Babymoov YOO Master+ HD additional camera with your parent unit. Includes step-by-step instructions and visual aids.</p>