

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Trayoo](#) /

› Trayoo Kids Tablet 10.1 Inches Android 11 64GB User Manual

## Trayoo Kids Tablet

# Trayoo Kids Tablet 10.1 Inches Android 11 64GB User Manual

Model: Kids Tablet

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your Trayoo Kids Tablet. Please read it thoroughly before operating the device and retain it for future reference.

The Trayoo Kids Tablet is designed for children, featuring a durable kid-proof case, parental control options, and access to educational content and games. It operates on Android 11 and includes 64GB of internal storage.

## 2. PRODUCT OVERVIEW

---

### 2.1 Package Contents

- Trayoo Kids Tablet (Blue)
- Kid-proof case with bracket
- Charging Cable
- User Manual (this document)

### 2.2 Key Features

- 10.1-inch IPS Touch Screen (1280 x 800 resolution)
- Android 11 Operating System
- Quad-core Processor
- 64GB Internal Storage (expandable up to 64GB via TF card)
- Dual Camera
- Wi-Fi and Bluetooth Connectivity
- 5000mAh Battery (up to 6 hours of use)
- Pre-installed iWAWA App for child-friendly content

- Advanced Parental Control features
- Durable Kid-Proof Case with integrated stand

## 2.3 Tablet Components

Refer to the images below for a visual guide to the tablet's components.



Figure 1: Front and Rear View of the Trayoo Kids Tablet in its protective case.




Figure 2: Side view illustrating the tablet's ports and controls.

## 3. SETUP

### 3.1 Initial Charging

Before first use, fully charge the tablet. Connect the provided charging cable to the tablet's charging port and plug the other end into a compatible power adapter (not always included) or a USB port.

- A full charge typically takes approximately 3-4 hours.
- The battery indicator on the screen will show charging status.

## 3.2 Powering On/Off

- To power on: Press and hold the Power button until the screen illuminates.
- To power off: Press and hold the Power button, then select "Power off" from the options that appear on the screen.

## 3.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes:

- Language selection.
- Wi-Fi network connection.
- Google account setup (optional, but recommended for full access to Google Play services).
- Date and time settings.

# 4. OPERATING INSTRUCTIONS

## 4.1 Basic Navigation

- **Touch Screen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access apps, widgets, and notifications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.

## 4.2 Parental Control Mode

The tablet includes a dedicated Parental Control Mode to manage content and screen time for children. This mode allows parents to:

- Control access to specific apps and content.
- Set daily screen time limits.
- Filter websites to ensure safe browsing.
- Create multiple child profiles with customized settings.

Access Parental Control settings through the pre-installed iWAWA app or the tablet's main settings menu.



Figure 3: Parental Control interface for managing tablet usage.

## 4.3 App Management

The tablet comes with the iWAWA app pre-installed, offering a variety of child-friendly games, learning tools, stories, and creative activities. Additional applications can be downloaded from the Google Play Store, including YouTube Kids and ABC Mouse.

- To download apps: Open the Google Play Store app, search for desired applications, and follow the on-

screen prompts to install.

- To uninstall apps: Go to Settings > Apps & notifications, select the app, and choose "Uninstall."



Figure 4: Overview of pre-installed apps and available content sources.

## 5. MAINTENANCE

### 5.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and tablet body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid harsh chemicals.
- Ensure no liquid enters ports or openings.

### 5.2 Protective Case

The included kid-proof case is designed to protect the tablet from scratches, dust, bumps, and drops. The integrated bracket allows for hands-free viewing.



Figure 5: Kid-proof case with anti-drop and stand features.

### 5.3 Battery Care

- Avoid extreme temperatures, which can affect battery life.
- Do not leave the tablet fully discharged for extended periods.
- Use only the provided or a compatible charging cable.

## 6. TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Tablet does not power on.	Ensure the tablet is charged. Connect to a power source and try again. If unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Verify the Wi-Fi password. Restart your router and the tablet.
Apps are running slowly or crashing.	Close unnecessary background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Ensure sufficient storage space. Restart the tablet.
Parental controls are not working as expected.	Review the parental control settings within the iWAWA app or tablet settings. Ensure profiles are correctly configured and time limits are active.
Tablet is not charging.	Check the charging cable and adapter for damage. Try a different compatible cable and adapter. Ensure the charging port is clean and free of debris.

## 7. SPECIFICATIONS

Feature	Detail
Model	Kids Tablet
Operating System	Android 11
Screen Size	10.1 Inches
Max Screen Resolution	1280 x 800 pixels
Processor	Quad-core ARM
Flash Memory Size	64 GB
Expandable Storage	Up to 64GB via TF card
Wireless Type	802.11g (Wi-Fi)
Connectivity	Bluetooth
Cameras	Dual Camera
Battery	5000mAh Lithium Polymer
Average Battery Life	6 Hours
Item Weight	1.96 pounds
Product Dimensions	10.1 x 6.8 x 0.47 inches
Color	Blue

## 8. WARRANTY AND SUPPORT

Trayoo provides a **12-month warranty** for this product. This warranty covers manufacturing defects and

ensures the tablet meets performance standards.

For technical support, warranty claims, or any inquiries regarding your Trayoo Kids Tablet, please contact Trayoo customer service. Contact information can typically be found on the product packaging or the official Trayoo website.

When contacting support, please have your product model number (Kids Tablet) and purchase details available.

## 9. SAFETY INFORMATION

---

- Do not expose the tablet to extreme temperatures, direct sunlight, or moisture.
- Avoid dropping or subjecting the tablet to strong impacts, even with the protective case.
- Keep the tablet away from small children who might ingest small parts.
- Use only manufacturer-approved accessories.
- Do not attempt to disassemble or repair the tablet yourself. Refer to qualified service personnel.
- Prolonged use at high volume levels may cause hearing damage.