

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Vaydeer](#) /

> [Vaydeer Metal Timed Lock Box User Manual](#)

Vaydeer ed5f22fc-f49f-4301-9209-a7d77d24ddcd

Vaydeer Metal Timed Lock Box User Manual

Model: ed5f22fc-f49f-4301-9209-a7d77d24ddcd

INTRODUCTION

This manual provides comprehensive instructions for the Vaydeer Metal Timed Lock Box. This device is designed to assist individuals in developing self-discipline by temporarily restricting access to items such as electronic devices, snacks, or other temptations. Please read this manual thoroughly before initial use to ensure proper operation and to maximize the benefits of your timed lock box.



Image: A family interacting with the Vaydeer Timed Lock Box, illustrating its use in promoting self-discipline and healthy habits.

Key Benefits

- **Enhanced Self-Discipline:** Helps manage habits related to electronic device usage, unhealthy eating, and other distractions.
- **Secure Storage:** Provides a temporary, timed restriction for various items.
- **User-Friendly Interface:** Designed for ease of use with clear controls and display.
- **Durable Construction:** Made from high-quality metal for longevity.

PRODUCT OVERVIEW

Components



Image: The Vaydeer Metal Timed Lock Box, showcasing its sleek design and control panel on the lid.

- **Main Body:** Constructed from durable metal.
- **Lid:** Features an ABS plastic upper lid with an integrated digital display and control buttons.
- **Digital Display:** Shows battery status, child lock status, lid open status, current time (Day, Hour, Min), and lock status.
- **Control Buttons:** Includes setting button, up/down buttons, and locking button.
- **Child Lock Button:** Prevents accidental operation by children.
- **USB-C Port:** For emergency power supply if batteries are depleted.
- **Charging Cable Hole:** Allows charging of devices placed inside the box while locked.

Material and Capacity

The Vaydeer Timed Lock Box is primarily constructed from high-quality metal, ensuring durability and resistance to tampering. The upper lid is made of ABS plastic.

Sturdy Solid Metal



1

Paint

2

Durable metal

Image: An exploded view diagram highlighting the durable metal and paint layers of the lock box's construction.

The interior dimensions of the lock box are approximately 8.03 × 5.33 × 4.72 inches, providing a capacity of 4.9 liters. This allows for storage of various items such as smartphones, iPad Minis, cigarettes, medication, snacks, and game controllers.

Volume: 4.9L

Interior size: 8.03 * 5.33 * 4.72 inch

For phones, ipad mini, snacks, cigarette, alcohol, keys, cash, game console, etc.



Image: The interior of the Vaydeer Timed Lock Box filled with common items, demonstrating its 4.9L capacity.

SETUP

Power Supply


The Vaydeer Timed Lock Box operates using two power supply methods:

1. **Primary Power (Batteries):** Insert 4 x AA batteries into the designated battery compartment. This is recommended for daily use.
2. **Emergency Power (USB-C):** In the event that the batteries are depleted while the box is locked, an external USB-C power supply can be connected to the USB-C port to temporarily power the device and allow unlocking. This port is for emergency use only and not for regular charging of the lock box itself.

Still unlockable by USB-C cable when battery is dead



USB-C connection powered



Daily use



Others:

No way to unlock if battery is run out

Image: Illustration demonstrating how to connect a USB-C cable for emergency power if the internal batteries are dead.

Note: Batteries are not included with the product. Ensure correct polarity when inserting batteries.

OPERATING INSTRUCTIONS

Setting the Lock Time

The Vaydeer Timed Lock Box features a straightforward process for setting the lock duration.



Image: Visual guide to the "Super Easy Buttons" and the three steps for setting the lock time.

1. **Step 1: Press Setting Button** - Press the gear icon button to activate the display and enter setting mode.
2. **Step 2: Set Time** - Use the up (^) and down (v) arrow buttons to adjust the desired locking duration in days, hours, and minutes. The maximum locking duration is 365 days.
3. **Step 3: Start Locking** - Press the lock icon button to initiate the countdown and lock the box.

Important: Once the lock button is pressed and the countdown begins, there is no override function to open the box before the set time expires. Ensure the time is set correctly before confirming.

Audio Prompt

The device includes an audio prompt feature to provide feedback during operation.

- When initiating the lock, the device will emit a "Di Di Di" sound 7 times. You can press any button during this period to cancel the locking process.
- Upon completion of the set locking time, a single "Di" sound will indicate that the box is unlocked.

Audio Prompt to Give You Hesitation Time




Image: Explanation of the audio prompts, including the 7-beep hesitation period before locking and the single beep upon unlocking.

Extending Lock Time

If you wish to extend the remaining lock time, follow these steps:

1. **Step 1:** Press any button to illuminate the screen.
2. **Step 2:** Hold the "setting" button (gear icon) for 5 seconds.
3. **Step 3:** Press the "setting" button repeatedly to cycle through Day/Hour/Min settings.
4. **Step 4:** Use the "Up" (^) button to increase the desired time. Note that time can only be increased, not decreased.
5. **Step 5:** Press the "locking" button (lock icon) to confirm the extended time.




Image: Step-by-step visual guide on how to extend the locking duration of the Vaydeer Timed Lock Box.

Child Lock Function

To prevent accidental button presses by children, the device includes a child lock feature.

- To activate child lock mode: Press the dedicated child lock button. Once activated, no other buttons can be operated.
- To deactivate child lock mode: Hold the child lock button for 3 seconds.

Child Lock Button

No button can be operated in child lock mode

Prevent misoperation by kids



Note: Press the button to start child lock mode and hold the button for **3s** to cancel

Image: A child near the Vaydeer Timed Lock Box, illustrating the purpose and location of the child lock button to prevent unintended operations.

MAINTENANCE

- **Cleaning:** Wipe the exterior with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace all 4 AA batteries when the low battery indicator appears on the display.
- **Storage:** Store the lock box in a dry environment away from extreme temperatures.
- **Water Resistance:** This product is not water resistant. Avoid exposure to liquids.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Dead or incorrectly inserted batteries.	Replace with new AA batteries, ensuring correct polarity.
Box is locked and batteries are dead.	No power for unlocking mechanism.	Connect an external USB-C power source to the emergency port to temporarily power the device and unlock.
Cannot open the box before the timer expires.	No override function is available once locked.	Wait for the set time to expire. Ensure time is set carefully before locking.
Buttons are unresponsive.	Child lock mode is active.	Hold the child lock button for 3 seconds to deactivate.
Audio prompt not working.	Speaker malfunction or low battery.	Check battery level and replace if necessary. If issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Vaydeer
Model Number	ed5f22fc-f49f-4301-9209-a7d77d24ddcd

Feature	Detail
Product Dimensions	5.6"D x 8"W x 5.5"H (Exterior)
Interior Size	8.03" x 5.33" x 4.72"
Lock Type	Electronic Combination Lock
Color	Black
Capacity	4.9 Liters
Material	Metal (main body), ABS Plastic (upper lid)
Power Supply	4 x AA Batteries (not included), USB-C for emergency power
Max Lock Duration	365 Days
Special Features	Charge Your Phone Inside, Easy to Use, Once Lock No Override, Solid Metal, Child Lock Button, Audible Alarm
Item Weight	2.8 Pounds
Water Resistance	Not Water Resistant
UPC	769044608862

WARRANTY AND SUPPORT

Specific warranty information for the Vaydeer Metal Timed Lock Box is not provided in the available product data. For details regarding warranty coverage, technical support, or service inquiries, please refer to the product packaging or contact Vaydeer customer service directly through their official website or the retailer where the product was purchased. You may find additional support resources by visiting the [Vaydeer Store on Amazon](#).

