

ALLIMITY RG57A16/BGEF

ALLIMITY RG57A16/BGEF Replacement Remote Control User Manual

For Midea AC Air Conditioners

INTRODUCTION

This manual provides detailed instructions for the ALLIMITY RG57A16/BGEF Replacement Remote Control. This remote is designed to function as a direct replacement for your original Midea AC Air Conditioner remote, offering seamless control without complex setup.

Compatible Models:

- RG57A16/BGEF
- RG57H3 (B) BGCEF-M
- RG57A2/BGEF
- RG57A3/BGEF
- RG57B/BGE
- RG57D/BGE

SETUP

The ALLIMITY RG57A16/BGEF remote control requires no programming. Simply install batteries to begin operation.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time with new ones. Do not mix old and new batteries or different types of batteries.



Image: Back of the remote control with the battery compartment open, illustrating where to insert AAA batteries.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your ALLIMITY RG57A16/BGEF remote control to effectively operate your Midea AC unit.



Image: Front view of the remote control, displaying the LCD screen and all function buttons.

Button Functions:

- **ON/OFF:** Press to turn the air conditioner unit on or off.
- **MODE:** Cycles through operating modes: Auto, Cool, Dry, Fan, Heat (if supported by AC unit).
- **FAN:** Adjusts the fan speed (Auto, Low, Med, High).
- **TEMP ▲ / ▼:** Increases or decreases the set temperature.
- **SHORT CUT:** Activates a pre-set favorite setting for quick operation.
- **TIMER ON:** Sets a timer for the unit to turn on automatically.
- **TIMER OFF:** Sets a timer for the unit to turn off automatically.
- **SLEEP:** Activates sleep mode, which adjusts temperature for comfortable sleep and saves energy.
- **TURBO:** Engages maximum fan speed and cooling/heating capacity for rapid temperature change.
- **SELF CLEAN:** Initiates the self-cleaning function of the indoor unit (if available).
- **LED:** Turns the display light on the indoor unit on or off.
- **FOLLOW ME:** Activates the 'Follow Me' function, where the remote's sensor measures the temperature and adjusts the AC accordingly.
- **◀ / ▶ (Swing/Airflow):** Adjusts the horizontal or vertical airflow direction (functionality may vary by AC model).

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your remote control.

Cleaning:

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Care:

- Replace batteries when the remote's response becomes sluggish or the display dims.
- If the remote will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and potential damage.
- Dispose of used batteries according to local regulations.

TROUBLESHOOTING

If you encounter issues with your remote control, refer to the following common problems and solutions:

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the proper polarity.
 - Replace old batteries with new 1.5V AAA alkaline batteries.
 - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Obstructions can block the infrared signal.
 - Confirm that the remote is pointed directly at the AC unit.
- **Limited range:**
 - Ensure batteries are fresh. Weak batteries can reduce signal strength.
 - Remove any obstacles between the remote and the AC unit.
- **AC unit not responding to specific functions:**
 - Some advanced functions (e.g., Self Clean, Follow Me) may only be available on specific Midea AC models. Refer to your air conditioner's original manual to confirm feature availability.

SPECIFICATIONS

Model Number	RG57A16/BGEF (Internal SKU: CV-RG57A16-BGEF-SH)
Product Dimensions	6.5 x 1.38 x 0.72 inches
Item Weight	1.59 ounces
Power Supply	2 x 1.5V AAA Batteries (not included)
Compatible Devices	Midea AC Air Conditioners
Connectivity Technology	Infrared
Special Feature	Ergonomic design

WARRANTY AND SUPPORT

For warranty information, technical assistance, or customer support regarding your ALLIMITY RG57A16/BGEF Replacement Remote Control, please refer to your purchase documentation or contact the seller directly. Specific warranty terms may vary based on the retailer and region of purchase.

ALLIMITY Replacement Remote Control Manual