Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY Y512F2

ALLIMITY Y512F2 Replacement Remote Control User Manual

For GREE, Trane, and Electrolux Air Conditioners

Introduction

This manual provides instructions for the ALLIMITY Y512F2 replacement remote control. This remote is designed to operate various GREE, Trane, and Electrolux air conditioner models. Please read this manual carefully to ensure proper setup and operation of your new remote control.

Compatibility

The ALLIMITY Y512F2 replacement remote control is compatible with the following air conditioner remote models:

- Y512F
- Y512F2
- Y502K
- Y512FA
- KTGL002
- Y512

This remote is suitable for use with various GREE, Trane, and Electrolux brand air conditioning units that originally used one of the listed remote models.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

No programming or setup is required. The remote control will function immediately after battery installation.



Image: Back view of the remote control with the battery compartment open, illustrating where to insert two AAA batteries.

Operating Instructions

Familiarize yourself with the buttons on your ALLIMITY Y512F2 remote control. Below is a general guide to common functions:





Image: Front view of the remote control, displaying the LCD screen and all function buttons.

- **ON/OFF Button:** Press to turn the air conditioner unit on or off.
- **MODE Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **SLEEP Button:** Activates or deactivates the sleep mode, which often adjusts temperature and fan speed for comfortable sleep.
- **SWING Button:** Controls the louver swing function for air direction.
- **AIR Button:** May control specific air purification or circulation features, depending on the AC unit model.
- **LIGHT Button:** Turns the display light on or off on the air conditioner unit.
- **T-ON Button:** Sets a timer for the air conditioner to turn on automatically.
- **T-OFF Button:** Sets a timer for the air conditioner to turn off automatically.
- **+°C / -°C Buttons:** Adjusts the desired temperature setting upwards or downwards.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure that the batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the remote is unresponsive or the display is dim, replace the old batteries with new 1.5V AAA alkaline batteries.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Obstructions can block the signal.
- **Distance:** Make sure you are within the effective operating range of the air conditioner unit.

Specifications

Feature	Detail
Model Number	Y512F2
Power Supply	2 x 1.5V AAA Batteries (not included)
Product Dimensions	6.5 x 1.38 x 0.72 inches

Item Weight	1.59 ounces
Special Feature	No Programming Required
Compatible Devices	Air Conditioner

Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the terms provided by your seller at the time of purchase. For any operational issues or further assistance, please contact the seller directly through your purchase platform.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCDFV9D6

More documents and user manuals: **https://manuals.plus/**